



Synway SMG Series Analog Gateway

SMG1008

SMG1016

SMG1032

SMG1032A2

SMG1032A4

Analog Gateway

User Manual

Version 1.7.6

Synway Information Engineering Co., Ltd

www.synway.net

Content

Content	i
Copyright Declaration	iii
Revision History	iv
Chapter 1 Product Introduction.....	1
1.1 Typical Application	1
1.2 Feature List.....	2
1.3 Hardware Description	3
1.4 Alarm Info	6
Chapter 2 Quick Guide.....	7
Chapter 3 WEB Configuration	12
3.1 System Login	12
3.2 Operation Info	14
3.2.1 System Info	14
3.2.2 Channel State.....	15
3.2.3 Call Count.....	16
3.2.4 SIP Message Count	17
3.3 Quick Config	17
3.4 VoIP Settings	20
3.4.1 SIP.....	21
3.4.2 SIP Compatibility	22
3.4.3 SIP Station.....	26
3.4.4 SIP Server	28
3.4.5 NAT Setting	30
3.4.6 Media.....	33
3.5 Advanced Settings.....	35
3.5.1 FXS.....	36
3.5.2 FXO	38
3.5.3 Tone Detector.....	40
3.5.4 Tone Generator	43
3.5.5 DTMF.....	44
3.5.6 Ringing Scheme.....	45
3.5.7 Fax.....	46
3.5.8 Function Key	48
3.5.9 Dialing Rule.....	50
3.5.10 Dialing Timeout	53
3.5.11 Cue Tone	54
3.5.12 Color Ring	55
3.5.13 QoS	56
3.5.14 Action URL	57
3.6 Port Settings	57
3.6.1 FXS.....	57
3.6.2 FXO	62

3.6.3	FXO Port Timer	66
3.6.4	FXO List Timer	68
3.6.5	Port Group.....	69
3.6.6	Advanced FXO Settings.....	75
3.7	Route Settings	76
3.7.1	Routing Parameters	76
3.7.2	IP to Tel.....	77
3.7.3	Tel to IP	79
3.8	Number Manipulation.....	81
3.8.1	IP to Tel CallerID	82
3.8.2	IP to Tel CalleeID.....	86
3.8.3	Tel to IP CallerID	87
3.8.4	Tel to IP CalleeID.....	90
3.9	System Tools	91
3.9.1	Management	92
3.9.2	Configuration File	94
3.9.3	Network	95
3.9.4	Upgrade.....	96
3.9.5	Signaling Capture.....	98
3.9.6	Call Log	98
3.9.7	Operation Log.....	99
3.9.8	Backup & Upload	100
3.9.9	Factory Reset.....	101
3.9.10	System Monitor	101
3.9.11	Centralized Manage	102
3.9.12	Access Control	103
3.9.13	Call Test.....	105
3.9.14	PING Test.....	107
3.9.15	TRACERT Test.....	108
3.9.16	Change Password.....	109
3.9.17	Restart.....	109
Appendix A Technical Specifications		110
Appendix B Troubleshooting		111
Appendix C Technical/sales Support		114

Copyright Declaration

All rights reserved; no part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, without prior written permission from Synway Information Engineering Co., Ltd (hereinafter referred to as 'Synway').

Synway reserves all rights to modify this document without prior notice. Please contact Synway for the latest version of this document before placing an order.

Synway has made every effort to ensure the accuracy of this document but does not guarantee the absence of errors. Moreover, Synway assumes no responsibility in obtaining permission and authorization of any third party patent, copyright or product involved in relation to the use of this document.

Revision History

Version	Date	Comments
Version 1.0	2013-10	Initial publication
Version 1.3.0	2014-03	New revision
Version 1.3.1	2014-06	Add description on the new series SMG1032A2
Version 1.3.2	2014-07	New revision
Version 1.3.3	2014-09	New revision
Version 1.3.5	2014-10	New revision
Version 1.5.0	2014-12	Add description on the new series SMG1032A4
Version 1.5.1	2015-01	New revision
Version 1.5.2	2015-04	New revision
Version 1.5.3	2015-11	New revision
Version 1.6.0	2016-03	New revision
Version 1.6.3	2016-12	New revision
Version 1.6.4	2017-02	New revision
Version 1.7.1	2017-05	New revision
Version 1.7.6	2018-01	New revision

Note: Please visit our website <http://www.synway.net> to obtain the latest version of this document.

Chapter 1 Product Introduction

Thank you for choosing Synway SMG Series Analog Gateway!

The Synway SMG series analog gateway products (hereinafter referred to as 'SMG analog gateway') are mainly used for connecting traditional phone sets, fax machines and PBXes with the IP telephony network or IP PBX. It provides a powerful, reliable and cost-effective VoIP solution for such occasions as IP call centers and multi-branch agencies.

SMG series analog gateway has five modules:

- SMG1008: 8 FXS/FXO
- SMG1016: 16 FXS/FXO
- SMG1032, SMG1032A2, SMG1032A4: 32 FXS/FXO

1.1 Typical Application




Figure 1-1 Typical Application

1.2 Feature List

Basic Features	Description
TDM Call	Call initiated from TDM to IP, via routing and number manipulation to obtain the called IP address.
IP Call	Call initiated from IP to TDM, via routing and number manipulation to obtain the call destination.
Number Manipulation	Peels off some digits of a phone number from left/right, or adds a prefix/suffix to a phone number.
Call Forward	Three options available: Unconditional, Busy and No Reply.
Call Waiting	When an FXS channel receives another call while it is in conversation, it will have the newly received call keep waiting. Once the current call is finished, the new one will ring the FXS channel and wait for its answer.
Auto Dial	If there is no dialing operation in a designated time period after pickup, the preset auto dial number will be called.
Do Not Disturb	Rejects all the incoming calls to the channel.
CID	Displays the CallerID.
Echo Cancellation	Provides the echo cancellation feature for a call conversation over the FXS/FXO channel.
TDM/VoIP Routing	Sets a routing path: from IP to TDM or from TDM to IP.
Fax	Provides multiple fax parameters: fax mode, maximum fax rate, fax train mode, error correction mode, etc.
Communication without Power	Provides composite modules to enable a direct connection of the station which is linked with the FXS port and the trunk which is linked with the FXO port to keep the calls between the FXS port and PSTN uninterrupted during power outage.
Communication without Network	Automatically routes a call to the proper port according to the configuration in case of network failure or call timeout.
Send Polarity Reversal Signal	Sends the polarity reversal signal to a corresponding FXS channel when the called party pick-up behavior is detected.
Detect Polarity Reversal Signal	Turns a corresponding channel into the talking state when the FXO port detects the polarity reversal signal.
Simultaneous Register to Multiple Servers	Registers the gateway to a master registrar server and a spare registrar server simultaneously.
IMS Network	Registers the gateway to a server under IMS network.
SIP Station	Supports a SIP terminal to be registered to the gateway and become a SIP station.
Group Ringing	Rings all the idle FXS ports in a port group.
Ringling by Turns	Rings the FXS ports in a port group by turns according to the <i>Rule for Ringling by Turns</i> .
Preemptive Answer	When a channel in a port group is ringing, another channel in the same port group can press the preemptive answer keyboard shortcut to transfer the call from the

	ringing channel to the current channel.	
Centralized Manage	The gateway can register to Synway DCMS platform and accept the management of the platform.	
Signaling & Protocol	Description	
SIP Signaling	Supported protocol: SIP V1.0/2.0, RFC3261.	
Voice	CODEC	G.711A, G.711U, G.729A/B, G.723, G.722, AMR, iLBC, SILK(16K), OPUS(16K), SILK(8K), OPUS(8K)
	DTMF Mode	RFC2833, SIP INFO, INBAND
Network	Description	
Network Protocol	Supported protocol: TCP/UDP, HTTP, ARP/RARP, DNS, NTP, TFTP, TELNET, STUN.	
Static IP	IP address modification support.	
DHCP	IP address dynamic allocation support.	
PPPoE	Virtual dial-up internet access support.	
DNS	Domain Name Service support.	
Security	Description	
Admin Authentication	Supports admin authentication to guarantee the resource and data security.	
System Monitor	Monitors the running status of the system and the server.	
Maintain & Upgrade	Description	
WEB Configuration	Support of configurations through the WEB user interface.	
Language	Chinese, English.	
Software Upgrade	Support of user interface, gateway service, kernel and firmware upgrades based on WEB.	
Tracking Test	Support of Ping and Tracert tests based on WEB.	
SysLog Type	Three options available: ERROR, WARNING, INFO.	

1.3 Hardware Description

The SMG analog gateway features 1U rackmount design and integrates embedded LINUX system within the POWERPC+DSP hardware architecture. It has 8/16/32 voice ports (FXS/FXO) and 2 LANs on the chassis. Each voice port can be configured on demand to serve as an FXS or FXO interface; however, the respective amount of FXS and FXO interfaces must be multiples of 2. See below for product appearance.



Figure 1-2 SMG1032 Front View



Figure 1-3 SMG1032 Rear View



Figure 1-4 SMG1032A2 Front View



Figure 1-5 SMG1032A2 Rear View




Figure 1-6 SMG1032A4 Front View



Figure 1-7 SMG1032A4 Rear View



Figure 1-8 Left View

The table below gives a detailed introduction to the interfaces, buttons and LEDs illustrated above:

Interface	Description
LAN	Amount: 2
	Type: RJ-45
	Bandwidth: 10/100Mbps
	Self-Adaptive Bandwidth Supported
	Auto MDI/MDIX Supported
FXS/FXO	Amount: 8/16/32
	Type: RJ-11, RJ-21, RJ45
	Maximum Transmission Distance: 1500m
	Charge Mode: Negative Anti-billing Supported
Console Port	Amount: 1
	Type: RS-232
	Baud Rate: 115200bps
	Connector: RJ45 to DB-9 Connector
	Data Bits: 8 bits
	Stop Bit: 1 bit
	Parity Unsupported
	Flow Control Unsupported
Button	Description
Power Key	Power on/off the SMG analog gateway.
Reset Button	Restore the gateway to factory settings.
LED	Description
Power Indicator	Indicates the power state. It lights up when the gateway starts up with the power cord well connected
Run Indicator	Indicates the running status. For more details, refer to 1.4 Alarm Info .
Alarm Indicator	Alarms the device malfunction. For more details, refer to 1.4 Alarm Info .
Link Indicator	The green LED on the left of LAN, indicating the network connection status.

ACT Indicator	The orange LED on the right of LAN, whose flashing tells data are being transmitted.
Channel Indicator	FXS and FXO channels are respectively marked by green and red LED after power on. <ol style="list-style-type: none">1. When the channel is idle, the LED Lights up;2. When the channel is off-hook, the LED flashes slowly;3. When the channel is ringing, the LED flashes fast.

For other hardware parameters, refer to [Appendix A Technical Specifications](#).

1.4 Alarm Info

The SMG analog gateway is equipped with two indicators denoting the system's running status: Run Indicator (green LED) and Alarm Indicator (red LED). The table below explains the states and meanings of the two indicators.

LED	State	Description
Run Indicator	Go out	System is not yet started.
	Light up and flash fast	System is starting.
	Flash slowly	System is normal.
Alarm Indicator	Go out	System is normal.
	Light up	Upon startup: System is normal. In runtime: System is abnormal.
	Flash	System is abnormal.

Note:

- The startup process consists of two stages: System Booting and Gateway Service Startup. The system booting costs about 1 minute and once it succeeds, both the run indicator and the alarm indicator light up. Then after the gateway service is successfully started and the device begins to work normally, the run indicator flashes and the alarm indicator goes out.
- During runtime, if the alarm indicator lights up or flashes, it indicates that the device goes abnormal. If you cannot figure out and solve the problem by yourself, please contact our technicians for help. Go to [Appendix C Technical/sales Support](#) to find the contact way.

Chapter 2 Quick Guide

This chapter is intended to help you grasp the basic operations of the SMG analog gateway in the shortest time.

Step 1: Confirm that your packing box contains all the following things.

- SMG Series Analog Gateway *1
- Angle Bracket *2, Rubber Foot Pad *4, Screw for Angle Bracket *8
- 220V Power Cord *1
- Warranty Card *1
- Installation Manual *1

Step 2: Properly fix the SMG analog gateway.

If you do not need to place the gateway on the rack, simply fix the 4 rubber foot pads. Otherwise, you should first fix the 2 angle brackets onto the chassis and then place the chassis on the rack.

Step 3: Connect the power cord.

Make sure the device is well grounded before you connect the power cord. Check if the power socket has the ground wire. If it doesn't, use the grounding stud on the rear panel of the device (See Figure 1-3) for earthing.

Step 4: Connect the network cable.

Step 5: Connect the telephone line. The line from PSTN should be connected to FXO port (port with red LED flashing); the line from station should be connected to FXS port (port with green LED flashing).

The connection for SMG1008, SMG1016, SMG1032 series products:

These series products provide RJ11 interfaces. You can use a common telephone line directly or construct a telephone line by yourself according to Figure 2-1. Note that only the middle two cores in the RJ11 jack are valid for use.




Figure 2-1 RJ11 Connection

The connection for SMG1032A2 series product:

SMG1032A2 adopts two RJ21 interfaces each of which accommodates 16 channels. One corresponds to channels 1 through 16 and the other corresponds to 17 through 32. Each pin in the RJ21 connector functions as follows.




Figure 2-2 RJ21 Pin Layout

The pins Ch1-a/b through Ch16-a/b on the RJ21 interface will be used respectively corresponding

to channels 1 through 16.

An RJ21 interface can be converted to 24 RJ11 interfaces through an RJ21-to-RJ11 adapter. See Figure 2-3 for the connection. SMG1032A2 needs two RJ21-to-RJ11 adapters of which the first 16 slots will be used.




Figure 2-3 RJ21-to-RJ11 Adapter Connection

Users can also use the RJ21 connecting cable directly.

SMG1032A4 has eight 8-pin RJ45 jacks each of which can be connected to four 2-pin RJ11 jacks via a 4-way hub. Take the first RJ45 jack for example, the matching relationship among the channel number, the pins of the RJ45 jack and the 4-way hub is shown in the table below.

Interface	Channel Number	Pins of the RJ45 Jack	4-way Hub
First RJ45 Jack	1	1 st and 2 nd pins	1 st jack
	2	3 rd and 4 th pins	2 nd jack
	3	5 th and 6 th pins	3 rd jack
	4	7 th and 8 th pins	4 th jack

Table 2-1 Matching Relationship among Channel Number, Pins of RJ45 Jack and 4-way Hub

Step 6: Power on and start the gateway.

Step 7: Log in the gateway.

Enter the original IP address (LAN1: 192.168.1.101) of the SMG analog gateway in the browser to go to the WEB interface of the gateway. The original username and password of the gateway are both 'admin'. For detailed instructions about login, refer to [3.1 System Login](#). We suggest you change the initial username and password via 'System Tools → Change Password' on the WEB interface as soon as possible after your first login. For detailed instructions about changing the password, refer to [3.9.15 Change Password](#). After changing the password, you are required to log

in again.

Step 8: Modify IP address of the gateway.

You can modify the IP address of the gateway via 'System Tools → Network' on the WEB interface to put it within your company's LAN. Refer to [3.9.3 Network](#) for detailed instructions about IP modification. After changing the IP address, you shall log in the gateway again using your new IP address.

Step 9: Make phone calls.

Note: For your easy understanding and manipulation, all examples given in this step do not involve registration, that is, SIP initiates calls in a point-to-point mode.

Situation 1: Call from a station to another (Tel→Tel)

The gateway allows two FXS ports to call each other by default. Just use a station connected with an FXS port to dial the number of the destination FXS port and you can make a Tel→Tel call. The default number of an FXS port is 80XX, among which XX represents the corresponding port number. For example, the default number corresponding to Port 1 is 8001, and that corresponding to Port 32 is 8032.

Actually a Tel→Tel call on the gateway is accomplished via the routing of Tel→IP→IP→Tel. For detailed introductions and configuration guide, refer to [Q2](#) in Appendix B.

Situation 2: Call from a station to an IP phone (Tel→IP)

1. Go to 'Advanced Settings → Dialing Rule' on the WEB interface and click the 'Add New' button to add a new dialing rule. Refer to [3.5.9 Dialing Rule](#) for detailed instructions. Enter either a particular number or a string of 'x's to represent several random numbers. For example, 'xxx' denotes 3 random numbers. You may use the default value of 'Index' and are required not to leave 'Description' empty.

Example: Set **Index** to **99**, fill in **Description** with **test** and configure **Dial Rule** to **123**.

2. Go to 'Port Settings → Port Group' on the WEB interface and click the 'Add New' button to create a new port group and add FXS ports which are connected with stations to it. Refer to [3.6.4 Port Group](#) for detailed instructions. You may use the default values of other configuration items and are required not to leave 'Description' empty.

Example: Provided the FXS port which is connected with a station is Port1, check the checkbox before **Port1**, set **Index** to **1**, fill in **Description** with **test**, and keep the default values of other configuration items.

3. Go to 'Route Settings → Tel→IP' on the WEB interface and click the 'Add New' button to add a new routing rule. Refer to [3.7.3 Tel→IP](#) for detailed instructions. Select the port group created in Step2 as 'Source Port Group' and fill in 'Destination IP' and 'Destination Port' with the IP address and the Port number you plan to call. You may use the default values of other configuration items and are required not to leave 'Description' empty.

Example: Provided the remote IP address intended to call is 192.168.0.111 and the port is 5060. Set **Index** to **63**, **Source Port Group** to **1**, fill in **Description** with **test**, configure **Destination IP** to **192.168.0.111**, **Destination Port** to **5060**, and keep the default values of other configuration items.

4. Pick up the station and dial the number set in Step1 to ring the remote IP phone. If you have set a particular number in Step 1, only this number you can dial; if you have set a string of 'x's, how many 'x's there are, how many random numbers you can dial.

Example: Pick up the station and dial 123. Then the IP phone with the IP address 192.168.0.111 and the port 5060 will ring.

Situation 3: Call from an IP phone to a station (IP →Tel)

1. Go to 'Port Settings → Port Group' on the WEB interface and click the 'Add New' button to create a new port group and add FXS ports which are connected with stations to it. Refer to

[3.6.4 Port Group](#) for detailed instructions. You may use the default values of other configuration items and are required not to leave 'Description' empty.

Example: Provided the FXS port which is connected with a station is Port1, check the checkbox before **Port1**, set **Index** to **1**, fill in **Description** with **test**, and keep the default values of other configuration items.

- Go to 'Route Settings → IP→Tel' on the WEB interface and click the 'Add New' button to add a new routing rule. Refer to [3.7.2 IP→Tel](#) for detailed instructions. Fill in 'Source IP' with the IP address which initiates the call and select the port group created in Step1 as 'Destination Port Group'. You may use the default values of other configuration items and required not to leave 'Description' empty.

Example: Provided the IP address of the IP phone which initiates the call is 192.168.0.111. Set **Index** to **63**, **Destination Port Group** to **1**, fill in **Description** with **test**, configure **Source IP** to **192.168.0.111**, and keep the default values of other configuration items.

- Pick up the IP phone and call the IP address and port of the SMG analog gateway to ring the station.

Example: Provided the IP address of the SMG analog gateway is 192.168.0.101 and the port is 5060, use the IP phone to call the IP address 192.168.0.101 and the station connected with Port1 will ring.

Step 10: Enable the auto dial feature. (Skip this step if not necessary.)

Go to the Port Settings interface to enable the auto dial feature and set the parameters 'Auto Dial Number' and 'Wait Time before Auto Dial'. If there is no dialing operation in a time period (i.e. Wait Time before Auto Dial) after pickup, the port will automatically call the preset number (i.e. Auto Dial Number). Refer to [3.6.1 FXS](#) for detailed instructions.

Step 11: Enable the DND (do not disturb) feature. (Skip this step if not necessary.)

Go to the Port Settings interface to enable the DND feature. Then, the FXS port will reject all incoming calls. Refer to [3.6.1 FXS](#) for detailed instructions.

Step 12: Enable the call waiting feature. (Skip this step if not necessary.)

Go to the Port Settings interface to enable the call waiting feature. Then the corresponding FXS port while in conversation can accept another call from IP and keep it in the waiting state. Once the current conversation is finished and the station hangs up, the call in the waiting state will ring the station and wait for answer. During the time in the waiting state, it will always hear the ringback tone from the FXS port. Refer to [3.6.1 FXS](#) for detailed instructions.

Step 13: Perform call forwarding. (Skip this step if not necessary.)

Situation 1: Hook-flash operation




Figure 2-4 Call Forward via Hook-flash

As shown above, Remote A initiates and establishes a call with Station. Then by a hook-flash operation, that is, a rapid clap on the hook or pressing the 'flash' button on the phone set, Station can forward the call to Remote B.

Once a flash is generated, Station will go into the dialing state (the FXS port sends it dialing tones) before it dials the forwarding number.

If the dialing succeeds, the FXS port will send ringback tones to Station. Provided Remote B picks up the call, at this time Station can:

- a) Directly talk with Remote B;
- b) Perform another hook-flash operation to switch the call to either Remote A or Remote B.
- c) Hang up to make Remote A and Remote B go into a direct talk with each other.

If the dialing fails, the FXS port will send busy tones to Station. At this time Station can:

- a) Hang up to go back to the ringing state; then pick up the call again to recover the talk with Remote A.
- b) Perform the hook-flash operation again without hanging up the call to recover the talk with Remote A.

Once Station recovers the call with Remote A, it can forward the call again by a new hook-flash operation.

Situation 2: Automatic call forward

Go to the port setting interface to enable the automatic call forward feature and fill in a forward number. According to what you set, the SMG analog gateway can automatically forward the incoming calls on three conditions: unconditional, busy, no reply. Note that this feature is applicable only to a single port, but not to a port group consisting of more than one port. Refer to [3.6.1 FXS](#) for detailed instructions.

Special Instructions:

- The chassis of the SMG analog gateway must be grounded for safety reasons, according to standard industry requirements. A simple way is earthing with the third pin on the plug or the grounding studs on the machine. No or improper grounding may cause instability in operation as well as decrease in lightning resistance.
- As the device will gradually heat up while being used, please maintain good ventilation to prevent sudden failure, ensuring that the ventilation holes (see Figure 1-8) are never jammed.
- During runtime, if the alarm indicator lights up or flashes, it indicates that the device goes abnormal. If you cannot figure out and solve the problem by yourself, please contact our technicians for help. Otherwise it may lead to a drop in performance or unexpected errors.

Chapter 3 WEB Configuration

3.1 System Login

Type the IP address into the browser and enter the login interface. See Figure 3-1.




Figure 3-1 Login Interface

The gateway only serves one user, whose original username and password are both 'admin'. You can change the username and the password via 'System Tools → Change Password' on the WEB interface. For detailed instructions, refer to [3.9.15 Change Password](#).

After login, you can see the main interface as below.

System Info

LAN 1

MAC Address	80:7B:85:10:2E:75		
IP Address	201.123.115.141	255.255.255.0	201.123.115.254
DNS Server	0.0.0.0		
Receive Packets	All:300120	Error:0	Drop:0
Transmit Packets	All:38088	Error:0	Drop:0
Current Speed	Receive:2.3 KB/s Transmit:220 B/s		
Work Mode	100Mb/s Full Duplex		

LAN 2 Disable

Runtime 5h 54m 3s

Current Version

WEB	forcommon_1.7.6_2018011119
Gateway	forcommon_1.7.6_2018011119
Serial No.	000007422
U-boot	Apr 09 2015 - 16:39:07
Kernel	#205 PREEMPT Tue Jan 19 11:30:24 CST 2016
Product Type	1032A2(RJ21)

Refresh

Figure 3-2 Main Interface

3.2 Operation Info

Operation Info includes four parts: **System Info**, **Channel State**, **Call Count** and **SIP Message Count**, showing the current running status of the gateway. See Figure 3-3.




Figure 3-3 Operation Info

3.2.1 System Info



Figure 3-4 System Info Interface

See Figure 3-4 for the system info interface. You can click **Refresh** to obtain the latest system information. The table below explains the items shown in Figure 3-4.

Item	Description
------	-------------

MAC Address	MAC address of LAN 1 or LAN 2 (disabled by default).
IP Address	The three parameters from left to right are IP address, subnet mask and default gateway of LAN 1 or LAN 2 (disabled by default).
DNS Server	DNS server address of LAN 1 or LAN 2 (disabled by default).
Receive Packets	The amount of receive packets after the gateway's startup, including three categories: All, Error and Drop.
Transmit Packets	The amount of transmit packets after the gateway's startup, including three categories: All, Error and Drop.
Current Speed	The current speed of data receiving and transmitting.
Work Mode	The work mode of the network, including four options: 10 Mbps Half Duplex, 10 Mbps Full Duplex, 100 Mbps Half Duplex, 100 Mbps Full Duplex.
Runtime	Time of the gateway keeping running normally after startup, which will be automatically updated.
WEB	Current version of the WEB interface.
Gateway	Current version of the gateway service.
Serial No.	Unique serial number of an SMG analog gateway.
U-boot	Current version of Uboot.
Kernel	Current version of the system kernel on the gateway. Note: The kernel version for the gateways with RJ45/RJ21 interface is different from that for the gateways with RJ11 interface.
Product Type	The type of the analog gateway.




























3.2.2 Channel State

Channel State										Channel State									
Channel	Type	Number	Voltage(v)	State	Direction	CallerID	CalleeID	Reg Status	Polarity Reversal Count	Channel	Type	Number	Voltage(v)	State	Direction	CallerID	CalleeID	Reg Status	Polarity Reversal Count
1	---	---	0		---	---	---	---	---	17	---	---	0		---	---	---	---	---
2	---	---	0		---	---	---	---	---	18	---	---	0		---	---	---	---	---
3	---	---	0		---	---	---	---	---	19	---	---	0		---	---	---	---	---
4	---	---	0		---	---	---	---	---	20	---	---	0		---	---	---	---	---
5	---	---	0		---	---	---	---	---	21	---	---	0		---	---	---	---	---
6	---	---	0		---	---	---	---	---	22	---	---	0		---	---	---	---	---
7	---	---	0		---	---	---	---	---	23	---	---	0		---	---	---	---	---
8	---	---	0		---	---	---	---	---	24	---	---	0		---	---	---	---	---
9	---	---	0		---	---	---	---	---	25	---	---	0		---	---	---	---	---
10	---	---	0		---	---	---	---	---	26	---	---	0		---	---	---	---	---
11	---	---	0		---	---	---	---	---	27	---	---	0		---	---	---	---	---
12	---	---	0		---	---	---	---	---	28	---	---	0		---	---	---	---	---
13	FXS	123	0		---	---	---	Unregistered	---	29	---	---	0		---	---	---	---	---
14	FXS	124	0		---	---	---	Unregistered	---	30	---	---	0		---	---	---	---	---
15	---	---	0		---	---	---	---	---	31	FXO	8031	0		---	---	---	Unregistered	---
16	---	---	0		---	---	---	---	---	32	FXO	8032	0		---	---	---	Unregistered	---

Figure 3-5 Channel State Interface

See Figure 3-5 for the channel state interface where shows the channel type, the voltage and the channel state for each channel on the gateway. The table below explains the items shown in Figure 3-5.

Item	Description
Channel	Channel number on the device.
Type	Type of the channel on the device: FXS or FXO. If this item shows ---, it means this channel is unavailable, that is, the corresponding module to this channel is not inserted or damaged.

	Note: If the FXO port is unconnected, the channel is unavailable too.																														
Number	The number corresponding to the port.																														
Voltage	Line voltage on the channel, calculated by volt (V).																														
State	Displays the channel state in real time. You can move the mouse onto the channel state icon for detailed state information.																														
	<table><tr><th>State</th><th>Icon</th><th>Description</th></tr><tr><td>Idle</td><td></td><td>The channel is available.</td></tr><tr><td>Off-hook</td><td></td><td>The channel picks up the call.</td></tr><tr><td>Wait Answer</td><td></td><td>The channel receives the ringback tone and is waiting for the called party to pick up the phone.</td></tr><tr><td>Ringing</td><td></td><td>The channel is in the ringing state.</td></tr><tr><td>Talking</td><td></td><td>The channel is in a conversation.</td></tr><tr><td>Dialing</td><td></td><td>The channel is dialing.</td></tr><tr><td>Pending</td><td></td><td>The channel is in the pending state.</td></tr><tr><td>Internal State</td><td></td><td>Internal state of the channel.</td></tr><tr><td>Unusable</td><td></td><td>The channel is unavailable.</td></tr></table>	State	Icon	Description	Idle		The channel is available.	Off-hook		The channel picks up the call.	Wait Answer		The channel receives the ringback tone and is waiting for the called party to pick up the phone.	Ringing		The channel is in the ringing state.	Talking		The channel is in a conversation.	Dialing		The channel is dialing.	Pending		The channel is in the pending state.	Internal State		Internal state of the channel.	Unusable		The channel is unavailable.
	State	Icon	Description																												
	Idle		The channel is available.																												
	Off-hook		The channel picks up the call.																												
	Wait Answer		The channel receives the ringback tone and is waiting for the called party to pick up the phone.																												
	Ringing		The channel is in the ringing state.																												
	Talking		The channel is in a conversation.																												
	Dialing		The channel is dialing.																												
	Pending		The channel is in the pending state.																												
Internal State		Internal state of the channel.																													
Unusable		The channel is unavailable.																													
Direction	Displays the direction of the call on channel.																														
CallerID	Displays the CallerID of the call on channel.																														
CalleeID	Displays the CalleeID of the call on channel.																														
Reg Status	Displays the registration status of the port.																														
Polarity Reversal Count	The counts of the polarity reversal detected by the FXO port.																														

3.2.3 Call Count

Call Count								
Call Direction	Total Calls	Successful Calls	Busy	No Answer	Call Forward	Routing Failure	Dialing Failure	Unknown Failure
IP→Tel	0	0	0	0	0	0	0	0
Tel→IP	0	0	0	0	0	0	0	0

Refresh

Figure 3-6 Call Count Interface

See Figure 3-6 for the call count Interface. The above list shows the detailed information about all the calls counted from the startup of the gateway service to the latest open or refresh of this interface. You can click **Refresh** to obtain the current call count information. The table below explains the items shown in Figure 3-6.

Item	Description
Call Direction	A condition for call count, two options available: <i>IP→Tel</i> and <i>Tel→IP</i> .
Total Calls	Total number of calls in a specified call direction.
Successful Calls	Total number of successful calls in conversation.
Busy	Total number of calls which fail as the called party has been occupied and replies a busy message.
No Answer	Total number of calls which fail as the called party does not pick up the call in a long time or the calling party hangs up the call before the called party picks it up.

Call Forward	Total number of calls which have been forwarded.
Routing Failure	Total number of calls which fail because no routing rules are matched.
Dialing Failure	Total number of calls which fail as the called party number does not conform to the dialing rule or due to dialing timeout.
Unknown Failure	Total number of calls which fail due to unknown reasons.

3.2.4 SIP Message Count

Request								
Request	REGISTER	INVITE	ACK	INFO	BYE	CANCEL	NOTIFY	OPTION
Send	0	1	1	0	1	0	0	0
Send Repeatedly	0	0	0	0	0	0	0	0
Receive	0	1	1	0	1	0	0	0
Receive Repeatedly	0	0	0	0	0	0	0	0
Common Response								
Common Response	100 Trying	180 Ringing	183 Session Process	200 OK	486 Busy	487 Request Already Terminated		
Send	1	1	0	2	0	0		
Receive	1	1	0	2	0	0		

Figure 3-7 SIP Message Count Interface

See Figure 3-7 for the SIP Message Count interface. This is used to record the amount of the normal SIP messages that are sent/received or repeatedly sent/received during the period from the startup of the gateway service to the latest open or refresh of the interface. Click **Refresh** to refresh the count of SIP messages, or click **Clear** to clear the current count of SIP messages.

3.3 Quick Config





Figure 3-8 Quick Config Interface

See Figure 3-8 for the Quick Config interface. Follow the gateway Quick Configuration wizard and you can easily complete the settings on network, SIP and FXS/FXO. The gateway can work normally after configuration.

See Figure 3-9 for the Quick Config-Network Settings interface. Refer to [3.9.3 Network](#) for detailed settings. After configuration, click **Next** to enter the SIP Settings interface.



The interface is titled "Quick Config-Network Settings". It contains two sections: "LAN 1" and "LAN 2".

LAN 1 Configuration:

- Network Type: Static (dropdown menu)
- IP Address (I): 192.168.1.101
- Subnet Mask (U): 255.255.255.0
- Default Gateway (D): 192.168.1.1
- DNS Server (P): 0.0.0.0
- Speed and Duplex Mode: Automatic Detection (dropdown menu)


LAN 2 Configuration:

- Enable: ☐ (checkbox)

At the bottom, there is a "Next" button.

Figure 3-9 Quick Config-Network Settings Interface

See Figure 3-10 for the Quick Config-SIP Settings interface. The configuration items on this interface are the same as those on the SIP interface. Refer to [3.4.1 SIP](#) for detailed settings. You are required to fill with the information about the registrar if the gateway must be registered. After configuration, click **Back** to go back to the Network Settings interface; click **Next** to enter the FXS Settings interface.



The interface is titled "Quick Config-SIP Settings". It contains the following configuration items:

















- SIP Address: LAN 1: 192.168.1.101 (dropdown menu)
- Registrar IP Address: (text input field)
- Registrar Port: (text input field)
- Spare Registrar IP Address: (text input field)
- Spare Registrar Port: (text input field)
- Registry Validity Period (s): 600 (text input field)

At the bottom, there are "Back" and "Next" buttons.

Figure 3-10 Quick Config-SIP Settings Interface

See Figure 3-11 for the FXS Settings interface. The configuration items on this interface are the same as those on the FXS interface. Refer to [3.6.1 FXS](#) for detailed settings. After configuration, click **Back** to go back to the SIP Settings interface; click **Next** to enter the FXO Settings interface.

FXS Settings

Port	Type	SIP Account	Display Name	Auto Dial Num	Forbid Outgoing Call	DND	Forward	FWD Type	FWD Number	CID	Call Waiting	Reg Status	Echo Canceller	Color Ring	Color Ring Index	Input Gain	Output Gain	Modify
1	FXS	8001	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	
2	FXS	8002	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	
3	FXS	8003	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	
4	FXS	8004	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	
5	FXS	8005	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	
6	FXS	8006	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	
7	FXS	8007	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	
8	FXS	8008	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	
9	FXS	8009	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	
10	FXS	8010	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	
11	FXS	8011	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	
12	FXS	8012	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	
13	FXS	8013	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	
14	FXS	8014	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	
15	FXS	8015	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	
16	FXS	8016	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	

32 Items Total16 Items/Page1/2FirstPreviousNextLastGo to Page12Pages Total

Batch Modify

















Back

Next

Figure 3-11 FXS Settings Interface

See Figure 3-12 for FXO Settings Interface. The configuration items on this interface are the same as those on the FXO interface. Refer to [3.6.2 FXO](#) for detailed settings. After configuration, click **Back** to back to the FXS Settings interface; click **Next** to enter the Quick Config-Completion interface, see Figure 3-13.

FXO Settings

Port	Type	SIP Account	Display Name	Connection Method	Bound Number	Forbid Outgoing Call	Caller ID Detection	Reg Status	Echo Canceller	Polarity Reversal Detection	Input Gain	Output Gain	Modify
17	FXO	8017	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	
18	FXO	8018	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	
19	FXO	8019	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	
20	FXO	8020	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	
21	FXO	8021	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	
22	FXO	8022	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	
23	FXO	8023	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	
24	FXO	8024	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	
25	FXO	8025	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	
26	FXO	8026	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	
27	FXO	8027	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	
28	FXO	8028	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	
29	FXO	8029	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	
30	FXO	8030	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	
31	FXO	8031	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	
32	FXO	8032	---	Two Stages Dialing for Incoming Call	---	Disable	Disable	Unregistered	Enable	Disable	0	0	

32 Items Total 16 Items/Page 2/2

[First](#) [Previous](#) [Next](#) [Last](#) Go to Page

2

 2 Pages Total

Back

Next

Batch Modify

Figure 3-12 FXO Settings Interface

Quick Config-Completion

The configuration is finished. Please click 'Finish' to quit the Quick Config!

Note: the gateway will restart the system after you click 'Finish'. Please log in the gateway again using your new IP address.

[Back](#) [Finish](#)

Figure 3-13 Quick Config-Completion Interface

Click **Back** to go back to the FXO Settings interface; click **Finish** to finish the Quick Config wizard and now the gateway can work normally with basic configuration.


3.4 VoIP Settings

VoIP Settings includes six parts: **SIP**, **SIP Compatibility**, **SIP Station**, **SIP Server**, **NAT Setting** and **Media**. See Figure 3-14. **SIP** is used to configure the general SIP parameters, **SIP Compatibility** is used to set which SIP servers and SIP messages will the gateway be compatible with, **SIP Station** is to set the basic information of the SIP station, **SIP Server** is to set the basic information of the SIP server, **NAT Setting** is used to configure the parameters for NAT, and **Media Settings** is to set the RTP port and the payload type.



Figure 3-14 VoIP Settings

3.4.1 SIP



The image shows a web-based configuration interface titled "SIP Settings". It contains various input fields and checkboxes for configuring SIP parameters. At the bottom, there are "Save" and "Reset" buttons.

Item	Value
SIP Address	LAN 1: 192.168.1.101
SIP Port	5060
Register Status	Unregistered
Register Gateway	Yes
SIP Account	
Password	
Authentication Username	
Registrar IP Address	
Registrar Port	
Spare Registrar Server	<input checked="" type="checkbox"/> Enable
Spare Registrar IP Address	
Spare Registrar Port	
Registry Validity Period (s)	600
Multi-Registrar Server Mode	<input type="checkbox"/> Enable
SIP Transport Protocol	UDP
Switch Signal Port if SIP Registration Failed	<input type="checkbox"/> Enable
IMS Network	<input checked="" type="checkbox"/> Enable
Externally Bound Address	
Externally Bound Port	5060

Figure 3-15 SIP Settings Interface

See Figure 3-15 for the SIP settings interface where you can configure the general SIP parameters. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.9.16 Restart](#) for detailed instructions. The table below explains the items shown in Figure 3-15.

Item	Description
SIP Address	IP address of SIP signaling, using LAN 1 by default.
SIP Port	Monitoring port of SIP signaling. The value range of it must be greater than 1024 and less than 65535, with the default value of 5060.
Register Status	Registration status of the gateway. When Register Gateway is set to <i>No</i> , the value of this item is <i>Unregistered</i> ; when Register Gateway is set to <i>Yes</i> , the value of this

	item is either <i>Failed</i> or <i>Registered</i> .
Register Gateway	Sets whether to register the gateway as a whole. The default value is <i>No</i> . Only when this configuration is set to <i>Yes</i> can you see the configuration items SIP Account and Password .
SIP Account	When the gateway initiates a call to SIP, this item corresponds to the username of SIP.
Password	Registration password of the gateway. To register the gateway to SIP, both configuration items SIP Account and Password should be filled in.
Authentication Username	Authentication username for registration.
Registrar IP Address	Address of the registry server for the gateway to register.
Registrar Port	Signaling port of the registry server.
Spare Registrar Server	Check the enable checkbox to enable the spare registrar server. By default, it is <i>disabled</i> .
Spare Registrar IP Address	Address of the spare registry server for the gateway to register. The gateway will enable the spare registrar server if the master registrar server has no reply, or the master server is detected with no response in case the item Detection Server Cycle is enabled.
Spare Registrar Port	Signaling port of the spare registry server.
Registry Validity Period	Validity period of the SIP registry. Once the registry is overdue, the gateway should be registered again. This configuration item is valid only when Register Gateway is set to <i>Yes</i> . Range of value: 10~3600, calculated by s, with the default value of 600.
Multi-Registrar Server Mode	Tick the checkbox before to enable the multi-registrar server mode. By default, it is <i>disabled</i> .
SIP Transport Protocol	There are two modes <i>UDP</i> and <i>TCP</i> available for running the SIP protocol. The default value is <i>UDP</i> .
Switch Signal Port if SIP Registration Failed	If the SIP registration fails, the SIP signaling port N will switch to N+1 for a new registration. It will continue until the registration succeeds. The default value is <i>disabled</i> .
IMS Network	Once this feature is enabled, the gateway will send signaling messages to the corresponding externally bound address and port when it registers to the server. By default, this feature is <i>disabled</i> . Only when this feature is <i>enabled</i> will these items Externally Bound Address , Externally Bound Port and Authentication Username be shown.
Externally Bound Address	Externally bound IP address for registration.
Externally Bound Port	Externally bound port for registration.

3.4.2 SIP Compatibility

See Figure 3-16 for the SIP Compatibility interface where you can configure the SIP parameters to determine which SIP servers and SIP messages will the gateway be compatible with. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the

configurations.

SIP Compatibility	
Obtain CalleeID from	"Request" Field
Set CallerID position	Username of From Field
Obtain CallerID from	Username of From Field
Use Contact Address	<input type="checkbox"/> Enable
Call Transfer Mode	Internal Handling
Internal Handle	Match Port Number
Call Flash Mode	Platform to Handle SIP I
Hold Music Source	Remote
Two Stage Dialing for SIP Incoming Call	<input type="checkbox"/> Enable
Maximum Wait Answer Time (s)	60
SIP Station Supported	<input type="checkbox"/> Enable
Set SIP Identifying	Gateway
Maximum Wait RTP Time (s)	15
Call Abnormal Hangup Detection	<input checked="" type="checkbox"/> Enable
Cycle(s)	0
Server Status Detection	<input checked="" type="checkbox"/> Enable
Cycle(s)	0
Send Cue Tone	<input type="checkbox"/> Enable
SIP Encryption	<input checked="" type="checkbox"/> Enable
Encryption Criterion	VOS1.1
Identifier	
Key	
RTP Encryption	<input type="checkbox"/> Enable
Ignore ACK	<input type="checkbox"/> Enable
User-defined SIP Code	<input type="checkbox"/> Enable
Use Iptables	<input type="checkbox"/> Enable

Save
Reset

Figure 3-16 SIP Compatibility Setting Interface

The table below explains the items shown in Figure 3-16.

Item	Description
Obtain CalledID from	There are two optional ways to obtain the called party number: from <i>"To" Field</i> and from <i>"Request" Field</i> . The default value is <i>"Request" Field</i> .
Set CallerID Position	There are two options to set the position of the calling party number: <i>"Displayname of From Field"</i> and <i>"Username of From Field"</i> . The default value is <i>"Username of From Field"</i> .
Obtain CallerID from	There are two optional ways to obtain the calling party number: from <i>"Displayname of From Field"</i> and from <i>"Username of From Field"</i> . The default value is <i>"Username of From Field"</i> .
Use Contact Address	Sets whether to send the request message according to the content of Contact, with the default setting of <i>disabled</i> . As it is disabled, if the Contact field indicates an IP address within the LAN, the request message will be sent according to the source address; if the Contact field indicates an IP address belonging to the WAN, the request message will be sent according to this IP address.
Call Transfer Mode	There are two optional ways to deal with call transfer: <i>Internal Handling</i> and <i>Platform to Handle SIP Info</i> . The default value is <i>Internal Handling</i> .
Internal Handle	Sets the internal handle mode for the call transfer, including two options: <i>Match Port Number</i> and <i>Search Idle FXO Channel</i> . The default value is <i>Match Port Number</i> .
Call Flash Mode	There are two optional ways to deal with call flash: <i>Internal Handling</i> and <i>Platform to Handle SIP Info</i> . The default value is <i>Internal Handling</i> .
Hold Music Source	Sets the source of the hold music, with the default value of <i>Remote</i> . This feature gets valid only when you choose the mode <i>Platform to Handle SIP Info</i> .
Two Stage Dialing for SIP Incoming Call	Once this feature is enabled, the incoming call from SIP should perform the two stage dialing operation. By default this feature is <i>disabled</i> .
Maximum Wait Answer Time	Sets the maximum time for the SIP channel to wait for the answer from the called party of the outgoing call it initiates. If the call is not answered within the specified time period, it will be canceled by the channel automatically. The default value is 60, calculated by s.
SIP Station Supported	Once this feature is enabled, a SIP terminal can be registered to the gateway and becomes a SIP station. By default this feature is disabled.
Set SIP Identifying	Sets the SIP identifying content in the SIP call message. The default setting is <i>Gateway</i> .
Maximum Wait RTP Time	Sets the maximum time for the SIP channel to wait for the RTP packet. If no RTP packet is received within the specified time period, the channel will enter the pending state automatically and release the call. The default value is 15, calculated by s.
Call Abnormal Hangup Detection Cycle	Sets the interval between checks of the remote end's abnormal hangup, with the default value of 0 (feature disabled), calculated by s. It is suggested to set to 10s if this feature is necessary to be used.

Server Status Detection Cycle	The interval of sending a heartbeat packet to detect the master registrar server status, with the default value of 0 (feature disabled), calculated by s. It is suggested to set to 15s if this feature is necessary to be used.
Send Cue Tone	Sets whether to send a cue tone once the server gets disconnected, with the default setting of <i>disabled</i> .
SIP Encryption	Once this feature is enabled, you can encrypt the SIP signal following selecting an encryption criterion and setting a key. By default it is <i>disabled</i> .
Encryption Criterion	The criterion used to encrypt the SIP signal. At present only VOS1.1 is supported.
Identifier	The identifier field of the VOS encryption, which is used to obtain the key of the SIP encryption.
Key	The key to encrypt the SIP signal.
RTP Encryption	Once this feature is enabled, you can encrypt the RTP package. By default it is <i>disabled</i> .
Ignore ACK	Once this feature is enabled, it is not necessary for the gateway to wait for the ACK message after sending the 200OK message to establish a call. By default it is <i>disabled</i> .
User-defined SIP Code	Once this feature is enabled, you can define a SIP code for the corresponding SIP status, with the default value of <i>disabled</i> .
Use Iptables	Once this feature is enabled, only the calls from the SIP registration server, the source IP address of the route IP->TEL and these IP addressed set in Access Control interface are permitted.

3.4.3 SIP Station

A SIP terminal can be registered to the gateway and becomes a SIP station. Enable the feature of '**SIP Station Supported**' on [3.4.2 SIP Compatibility](#) interface, and you will see the item SIP Station on the VoIP Settings menu. Click '**SIP Station**' to go into the SIP Station interface. By default, there is no available SIP station. See Figure 3-17 below.





Figure 3-17 SIP Station Setting Interface

Click **Add New** to add SIP stations manually. See Figure 3-18. You can configure basic SIP station information on this interface. The bound port to a SIP station must be an FXO port and unique. The username must be the same as that used to register the SIP terminal to the gateway.



The dialog box titled "SIP Station" contains the following fields and controls:


- Number:** A text input field containing the value "0".
- Username:** An empty text input field.
- Password:** An empty text input field.
- Bound Port:** A dropdown menu showing "29".
- Description:** A text input field containing the value "default".
- Batch Setting:** A checkbox labeled "Enable" which is currently unchecked.
- Buttons:** "Save" and "Close" buttons at the bottom.

Figure 3-18 Add New SIP Station

The table below explains the items shown above:

Item	Description
Number	The logical number for a SIP station to register to the gateway.
Username	The username used to register a SIP station to the gateway.
Password	The password used to register a SIP station to the gateway.
Bound Port	The FXO port which is bound to the SIP station.
Description	It is user-defined, with the default value of <i>default</i> .
Batch Setting	Used to set multiple SIP stations at the same time.

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings. See Figure 3-19 for the applied SIP station information.





SIP Station									
Check	Number	Username	IP Address	Bound Port	Register Status	Register Duration (s)	Voice Channel State	Description	Modify
<input type="checkbox"/>	0	120	—	29	Unregistered	—	—	default	
<div> <input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Inverse"/> <input type="button" value="Delete"/> <input type="button" value="Clear All"/> <input type="button" value="Add New"/> </div>									
1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total									

Figure 3-19 SIP Station Interface

Click **Modify** in the above figure to modify the configuration of the SIP station. See Figure 3-20.

The configuration items on this interface are the same as those on the **Add New SIP Station** interface.



The image shows a 'SIP Station' configuration window. It contains the following fields and controls:

- Number:** A text input field containing the value '0'.
- Username:** A text input field containing the value '120'.
- Password:** A text input field containing three dots '...', indicating a masked password.
- Bound Port:** A dropdown menu with '29' selected.
- Description:** A text input field containing the value 'default'.
- Batch Setting:** A checkbox labeled 'Enable' which is currently unchecked.
- Buttons:** At the bottom, there are two buttons: 'Save' (highlighted in blue) and 'Close'.

Figure 3-20 SIP Station Modification Interface

To delete a SIP station, check the checkbox before the corresponding index in Figure 3-19 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all SIP stations at a time, click the **Clear All** button in Figure 3-19.

3.4.4 SIP Server

The gateway supports the multi-registrar server feature. Enable the feature of '**Multi-Registrar Server Mode**' on the [SIP](#) interface (see [3.4.1 SIP](#)) and you will see the item SIP Server under the VoIP Settings menu. Click '**SIP Server**' to go into the SIP Server interface. By default, there is no available SIP server. See Figure 3-21 below.




Figure 3-21 SIP Server Interface

Click **Add New** to add SIP servers manually. See Figure 3-22. You can configure basic SIP server information on this interface.

Figure 3-22 Add New SIP Server

All the items except Index and Description are the same as those on [the SIP](#) interface ([3.4.1 SIP](#)).

Item	Description
Index	The index of each SIP server. The gateway supports up to 8 SIP servers.
Description	More information about each SIP server, with the default value of <i>default</i> .

After configuration, click **Save** to save the above settings into the gateway or click **Cancel** to cancel the settings. See Figure 3-23 for the SIP server management interface.

Check	Index	Description	IP Address	Port	IMS Network	Externally Bound Address	Externally Bound Port	Registry Validity Period	Port	Port Group	Modify
<input type="checkbox"/>	1	defalut	201.123.115.233	5060	Enable	201.123.123.145	5060	600	---	---	
<input type="checkbox"/>	2	defalut	201.123.115.233	5060	Disable	---	---	600	---	---	

Figure 3-23 SIP Server Management

Click **Modify** in the above figure to modify the configuration of the SIP server. See Figure 3-24.

The configuration items on this interface are the same as those on the **Add New SIP Server** interface.

Modify SIP Server

Index	<input style="width: 90%;" type="text" value="1"/>
Description	<input style="width: 90%;" type="text" value="defalut"/>
Registrar IP Address	<input style="width: 90%;" type="text" value="201.123.115.233"/>
Registrar Port	<input style="width: 90%;" type="text" value="5060"/>
Registry Validity Period (s)	<input style="width: 90%;" type="text" value="600"/>
IMS Network	<input checked="" type="checkbox"/> Enable
Externally Bound Address	<input style="width: 90%;" type="text" value="201.123.123.145"/>
Externally Bound Port	<input style="width: 90%;" type="text" value="5060"/>

Figure 3-24 SIP Server Modification Interface

To delete a SIP server, check the checkbox before the corresponding index in Figure 3-23 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all SIP servers at a time, click the **Clear All** button in Figure 3-23.

3.4.5 NAT Setting

See Figure 3-25 for the NAT setting interface where you can configure the parameters for NAT. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations.

NAT Settings

Local NAT Traversal

Method 1:

Auto Nat

Enable PMP

Outer Network Address

Offline

Method 2:

STUN Server

☒ Enable

NAT Type

Unknown

STUN Server Address

127.0.0.1

Method 3:

Mapping Contact IP

Mapping SDP IP

Method 4:

Rport

☒ Enable

Auto Detect NAT IP

☐ Enable

Help Remote Device Complete NAT Traversal

RTP Self-adaption

☐ Enable

Note:

The non-professional person please do not modify the configuration on this page.

"Local NAT Traversal": Please select one method according to your current network environment.

"Auto Nat": It is required to enable the feature of upon or pmp for the router.

"Mapping Contact IP": It is required to set the router to map the SIP port to the gateway.

"Mapping SDP IP": It is required to set the router to map the RTP port range to the gateway.

"Auto Detect NAT IP": It is valid only when the feature "Rport" is enabled and the router is set to map the RTP port range to the gateway.

Save

Reset

Figure 3-25 NAT Setting Interface

The table below explains the items shown in Figure 3-25.

Item	Description
Auto Nat	Sets whether to enable the Auto Nat feature. Three options are available: DisableAutoNat, Enable PMP and Enable UPNP, with the default value of <i>Auto Nat</i> .
Outer Network	The address of the outer network acquired automatically once the PMP or UPNP

Address	feature is enabled.
STUN Server	Sets whether to enable the STUN server for NAT traversal. By default the STUN server is disabled.
NAT Type	Detected NAT (Network Address Translation) type. The gateway will return the NAT type automatically in case STUN Server is enabled. It includes 9 types: unknown; no NAT; ConeNat; RestrictedNat; PortRestrictedNat; Symmetric NAT; Symmetric NAT with firewall; can't detect over (fail to send detect message) and fail to detect (No reply from the stun server).
STUN Server Address	Address of the server for STUN traversal.
Mapping Contact IP	The IP filled in here will be used in the Contact field of the SIP message.
Mapping SDP IP	The IP filled in here will be used in the SDP field of the SIP message.
Rport	When this feature is enabled, a corresponding Rport field will be added to the Via message of SIP. The default value is <i>enabled</i> .
Auto Detect NAT IP	When this feature is enabled, the gateway will parse the corresponding address and port in the message returned by Rport so as to use them for the following communication. By default, this feature is <i>disabled</i> . Note: This feature gets valid only when Rport is enabled.
RTP Self-adaption	When this feature is enabled, the RTP reception address or port carried by the signaling message from the remote end, if not consistent with the actual state, will be updated to the actual RTP reception address or port. By default, this feature is <i>disabled</i> .

3.4.6 Media

Media Parameters

DTMF Transmit Mode

RFC2833 ▾

RFC2833 Payload

101

RTP Port Range

6000,10000

Silence Suppression

Disable ▾

Auto Noise Reduction

Disable ▾

JitterMode

Static Mode ▾

JitterBuffer(ms)

100

JitterUnderrunLead(ms)

200

JitterOverrunLead(ms)

200

Voice Gain Output from IP (dB)

0

CODEC Priority

Check	Priority	CODEC	Packing Time	Bit Rate (kbs)
<input checked="" type="checkbox"/>	1	G711A ▾	20 ▾	64 ▾
<input checked="" type="checkbox"/>	2	G711U ▾	20 ▾	64 ▾
<input checked="" type="checkbox"/>	3	G729 ▾	20 ▾	8 ▾
<input checked="" type="checkbox"/>	4	G723 ▾	30 ▾	6.3 ▾
<input checked="" type="checkbox"/>	5	G722 ▾	30 ▾	64 ▾
<input checked="" type="checkbox"/>	6	AMR ▾	20 ▾	6.70 ▾
<input checked="" type="checkbox"/>	7	iLBC ▾	20 ▾	15.2 ▾
<input checked="" type="checkbox"/>	8	SILK(16K) ▾	20 ▾	20 ▾
<input checked="" type="checkbox"/>	9	OPUS(16K) ▾	20 ▾	20 ▾
<input checked="" type="checkbox"/>	10	SILK(8K) ▾	20 ▾	12 ▾
<input checked="" type="checkbox"/>	11	OPUS(8K) ▾	20 ▾	12 ▾

Save

Reset

Figure 3-26 Media Settings Interface

See Figure 3-26 for the media settings interface where you can configure the RTP port and payload type depending on your requirements. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.9.16 Restart](#) for detailed instructions. The table below explains the items shown in Figure 3-26.

Item	Description
------	-------------

DTMF Transmit Mode	Sets the transmit mode for the IP channel to send DTMF signals. The optional values are <i>RFC2833</i> , <i>In-band</i> and <i>Signaling</i> , with the default value of <i>RFC2833</i> .
RFC2833 Payload	Payload of the RFC2833 formatted DTMF signals on the IP channel. Range of value: 90~127, with the default value of 101.
RTP Port Range	Supported RTP port range for the IP end to establish a call conversation, with the lower limit of 2000 and the upper limit of 60000 and the difference between larger than 480. The default value is 6000-10000.
Silence Suppression	Sets whether to send comfort noise packets to replace RTP packets or never to send RTP packets to reduce the bandwidth usage when there is no voice signal throughout an IP conversation. The optional values are <i>Enable</i> and <i>Disable</i> , with the default value of <i>Disable</i> .
Auto Noise Reduction	Once this feature is enabled, the volume of the noise accompanied with the line will be reduced automatically. By default, the feature is <i>disabled</i> .
JitterMode	Sets the working mode of JitterMode. The optional values are <i>Static Mode</i> and <i>Adaptive Mode</i> , with the default value of <i>Static Mode</i> .
JitterBuffer	Acceptable jitter for data packets transmission over IP, which indicates the buffering capacity. A larger JitterBuffer means a higher jitter processing capability but as well as an increased voice delay, while a smaller JitterBuffer means a lower jitter processing capability but as well as a decreased voice delay. Range of value: 0~280, calculated by ms, with the default value of 100.
JitterUnderrunLead	Sets the initial delay of packets if they are received later than JitterBuffer. Range of value: 0~280, calculated by ms, with the default value of 200, Note: Only when JitterMode is set to <i>Static Mode</i> will this item be shown.
JitterOverrunLead	Sets the initial lead inserted if packets are received earlier than 300-JitterBuffer. Range of value: 0~280, calculated by ms, with the default value of 200, Note: Only when JitterMode is set to <i>Static Mode</i> will this item be shown.
JitterMin	Sets the minimum delay that can be set by the adaptive jitter function. It cannot be larger than the value set in JitterBuffer. Range of value: 0~280, calculated by ms, with the default value of 10. Note: Only when JitterMode is set to <i>Adaptive Mode</i> will this item be shown.
JitterDecreaseRatio	Sets the rate for delay reduction under the adaptive mode. It defines the maximum percentage of silence that can be removed for delay reduction. Range of value: 0~100, with the default value of 50, Note: Only when JitterMode is set to <i>Adaptive Mode</i> will this item be shown.
JitterIncreaseMax	Sets the maximum delay that can be increased during a silence period. Range of value: 0~280, calculated by ms, with the default value of 50, Note: Only when JitterMode is set to <i>Adaptive Mode</i> will this item be shown.
Voice Gain Output from IP	Adjusts the gain of the voice output from IP. Range of value: -24~24, calculated by dB, with the default value of 0.

CODEC Priority	Supported CODECs and their corresponding priority for the IP end to establish a call conversation. The table below explains the sub-items:	
	Sub-item	Description
	<i>Priority</i>	Priority for choosing the CODEC in an SIP conversation. The smaller the value is, the higher the priority will be.
	<i>CODEC</i>	Three optional CODECs are supported: <i>G711A</i> , <i>G711U</i> , <i>G729A/B</i> , <i>G723</i> , <i>G722</i> , <i>AMR</i> , <i>iLBC</i> , <i>SILK(16K)</i> , <i>OPUS(16K)</i> , <i>SILK(8K)</i> and <i>OPUS(8K)</i> .
	<i>Packing Time</i>	Time interval for packing an RTP packet, calculated by ms.
	<i>Bit Rate</i>	The number of thousand bits (excluding the packet header) that are conveyed per second.
	By default, all of the eleven CODECs are supported and ordered <i>G711A</i> , <i>G711U</i> , <i>G729A/B</i> , <i>G723</i> , <i>G722</i> , <i>AMR</i> , <i>iLBC</i> , <i>SILK(16K)</i> , <i>OPUS(16K)</i> , <i>SILK(8K)</i> and <i>OPUS(8K)</i> by priority from high to low.	
	The packing time and bit rate supported by different CODECs are listed in the table below. Those values in bold face are the default values.	
	CODEC	Packing Time (ms) Bit Rate (kbps)
	<i>G711A</i>	5 / 10 / 20 / 30 / 40 / 50 / 60 64
	<i>G711U</i>	5 / 10 / 20 / 30 / 40 / 50 / 60 64
	<i>G729A/B</i>	10 / 20 / 30 / 40 / 50 / 60 8
	<i>G723</i>	30 / 60 / 90 5.3 / 6.3
	<i>G722</i>	5 / 10 / 20 / 30 / 40 64
	<i>AMR</i>	20 / 40 / 60 / 80 / 100 4.75 / 5.15 / 5.90 / 6.70 / 7.40 / 7.95 / 10.20 / 12.20
	<i>iLBC</i>	20 / 40 15.2
		30 13.3
		60 13.3 / 15.2
	<i>SILK(16K)</i>	20 / 40 / 60 20
	<i>OPUS(16K)</i>	10 / 20 / 40 / 60 20
	<i>SILK(8K)</i>	20 / 40 / 60 12
	<i>OPUS(8K)</i>	10 / 20 / 40 / 60 12

3.5 Advanced Settings

Advanced Settings includes fourteen parts: **FXS**, **FXO**, **Tone Detector**, **Tone Generator**, **DTMF**, **Ringing Scheme**, **Fax**, **Function Key**, **Dialing Rule**, **Dialing Timeout**, **Cue Tone**, **Color Ring**, **QoS** and **Action URL**. See Figure 3-27. **FXS** is used to configure the general properties of the FXS port, **FXO** is used to configure the general properties of the analog voice ports, such as the conditions for sending the caller party information. **Tone Detector** is used to configure some properties of detected tones. **Tone Generator** is used to configure some properties of generated tones. **DTMF** is used to set the properties related to DTMF. **Ringing Scheme** is used to set the ringing scheme for the FXS port. **Fax** is used to configure multiple fax parameters. **Function Key** is used to set a cluster of combination keys for you to query a related number. **Dialing Rule** and **Dialing Timeout** are used to set the judging conditions for dialing. **Cue Tone** is used to set the gateway language for playing voice and the voice file used for the two-stage dialing. **Color Ring** is used to upload the color ring file which can be set as a ringback tone for an incoming call from IP

to FXS port. **QoS** uses the differentiated services technology to increase the gateway's service quality. **Action URL** is used to designate the server path to report the on-hook or off-hook state of the FXS channel.



Figure 3-27 Advanced Settings

3.5.1 FXS




Figure 3-28 FXS Configuration Interface

See Figure 3-28 for the FXS/FXO configuration interface. The table below explains the items shown in the above figure.

Item	Description
Tone Energy	Energy of the tone signal sent by the gateway. Range of value: -35~15, calculated by dB, with the default value of -16.
Hook-flash Detection	Sets whether to enable the hook-flash detection feature or not, with the default setting of being disabled.
Minimum Time	Time length for judging a flash operation. Only a hook-flash operation which lasts a time more than the value of this configuration item will be regarded as a valid flash operation. Range of value: 80~ Maximum Time , calculated by ms, with the default value of 80. Note: This item appears only when Hook-flash Detection is enabled.
Maximum Time	Time length for judging a flash operation. Only a hook-flash operation which lasts a time less than the value of this configuration item will be regarded as a valid flash operation. Those lasting a time longer than the value of this configuration item will be regarded as hangup operations. Range of value: 32~2000, calculated by ms, with the default value of 700. Note: This item appears only when the hook-flash detection is enabled.
Minimum Time Length of On-hook Detection	The minimum time length for detecting whether the phone is on-hook or not. Range of value: 64~2000, calculated by ms, with the default value of 64. Note: This item is valid only when Hook-flash Detection is disabled.
CID Transmit Mode	The mode adopted by the FXS port to send the CallerID. The optional values are <i>FSK</i> and <i>DTMF</i> , with the default value of <i>FSK</i> .
Occasion to Send FSK CallerID	Sets when to send the CallerID, before rings or after the 1 st Ring. The default value is after 1 st Ring.
Send Polarity Reversal Signal	Once this feature is enabled, the gateway will send the polarity reversal signal to a corresponding FXS channel when it detects the called party pick-up behavior. By default, this feature is disabled.
Off-hook Dither Signal Duration	The minimum duration of the off-hook signal, calculated by millisecond (ms), which must be the multiple of 16. The less value indicates the larger sensitivity. And the default value is 64.
Hybrid Balance	Sets whether to enable the hybrid balance feature or not. The default setting is being enabled.
Handling of Call from Internal Station	Sets the handling mode for the calls from station to station, two options available: Internal Handling and Platform Handling, with the default value of Platform Handling.
Light Up Mode for Voice Message	Sets the light up mode for leaving a voice message on the phone, two options available: Not Light Up and Light Up by FSK, with the default value of Not Light Up.
Open Session In Advance	Sets whether to reply 183 for an incoming FXS call.

After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.9.16 Restart](#) for detailed instructions.

3.5.2 FXO

The screenshot displays the 'FXO' configuration window. It contains the following settings:

- Calling Party Detection Time (s): 10
- Silence Detection(FXO will Hang up the Call upon Detecting the Silence.): ☐ Enable
- Incoming Call from PSTN:
 - Rapid Release: ☐ Enable
 - FSK Standard: GR-30(North America, China) [dropdown]
 - Reception Interval of DTMF CallerID (ms): 250
 - Delay for Two Stages Dialing (s): 0
- Outgoing Call to PSTN:
 - Flash Time (ms): 100
 - Delay after Dial (ms): 1000
 - FXO Pick-up Delay after INVITE Received at IP Side(s): 0
 - Maximum Wait Answer Time (s)(Valid when Polarity Reversal Enabled): 60
 - Communicate without Network: ☒ Enable
 - Communicate without Network Mode: Auto search idle c [dropdown]
 - Two Stage Dialing Mode: ☐ Enable
 - Delay to Send 200 OK to IP Side (Invalid if Polarity Reversal is enabled): ☐ Enable
 - Avoid Being Detected as Flash Signal by PBX: ☐ Enable
 - Open Session In Advance: ☒ Enable

At the bottom, there are 'Save' and 'Reset' buttons.

Figure 3-29 FXO Configuration Interface

The table below explains the particular configuration items for FXO.

Item	Description
Calling Party Detection Time	The maximum waiting time for the detection of the calling party number from FXO port. Range of value: 1~20, calculated by s, with the default value of 10.
Silence Detection	Used to detect whether the line is silent or not according to the energy threshold and time threshold of silence. FXO will hang up the call automatically if these conditions are satisfied. The default setting is being disabled.
Energy Threshold of Silence	The energy threshold to judge whether the line is silent or not. The signal with the energy less than this set value will be determined to be silence. Range of value: -86~-5, calculated by s, with the default value of -34. Note: This item will be valid only when Silence Detection is enabled.
Time Threshold of Silence	The time threshold to judge whether the line is silent or not, calculated by s, with the default value of 60. Note: This item will be valid only when Silence Detection is enabled.
Rapid Release	Once this feature is enabled, the FXO port will release the source rapidly and go to the idle state when a call from PSTN to soft-terminal via FXO port is rejected by the IP soft-terminal.

FSK Standard	Standard for sending FSK formatted CallerID, which varies in different countries and districts. The optional values are: <i>ETSI (Europe)</i> , <i>GR-30 (North America, China)</i> and <i>NIT (Japan)</i> , with the default value of <i>GR-30</i> .
Reception Interval of DTMF CallerID	The time interval between digits of the DTMF CallerID from FXO port, calculated by ms, with the default value of 250.
Delay for Two Stages Dialing	If the feature of two-stages dialing mode is enabled and an incoming call occurs, the FXO port will have a delay set by this configuration item before going into the two-stages dialing process,
Flash Time	Sets the time for generating a flash signal on the analog trunk. Range of value: 32~1000, calculated by ms, with the default value of 100.
Delay after Dial	Sets the delay to send the CallerID to PBX after you pick up and dial. Range of value: 200~2000, calculated by ms, with the default value of 1000.
FXO Pick-up Delay after INVITE Received at IP Side	Once this feature is enabled, the FXO port will be delayed to pick up the call after the IP side receives the INVITE message.
Maximum Wait Answer Time	The maximum time to wait the answer of the remote side for an outgoing call from FXO port. This item is valid only when Polarity Reversal is enabled. It is calculated by s, with the default value of 60.
Communication without Network	Automatically routes a call to the proper port according to the configuration in case of network failure or call timeout.
Communicate without Network Mode	Sets the mode for the communications without network, two options available: <i>Auto Search Idle Channel</i> and <i>Use Current Route Setting</i> , with the default value of <i>Auto Search Idle Channel</i> . In the mode of <i>Auto Search Idle Channel</i> , the gateway will search an idle FXO port to route the call once the network is disconnected; in the mode of <i>Use Current Route Setting</i> , the gateway will search an escaping channel according to the settings of Tel->IP route.
Two Stages Dialing Mode	Sets whether it is necessary to perform the two-stages dialing operation to call the remote end via an FXO port. By default this feature is disabled.
Delay to Send 200 OK to IP Side	Once this feature is enabled, the gateway will delay to send the 200 OK message to the IP side. The default value is <i>disabled</i> .
Avoid Being Detected as Flash Signal by PBX	Once this feature is enabled, after hanging up a call, the FXO channel will be compelled to stay idle for a while before making a new call outside, which helps avoid the pick-up signal being detected as a flash signal by the PBX. The default value is <i>disabled</i> .
Open Session In Advance	Once this feature is enabled, the gateway will reply the 183 message when the FXO port is making an outgoing call; otherwise, it will reply the 180 message. This item is valid only when Polarity Reversal is enabled. The default value is <i>enabled</i> .

After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.9.16 Restart](#) for detailed instructions.

3.5.3 Tone Detector

Tone Detector									
Check	Index	Tone	Type	The 1st Mid-frequency	The 2nd Mid-frequency	Duration at ON State	Duration at OFF State	Period Count	Accepted Frequency Error
<input type="checkbox"/>	0	Dial Tone	Continuous Tone	450	0	1500	0	0	5
<input type="checkbox"/>	1	Busy Tone	Periodic Tone	450	0	350	350	2	5
<input type="checkbox"/>	2	Ringback Tone	Periodic Tone	450	0	1000	4000	1	5

3 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-30 Tone Parameters Setting Interface

See Figure 3-30 for the Tone Parameters setting interface. By default, there are three pieces of tone parameters on the gateway. Click **Add New** to add tone parameters manually, see Figure 3-31.

Tone Parameters

Index:

3

Tone:

Dial Tone

Type:

Continuous Tone

The 1st Mid-frequency:

450

The 2nd Mid-frequency:

0

Duration at ON State:

1500

Duration at OFF State:

0

Period Count:

0

Accepted Frequency Error(%):

5

Duration Error at ON/OFF State(%):

20

Save

Close

Figure 3-31 Add New Tone Parameter Interface

The table below explains the items shown in the above figure.

Item	Description
Index	The unique index of each group of tone detectors.
Tone	There are three options: Dial Tone , Busy Tone and Ringback Tone .
Type	There are two options: Continuous Tone and Periodic Tone .

The 1st Mid-frequency	The 1 st center frequency. Range of value: 300~3400, calculated by Hz. The default value is 450.
The 2nd Mid-frequency	The 2 nd center frequency. Range of value: 0 or 300~3400, calculated by Hz. The default value is 0.
Duration at ON State	The duration of tones at on state. The default setting: Dial Tone is 1500ms, Busy Tone is 350ms, Ringback Tone is 1000ms.
Duration at OFF State	The duration of tones at off state. The default setting: Dial Tone is 0ms, Busy Tone is 350ms, Ringback Tone is 4000ms.
Period Count	Set the count of periods as the condition to determine a periodic tone. The default setting: Dial Tone is 0, Busy Tone is 2, Ringback Tone is 1.
Accepted Frequency Error	Allowable error of the center frequency. Range of value: 1~5, calculated by %, with the default value of 5.
Duration Error at ON/OFF State	The accepted maximum error at on/off state. Range of value: 0~100, calculated by %, with the default value of 20.

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.9.16 Restart](#) for detailed instructions.

Click **Modify** in Figure 3-30 to modify the tone parameter. See Figure 3-32 for the tone parameter modification interface. The configuration items on this interface are the same as those on the **Add New Tone Parameter** interface.

Tone Parameters

Index:

0 ▼

Tone:

Dial Tone ▼

Type :

Continuous Tone ▼

The 1st Mid-frequency:

450

The 2nd Mid-frequency:

0

Duration at ON State:

1500

Duration at OFF State:

0

Period Count :

0

Accepted Frequency Error(%):

5

Duration Error at ON/OFF State(%):

20

Save

Close

Figure 3-32 Modify Tone Parameter

To delete a piece of tone, check the checkbox before the corresponding index in Figure 3-30 and click the '**Delete**' button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all tone at a time, click the **Clear All** button in Figure 3-30.

3.5.4 Tone Generator

Tone Generator	
Dial Tone	<input type="text" value="450/0"/> <p>350+440/0 Continuously play a dual tone which is composed of 350HZ and 440HZ. Note: The value range of the frequency is 200~3500HZ.</p>
Ringback Tone	<input type="text" value="450/1000,0/4000"/> <p>480+620/500,0/500 Repeatedly play a dual tone which is composed of 480HZ and 620HZ in the method of 500ms play with 500ms pause. Note: 0/500 denotes 500ms silence and the tone cannot start with the silence.</p>
Busy Tone	<input type="text" value="450/350,0/350"/> <p>950/333,1400/333,1800/333,0/1000 Repeatedly play tones in turn: first a 333ms 950HZ tone, followed by a 333ms 1400HZ tone, then a 333ms 1800HZ tone and at last a 1s silence. Note: The count of signals at ON state in a period cannot be greater than 4.</p>
<div> <input type="button" value="Save"/> <input type="button" value="Reset"/> </div>	

Figure 3-33 Tone Generator Setting Interface

See Figure 3-33 for the Tone Generator Setting interface. By default, there are three tones on it: Dial Tone—a continuous single tone with 450HZ frequency; Ringback Tone—a single tone with 450HZ frequency, repeatedly playing in the method of 1s play and 4s pause; Busy Tone—a single tone with 450HZ frequency, repeatedly playing in the method of 350ms play and 350ms pause. You can configure the tone generator manually. The exact explanation about the format and the meaning is described on the right of the interface.

3.5.5 DTMF

DTMF Detector

Energy Difference of High-freq minus Low-freq (dB)	<input style="width: 90%;" type="text" value="5"/>
Energy Difference of Low-freq minus High-freq (dB)	<input style="width: 90%;" type="text" value="9"/>
Minimum Duration at ON (ms)	<input style="width: 90%;" type="text" value="50"/>
Maximum Interruption at ON (ms)	<input style="width: 90%;" type="text" value="5"/>
Center Frequency Error (%)	<input style="width: 90%;" type="text" value="1"/>
Lowest Energy Threshold (dB)	<input style="width: 90%;" type="text" value="-30"/>
Minimum Signal-to-noise Ratio Threshold (dB)	<input style="width: 90%;" type="text" value="-3"/>
DTMF Display via Channel Status	<input type="checkbox"/> Enable
ABCD Detection	<input type="checkbox"/> Enable

DTMF Generator

DTMF Energy (dB)	<input style="width: 90%;" type="text" value="-11"/>
Duration at ON (ms)	<input style="width: 90%;" type="text" value="100"/>
Duration at OFF (ms)	<input style="width: 90%;" type="text" value="32"/>

Figure 3-34 DTMF Detector Configuration Interface

See Figure 3-34 for the DTMF detector configuration. The table below explains the items shown in the above figure.

Item	Description
Energy Difference of High-freq minus Low-freq	The allowed difference in dB for the DTMF high frequency energy level to surpass the low frequency energy level. Range of value: 0~24. The default value is 5.
Energy Difference of Low-freq minus High-freq	The allowed difference in dB for the DTMF low frequency energy level to surpass the high frequency energy level. Range of value: 0~24. The default value is 9.
Minimum Duration at ON	The shortest time that a valid tone has to last at ON state. Range of value: 10~2000, calculated by ms. The default value is 50.
Maximum Interruption at ON	The longest time for a valid tone to stay interrupted at ON state. Range of value: 0~20, calculated by ms. The default value is 5.

Center Frequency Error	The error threshold of the center frequency at ON state in the DTMF tone, with the default value of 1.
Lowest Energy Threshold	The energy threshold to trigger the DTMF detection. Range of value: -40~-9, calculated by dB. The default value is -30.
Minimum Signal-to-noise Ratio Threshold	The signal-to-noise ratio threshold to trigger the DTMF detection. Range of value: -9~0, calculated by dB. The default value is -3.
DTMF Display via Channel Status	Once this feature is enabled, the received/transmitted DTMF will be displayed as you put the mouse on the icon of channel status.
ABCD Detection	Once this feature is enabled, the gateway can detect the DTMF digits A, B, C and D (Case-insensitive). The default value is disabled.
DTMF Energy	Energy of the DTMF signal sent by the gateway. Range of value: -35~15, calculated by dB, with the default value of -11.
Duration at ON	The duration of DTMF signal at on state. Range of value: 0~16383, calculated by ms, with the default value of 100.
Duration at OFF	The duration of DTMF signal at off state. Range of value: 0~16383, calculated by ms, with the default value of 32.

After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.9.16 Restart](#) for detailed instructions.

3.5.6 Ringing Scheme

Ringing Scheme

Matching Scheme

Scheme 1

CallerID

Ringing Mode

Scheme 2

CallerID

Ringing Mode

Scheme 3

CallerID

Ringing Mode

Scheme 4

CallerID

Ringing Mode

CallerID Matching
▼

Save

Reset

SMG Series Analog Gateway User Manual (Version 1.7.6)

Page 45

Figure 3-35 Ringing Scheme Configuration Interface

See Figure 3-35 for the Ringing Scheme interface. The gateway will execute different ringing schemes according to the CallerID or Alert-Info.

The table below explains the items shown in the above figure.

Item	Description
CallerID	The gateway will match the CallerID set in this item to that of the incoming call. If they are matched, the current ringing scheme will be executed; otherwise, the default ringing scheme (1 sec on and 4 sec off) will work. The rule to fill in the CallerID is the same as that of 3.5.9 Dialing Rule . Multiple CallerIDs are supported; they should be separated by “,”
Alert-Info Value	The gateway will match the Alert-info value set in this item to that of the incoming call. If they are matched, the current ringing scheme will be executed; otherwise, the default ringing scheme (1 sec on and 4 sec off) will work..
Ringing Scheme	The ringing scheme can be “1,X,Y” or “2,X,Y,M,N”, in which, the number 1 or 2 denotes one group or two groups; X, M denote the duration at on state while Y, N denote the duration at off state. Note: The duration at ON or OFF cannot be greater than 12000ms, the total duration at ON and OFF cannot be greater than 16000ms, and N - the last duration at OFF cannot be less than 1800ms if the item “Occasion to Send FSK CallerID” is set to After the first ring.

After configuration, click **Save** to save the above settings into the gateway or click **Reset** to restore the configurations.

3.5.7 Fax

The image shows a web-based configuration interface for fax parameters. At the top, there is a blue header bar labeled 'Fax Parameters'. Below this, there is a light gray box containing the 'Fax Mode' label and a dropdown menu currently showing 'Disable'. At the bottom of the interface, there are two blue buttons labeled 'Save' and 'Reset'.

Figure 3-36 Fax Configuration Interface (Disable by default)

See Figure 3-36 for the default fax mode configuration. The table below explains the items shown in the above figure.

Item	Description
Fax Mode	The real-time IP fax mode. The optional values are <i>T.38</i> , <i>Pass-through</i> and <i>Disable</i> , and the default value is <i>Disable</i> which means to disable both T.38 and Pass-through.

See Figure 3-37 for the fax configuration under the T.38 mode.

Fax Parameters

Fax Mode	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">T.38 ▼</div>
T38 Fax Port	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">Use Original Voice Port ▼</div>
T38 Version	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">0 ▼</div>
T38 Negotiation	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">Initiate Negotiation as Fax Receiver ▼</div>
Maximum Fax Rate (bps)	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">14400 ▼</div>
Fax Train Mode	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">transferredTCF ▼</div>
Error Correction Mode	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">t38UDPRedundancy ▼</div>
T.30 ECM	<input checked="" type="checkbox"/> Enable
Min Duration of CNG(ms)	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">425</div>
Min Duration of CED(ms)	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">2600</div>

Save

Reset

Figure 3-37 Fax Configuration Interface (T.38 Mode)

Users can configure the general fax parameters via this interface. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.9.16 Restart](#) for detailed instructions. The table below explains the configuration items in Figure 3-37.

Item	Description
T38 Fax Port	The port for T.38 faxing, providing two options: Use Original Voice Port and Use New Port . The default setting is <i>Use Original Voice Port</i> .
T38 Version	Version of T.38 which is defined by ITU-T. Range of value: 0~3, with the default value of 0.
T38 Negotiation	The Negotiation mode of T.38, providing two options: <i>Initiate Negotiation as Fax Sender</i> and <i>Initiate Negotiation as Fax Receiver</i> . The default value is <i>Initiate Negotiation as Fax Receiver</i> .
Maximum Fax Rate	Sets the maximum faxing rate for both receiving and transmitting. Range of value: 14400, 9600 and 4800, calculated by bps, with the default value of 14400.
Fax Train Mode	Sets the train mode for T.38 fax. The optional values are <i>transferredTCF</i> and <i>localTCF</i> , with the default value of <i>transferredTCF</i> .
Error Correction Mode	Sets the error correction mode for T.38 fax. The optional values are <i>t38UDPRedundancy</i> (Redundancy Error Correction) and <i>t38UDPFEC</i> (Forward Error Correction), with the default value of <i>t38UDPRedundancy</i> .
T.30 ECM	Sets whether to enable the T.30 error correction mode. By default this feature is enabled.

Min Duration of CNG	As stipulated in the standard FAX CNG, the minimum duration of CNG is 500ms \pm 15%, calculated by ms, with the default value of 425. Note: Usually there is no need to modify it; please contact our technicians if necessary.
Min Duration of CED	As stipulated in the standard FAX CED, the minimum duration of CED is 2600~4000ms, calculated by ms, with the default value of 2600. Note: Usually there is no need to modify it; please contact our technicians if necessary.

If you set **Fax Mode** to *Pass-through*, you can see the interface shown as Figure 3-38.

Figure 3-38 Fax Configuration Interface (Pass-through Mode)

The table below explains the configuration item in the above figure.

Item	Description
Pass-through Payload	RTP Payload under the pass-through fax mode. Range of value: 96~127, with the default value of 102.

3.5.8 Function Key

See Figure 3-39 for the function key configuration interface. Here you can set a cluster of combination keys to query a related number.

Function Key			
Function	Enable	Function Key	Mode
Device Function			
Query LAN1	<input checked="" type="checkbox"/>	*11*	Default
Query LAN2	<input checked="" type="checkbox"/>	*12*	Default
Query Phone Number	<input checked="" type="checkbox"/>	*20*	Default
Phone Test	<input checked="" type="checkbox"/>	*30*	Default
Switch Eth Device	<input checked="" type="checkbox"/>	*50*	Default
Password for Switch Eth Device	<input type="password" value="....."/>		
Set LAN1	<input checked="" type="checkbox"/>	*61*	Default
Set LAN2	<input checked="" type="checkbox"/>	*62*	Default
Query WEB Port	<input checked="" type="checkbox"/>	*70*	Default
Reboot	<input checked="" type="checkbox"/>	*#88921532*#	Default
Query Missed Call Number	<input checked="" type="checkbox"/>	*71*	Default
Service Available			
Blind Transfer	<input checked="" type="checkbox"/>	*010*	Default
Call Forward Unconditional Activate	<input checked="" type="checkbox"/>	*030*	Default
Call Forward Unconditional Deactivate	<input checked="" type="checkbox"/>	*031*	Default
Call Forward Busy Activate	<input checked="" type="checkbox"/>	*040*	Default
Call Forward Busy Deactivate	<input checked="" type="checkbox"/>	*041*	Default
Call Forward No Reply Activate	<input checked="" type="checkbox"/>	*050*	Default
Call Forward No Reply Deactivate	<input checked="" type="checkbox"/>	*051*	Default
Do Not Disturb Activate	<input checked="" type="checkbox"/>	*060*	Default
Do Not Disturb Deactivate	<input checked="" type="checkbox"/>	*061*	Default
Register	<input checked="" type="checkbox"/>	*020*	Default
Unregister	<input checked="" type="checkbox"/>	*021*	Default
Query Register Status	<input checked="" type="checkbox"/>	*022*	Default
<p>Note:</p> <p>'Switch Eth Device' means to exchange the IP addresses of these two network ports as well as their status (enabled or disabled). And don't forget to switch the netting twine from one port to the other after this setting.</p>			
<input type="button" value="Save"/>			

Figure 3-39 Function Key Configuration Interface

Click "Enable" to enable the corresponding function key. The gateway will use the default function keys when the mode is set to default; and it will allow you to set new function keys when the mode is set to user-defined. Click **Save** to save your settings into the gateway.

Note: Phone Test is used just to see if the phone can work normally. It requires you to hang up the phone after dialing the corresponding combination keys. Then the gateway will ring the phone. At that time, pick up the phone and you can hear the voice prompt played by the gateway (e.g. 'Test successful'.)

When the **Blind Transfer** feature is enabled, set a corresponding function key in the box behind. After you transfer a call by rapidly clapping on the hook switch, dial the set function key for **Blind Transfer** and then the called party number. After that, hang up the call once hearing the howler tone to let the subsequent call procedure go out of your control.

3.5.9 Dialing Rule

Considering efficiency, it is not acceptable that the gateway reports to the PBX or relevant devices every time it receives a number. Instead, we hope that the gateway can automatically judge the received number to see if it meets the set rule, if it is complete and if it is qualified to make outgoing calls. Therefore, a whole dialing plan, which consists of multiple dialing rules specifying the auto judging conditions, is required. Each dialing rule has a priority, which is used to restrict the sequence and avoid conflict.

Standard Mode

Character Mode

Dialing Rule				
Check	Index	Dialing Rule	Description	Modify
<input type="checkbox"/>	81	400xxxxxxx	default	
<input type="checkbox"/>	82	40[1-9]xxxxx	default	
<input type="checkbox"/>	83	4[1-9]xxxxxxx	default	
<input type="checkbox"/>	84	800xxxxxxx	default	
<input type="checkbox"/>	85	80[1-9]xxxxx	default	
<input type="checkbox"/>	86	8[1-9]xxxxxxx	default	
<input type="checkbox"/>	87	[2-3,5-7]xxxxxxx	default	
<input type="checkbox"/>	88	1[3-5,7-8]xxxxxxxxxxx	default	
<input type="checkbox"/>	89	100xx	default	
<input type="checkbox"/>	90	95xxx	default	
<input type="checkbox"/>	91	123xx	default	
<input type="checkbox"/>	92	111xx	default	
<input type="checkbox"/>	93	11[0,2-9]	default	
<input type="checkbox"/>	94	120	default	
<input type="checkbox"/>	95	0[3-9]xxxxxxxxxxx	default	
<input type="checkbox"/>	96	02xxxxxxxxxxx	default	
<input type="checkbox"/>	97	010xxxxxxxxxxx	default	
<input type="checkbox"/>	98	01[3-5,7-8]xxxxxxxxxxx	default	
<input type="checkbox"/>	99	.	default	

Check All

Uncheck All

Inverse

Delete

Clear All

Add New

19 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-40 Dialing Rule Configuration Interface (Standard)

See Figure 3-40 for the Dialing Rule Configuration interface under the standard mode. The list in the above figure shows the dialing rules with their priorities and description, which can be added by the **Add New** button on the bottom right corner. See Figure 3-41 for the dialing rule adding interface.

Dialing Rule

Index:

98

Description:

Dialing Rule:

Save

Close

Figure 3-41 Add New Dialing Rule


The table below explains the items shown in Figure 3-41.

Item	Description																																																		
Index	The unique index of each dialing rule, which denotes its priority. A dialing rule with a smaller index value has a higher priority and will be checked earlier while matching.																																																		
Description	Remarks for the dialing rule. It can be any information, but cannot be left empty.																																																		
Dialing Rule	<p>Up to 100 dialing rules can be configured in the gateway, and the maximum length of each dialing rule is 127 characters. See below for the meaning of each character in the dialing rule. The gateway will do instant matching for your dialing number based on the dialing rule and regard your dialing as finished upon receiving '#' or dialing timeout.</p> <table><tr><th>Character</th><th>Description</th></tr><tr><td>"0"~"9"</td><td>Digits 0~9.</td></tr><tr><td>"A"~"D"</td><td>Letters A~D.</td></tr><tr><td>"x"</td><td>A random number. A string of 'x's represents several random numbers. For example, 'xxx' denotes 3 random numbers.</td></tr><tr><td>"."</td><td>'.' indicates a random amount (including zero) of characters after it.</td></tr><tr><td>"[]"</td><td>'[]' is used to define the range for a number. Values within it only can be digits '0~9', punctuations '-' and ','. For example, [1-3,6,8] indicates any one of the numbers 1, 2, 3, 6, 8.</td></tr><tr><td>"_"</td><td>'-' is used only in '[]' between two numbers to indicates any number between these two numbers.</td></tr><tr><td>" , "</td><td>',' is used to separate numbers or number ranges, representing alternatives.</td></tr><tr><td>"*"</td><td>Only represents symbol "*".</td></tr><tr><td>"#"</td><td>Only set it at the beginning of the string, representing symbol "#".</td></tr></table> <p>There are 19 dialing rules already configured on the gateway for easy use. See below for detailed information.</p> <table><tr><th>Priority</th><th>Dialing Rule</th><th>Description</th></tr><tr><td>99</td><td>.</td><td>Any number in any length.</td></tr><tr><td>98</td><td>01[3-5,7-8]xxxxxxxx.</td><td>Any 12-digit number starting with 013, 014, 015, 017 or 018</td></tr><tr><td>97</td><td>010xxxxxxxx</td><td>Any 11-digit number starting with 010</td></tr><tr><td>96</td><td>02xxxxxxxx</td><td>Any 11-digit number starting with 02</td></tr><tr><td>95</td><td>0[3-9]xxxxxxxx</td><td>Any 12-digit number starting with 03, 04, 05, 06, 07, 08 or 09</td></tr><tr><td>94</td><td>120</td><td>Number 120.</td></tr><tr><td>93</td><td>11[0,2-9]</td><td>Number 110, 112, 113, 114, 115, 116, 117, 118 or 119</td></tr><tr><td>92</td><td>111xx</td><td>Any 5-digit number starting with 111</td></tr><tr><td>91</td><td>123xx</td><td>Any 5-digit number starting with 123</td></tr></table>	Character	Description	"0"~"9"	Digits 0~9.	"A"~"D"	Letters A~D.	"x"	A random number. A string of 'x's represents several random numbers. For example, 'xxx' denotes 3 random numbers.	"."	'.' indicates a random amount (including zero) of characters after it.	"[]"	'[]' is used to define the range for a number. Values within it only can be digits '0~9', punctuations '-' and ','. For example, [1-3,6,8] indicates any one of the numbers 1, 2, 3, 6, 8.	"_"	'-' is used only in '[]' between two numbers to indicates any number between these two numbers.	" , "	',' is used to separate numbers or number ranges, representing alternatives.	"*"	Only represents symbol "*".	"#"	Only set it at the beginning of the string, representing symbol "#".	Priority	Dialing Rule	Description	99	.	Any number in any length.	98	01[3-5,7-8]xxxxxxxx.	Any 12-digit number starting with 013, 014, 015, 017 or 018	97	010xxxxxxxx	Any 11-digit number starting with 010	96	02xxxxxxxx	Any 11-digit number starting with 02	95	0[3-9]xxxxxxxx	Any 12-digit number starting with 03, 04, 05, 06, 07, 08 or 09	94	120	Number 120.	93	11[0,2-9]	Number 110, 112, 113, 114, 115, 116, 117, 118 or 119	92	111xx	Any 5-digit number starting with 111	91	123xx	Any 5-digit number starting with 123
Character	Description																																																		
"0"~"9"	Digits 0~9.																																																		
"A"~"D"	Letters A~D.																																																		
"x"	A random number. A string of 'x's represents several random numbers. For example, 'xxx' denotes 3 random numbers.																																																		
"."	'.' indicates a random amount (including zero) of characters after it.																																																		
"[]"	'[]' is used to define the range for a number. Values within it only can be digits '0~9', punctuations '-' and ','. For example, [1-3,6,8] indicates any one of the numbers 1, 2, 3, 6, 8.																																																		
"_"	'-' is used only in '[]' between two numbers to indicates any number between these two numbers.																																																		
" , "	',' is used to separate numbers or number ranges, representing alternatives.																																																		
"*"	Only represents symbol "*".																																																		
"#"	Only set it at the beginning of the string, representing symbol "#".																																																		
Priority	Dialing Rule	Description																																																	
99	.	Any number in any length.																																																	
98	01[3-5,7-8]xxxxxxxx.	Any 12-digit number starting with 013, 014, 015, 017 or 018																																																	
97	010xxxxxxxx	Any 11-digit number starting with 010																																																	
96	02xxxxxxxx	Any 11-digit number starting with 02																																																	
95	0[3-9]xxxxxxxx	Any 12-digit number starting with 03, 04, 05, 06, 07, 08 or 09																																																	
94	120	Number 120.																																																	
93	11[0,2-9]	Number 110, 112, 113, 114, 115, 116, 117, 118 or 119																																																	
92	111xx	Any 5-digit number starting with 111																																																	
91	123xx	Any 5-digit number starting with 123																																																	

	90	95xxx	Any 5-digit number starting with 95
	89	100xx	Any 5-digit number starting with 100
	88	1[3-5,7-8]xxxxxxxx	Any 11-digit number starting with 13, 14, 15, 17 or 18
	87	[2-3,5-7]xxxxxxx	Any 8-digit number starting with 2, 3, 5, 6 or 7
	86	8[1-9]xxxxxx	Any 8-digit number starting with 81, 82, 83, 84, 85, 86, 87, 88 or 89
	85	80[1-9]xxxxx	Any 8-digit number starting with 801, 802, 803, 804, 805, 806, 807, 808 or 809
	84	800xxxxxxx	Any 10-digit number starting with 800
	83	4[1-9]xxxxxx	Any 8-digit number starting with 41, 42, 43, 44, 45, 46, 47, 48 or 49.
	82	40[1-9]xxxxx	Any 8-digit number starting with 401, 402, 403, 404, 405, 406, 407, 408 or 409
	81	400xxxxxxx	Any 10-digit number starting with 400

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-40 to modify the dialing rules. See Figure 3-42 for the dialing rule modification interface. The configuration items on this interface are the same as those on the **Add New Dialing Rule** interface.



The image shows a 'Dialing Rule' configuration window. It has a title bar 'Dialing Rule'. Inside, there are three input fields: 'Index:' with a dropdown menu showing '99', 'Description:' with a text box containing 'test', and 'Dialing Rule:' with a text box containing 'xxx'. At the bottom, there are two buttons: 'Save' and 'Close'.

Figure 3-42 Modify Dialing Rule

To delete a dialing rule, check the checkbox before the corresponding index in Figure 3-40 and click the '**Delete**' button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all dialing rules at a time, click the **Clear All** button in Figure 3-40.

See Figure 3-43 for the Dialing Rule Configuration interface under the Character mode. You can edit the dialing rule list to add a new one or modify an old one. The exact meaning of each rule element is described on the page.

Note: The Dialing Rule contains such fields as Dialing Rule and Description.
The priority decreases from top to bottom; adjacent fields are separated by a space; Symbol . denotes any string.
Don't forget to save the configuration after your modification!

400xxxxxx default
40[1-9]xxxx default
4[1-9]xxxx default
800xxxxxx default
80[1-9]xxxx default
8[1-9]xxxx default
[2-3,5-7]xxxxxx default
1[3-5,7-8]xxxxxxxx default
100xx default
95xxx default
123xx default
111xx default
11[0,2-9] default
120 default
0[3-9]xxxxxxxxxx default

20 Items Total

Save

Figure 3-43 Dialing Rule Configuration Interface (Character)

3.5.10 Dialing Timeout


Dialing Timeout Info		
Inter Digit Timeout (s)	Description	Modify
6	example	

Figure 3-44 Dialing Timeout Info Interface

See Figure 3-44 for the dialing timeout info interface. The table below explains the items shown in the above figure.

Item	Description
Inter Digit Timeout	Sets the largest interval between two digits of a dialing number. Range of value: 1~10, calculated by s, with the default value of 6. In case your dialing rules do not include ".", the call will fail if there is no digit dialed or no dialing rule matched during this interval; in case your dialing rules include ".", the gateway will wait until this interval ends and match to the dialing rule "." if there is no digit dialed or no other dialing rule matched during this interval.
Description	More information about the configuration item Inter Digit Timeout , such as the reason for adopting the current value.

Click **Modify** in Figure 3-44 to modify the dialing timeout info. See Figure 3-45 for the dialing timeout info modification interface. The configuration items on this interface are the same as those on the **Dialing Timeout Info Interface**.




The image shows a 'Dialing Timeout' configuration window. It has a title bar 'Dialing Timeout'. Inside, there are two input fields: 'Description:' with the value 'example' and 'Inter Digit Timeout (s):' with the value '6'. At the bottom, there are two buttons: 'Save' and 'Close'.

Figure 3-45 Modify Dialing Timeout Info

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

3.5.11 Cue Tone



The image shows a 'Cue Tone Upload' interface. It has a title bar 'Upload'. Below the title bar, there is a text label 'Upload a file of cue tone'. To the right of this label is a dropdown menu showing 'File of cue tone for IVR' and a 'Browse...' button. To the right of the dropdown is an 'Upload' button. Below these elements, there is a note: 'Note: The file should be a wav file with 8000Hz sampling rate, 16-bit mono, A-law formatted, and less than 200KB in size.'

Figure 3-46 Cue Tone Interface

See Figure 3-46 for the Cue Tone interface. The table below explains the items shown in the above figure.

Item	Description
Upload a file of cue tone	Uploads a user-defined cue tone file to the gateway, including two options: <i>Cue Tone for IVR</i> and <i>Cue Tone for Call Waiting</i> .

Click **Save** to save the above settings into the gateway.

3.5.12 Color Ring




Figure 3-47 Color Ring Interface

By default, there is no available color ring on the gateway. See Figure 3-47. Click **Upload** to upload a new color ring manually. See Figure 3-48. You can upload the required color ring file to the gateway following this interface.

Figure 3-48 Color Ring Upload Interface

The table below explains the items shown above:

Item	Description
Index	The unique index of each color ring to be uploaded.
Description	It is user-defined, with the default value of <i>default</i> .
Color Ring	The file of the color Ring to be uploaded.

After configuration, click **Upload** to upload the color ring file to the gateway or click **Return** to cancel the upload. After upload, the color ring will appear on the color ring manage interface, see Figure 3-49.

Color Ring Manage				
Check	Index	Color Ring	Port	Modify
<input type="checkbox"/>	1	ringtone1	---	

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-49 Color Ring Manage Interface

Click **Modify** in Figure 3-49 to modify the configuration of the color ring or tick the **Upload** checkbox to change the old color ring file. See below for the color ring modification interface. The configuration items on this interface are the same as those on the **Color Ring Upload** interface.

Color Ring-Modify	
Index	<input type="text" value="1"/>
Description	<input type="text" value="ringtone1"/>
Upload	<input checked="" type="checkbox"/>
Color Ring	<input type="text"/> <input type="button" value="Browse..."/>
<p>Note: The file should be a wav file with 8000Hz sampling rate, 16-bit mono, A-law formatted, and less than 200KB in size.</p>	
<input type="button" value="Save"/> <input type="button" value="Cancel"/>	

Figure 3-50 Color Ring Modification Interface

To delete a color ring, check the checkbox before the corresponding index in Figure 3-49 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all color rings at a time, click the **Clear All** button in Figure 3-50.

3.5.13 QoS

QoS	
QoS	<input checked="" type="checkbox"/> Enable
Media Premium QoS	<input type="text" value="46"/>
Control Premium QoS	<input type="text" value="26"/>
<input type="button" value="Save"/> <input type="button" value="Reset"/>	


Figure 3-51 Differentiated Services Setting Interface

See Figure 3-51 for the Differentiated Services setting interface. Using this technology, the gateway can meet various application requirements under a limited bandwidth and ensure neither delay nor discard for important services so as to improve its quality of services.

The table below explains the items shown in the above figure.

Item	Description
QoS	Sets whether to enable the QoS differentiated services. By default, it is disabled.
Media Premium QoS	Sets the priority of the media premium for QoS. A media premium QoS with a bigger value has a higher priority. The value range is 0~63, with the default value of 46.
Control Premium QoS	Sets the priority of the control premium for QoS. A control premium QoS with a bigger value has a higher priority. The value range is 0~63, with the default value of 26.

3.5.14 Action URL



The interface is titled "Channel State Report Settings". It contains two input fields: "Channel Pick up" and "Channel Hang up". Below these fields are two buttons: "Save" and "Reset".

Figure 3-52 Channel State Report Settings Interface

See Figure 3-52 for the Action URL interface, which is used to designate the server patch to report the on-hook or off-hook state of the FXS channel. You are allowed to designate two different server paths. After setting, the state will be reported to the designated server once any of the FXS channel hangs up or picks up a call. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations.

3.6 Port Settings

Port Settings includes five parts: **FXS**, **FXO**, **FXO Port Timer**, **Port Group** and **Advanced FXO Settings**. See Figure 3-53.





Figure 3-53 Port Settings

3.6.1 FXS




The interface shows a table of FXS settings. The table has 19 columns: Port, Type, SIP Account, Display Name, Auto Dial Num, Forbid Outgoing Call, DND, Forward, FWD Type, FWD Number, CID, Call Waiting, Reg Status, Echo Canceller, Color Ring, Color Ring Index, Input Gain, Output Gain, and Modify. There are three rows of data.

Port	Type	SIP Account	Display Name	Auto Dial Num	Forbid Outgoing Call	DND	Forward	FWD Type	FWD Number	CID	Call Waiting	Reg Status	Echo Canceller	Color Ring	Color Ring Index	Input Gain	Output Gain	Modify
1	FXS	8001	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	Edit
2	FXS	8002	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	Edit
30	FXS	8030	---	---	Disable	Disable	Disable	---	---	Enable	Disable	Unregistered	Enable	Disable	---	0	0	Edit

3 Items Total 16 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total [Batch Modify](#)

Figure 3-54 FXS Settings Interface

See Figure 3-54 for the FXS settings interface. The list in the above figure shows the feature and properties of each FXS port. Click **Modify** in Figure 3-54 to modify the properties of the corresponding port. See Figure 3-55 for the FXS modification interface.



The image shows a software window titled "FXS-Modify". It contains various configuration fields for an FXS port. The fields are organized into sections. The first section includes "Port" (a dropdown menu showing "1"), "Type" (a text field showing "FXS"), "Register Port" (a dropdown menu showing "Yes"), "SIP Account" (a text field showing "8001"), "Display Name" (a text field), "Password" (a text field), and "Display Name preferred" (a checkbox labeled "Enable"). The second section includes "Auto Dial Number" (a text field), "Wait Time before Auto Dial (s)" (a text field showing "0"), "Input Gain (dB)" (a text field showing "0"), "Output Gain (dB)" (a text field showing "0"), "Echo Celler" (a checkbox labeled "Enable"), "Forbid Outgoing Call" (a checkbox labeled "Enable"), "CID" (a checkbox labeled "Enable"), "Call Waiting" (a checkbox labeled "Enable"), "DND (Do Not Disturb)" (a checkbox labeled "Enable"), and "Call Forward" (a checkbox labeled "Enable"). The third section includes "Advanced Configuration" (a checkbox labeled "Enable"), "Talkback" (a checkbox labeled "Enable"), "Bound Number" (a text field), "Ringing Parameter" (a dropdown menu showing "RING_F25_75VRMS_0VDC_LPR_SIN"), "Feed Voltage Parameter" (a dropdown menu showing "DCFEED_48V_20MA"), and "Impedance Parameter" (a dropdown menu showing "ZSYN_200_680_100_30_0"). At the bottom of the window, there is a note: "Note: 'Auto Dial Number' goes into effect only if no dialing occurs during 'Wait Time before Auto Dial'." Below the note are three buttons: "Modify", "Reset", and "Cancel".

Figure 3-55 FXS Modification

The table below explains the configuration items on the FXS modification interface.

Item	Description
Port	Serial number of the FXS port on the device.
Type	Type of the port on the device (FXS). This item is not configurable.

Register Port	Sets whether to register the port to the SIP server. When this item is set to <i>No</i> , the item Reg Status on the FXS settings interface (Figure 3-54) shows <i>Unregistered</i> ; when this item is set to <i>Yes</i> , the item Reg Status shows <i>Failed</i> or <i>Registered</i> .
SIP Account	When the port initiates a call to SIP, this item corresponds to the username of SIP. The default SIP account is 80XX among which XX represents the corresponding port number. For example, the default SIP account corresponding to Port 1 is 8001, and that corresponding to Port 32 is 8032.
Display Name	Set the content of the displayname field of the SIP message. If it doesn't set with any value, the displayname field will by default display the content of callerid.
Password	Registration password of the port. To register a port to the SIP server, both items SIP Account and Password must be filled in.
Display Name Preferred	In case this feature is enabled and the port group or the whole gateway is registered, if the display name set by the port is different from that set by the port group, the displayname in the sent SIP message will be the one set by the port. In case this feature is disabled, if the port group is registered, the displayname in the sent SIP message will be the display name set by the port group; if the whole gateway is registered, the displayname in the sent SIP message will be the displayname of the gateway.
Server Index	The index of the SIP server which will be quoted by the current FXS port.
Auto Dial Number, Wait Time before Auto Dial	The FXS port will dial the Auto Dial Number if there is no dialing operation after pickup within a designated time period (i.e. Wait Time before Auto Dial).
Input Gain, Output Gain	Adjusts the gain of the voice input to/ output from the FXS port. The value must be multiples of 3. Range of value: -24~24, calculated by dB, with the default value of 0.
Echo Canceller	The echo cancellation feature for a call conversation over the FXS channel. By default, this feature is enabled and the effect can reach 128ms.
Forbid Outgoing Call	If this feature is enabled, the FXS port will be forbidden to call out. The default setting is <i>disabled</i> .
CID	CallerID. If this feature is enabled, the FXS port will send the CallerID of the incoming IP call together with the ringing tone to the corresponding station. The default setting is <i>enabled</i> . CallerID displays digits only and will filter out any other characters if exist.
Call Waiting	If this feature is enabled, the FXS port in conversation can accept another call from IP and keep it in the waiting state. Once the current conversation is finished and the station hangs up, the call in the waiting state will ring the station and wait for answer. The default setting is <i>disabled</i> .
DND	Do Not Disturb. If this feature is enabled, the FXS port will reply the 403 message to reject all incoming calls. The default setting is <i>disabled</i> .
Call Forward	The automatic call forward feature for the FXS port. Once this feature is enabled, the FXS port will forward incoming IP calls according to FWD Type . Note: To enable this feature, do not put the FXS port into a port group with other ports. The default setting is <i>disabled</i> .

FWD Type	Forward conditions for the FXS port to forward incoming IP calls. The optional values are:								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>Unconditional</td><td>The FXS port will forward all incoming IP calls to the preset FWD Num immediately when it receives them.</td></tr><tr><td>Busy</td><td>The FXS port will forward incoming IP calls to the preset FWD Num if it is busy upon receiving them.</td></tr><tr><td>No Reply</td><td>The FXS port will forward incoming IP calls to the preset FWD Num if the corresponding station does not answer them in a designated time period (i.e. Time for No Reply Forward). Only when this forward condition is selected does the configuration item Time for No Reply Forward become valid.</td></tr></table>	Option	Description	Unconditional	The FXS port will forward all incoming IP calls to the preset FWD Num immediately when it receives them.	Busy	The FXS port will forward incoming IP calls to the preset FWD Num if it is busy upon receiving them.	No Reply	The FXS port will forward incoming IP calls to the preset FWD Num if the corresponding station does not answer them in a designated time period (i.e. Time for No Reply Forward). Only when this forward condition is selected does the configuration item Time for No Reply Forward become valid.
	Option	Description							
	Unconditional	The FXS port will forward all incoming IP calls to the preset FWD Num immediately when it receives them.							
	Busy	The FXS port will forward incoming IP calls to the preset FWD Num if it is busy upon receiving them.							
No Reply	The FXS port will forward incoming IP calls to the preset FWD Num if the corresponding station does not answer them in a designated time period (i.e. Time for No Reply Forward). Only when this forward condition is selected does the configuration item Time for No Reply Forward become valid.								
This item is valid only when Call Forward is set to <i>Enable</i> .									
FWD Num	The number to which the incoming IP call is forwarded. If the Call Forward feature is enabled, this item cannot be left empty.								
Color Ring	Sets whether to enable the color ring feature or not, with the default setting of being <i>disabled</i> . Note: Only when there are available color rings will appear this item.								
Color Ring Index	The index of the color ring which will be quoted by the current FXS port.								
Talkback	With this feature enabled and a number bound, the port can talk back to its bound number. That is, they can start a call with each other as soon as picking up the phone. The default setting is <i>disabled</i> . Note: This feature is only used in the case of channel registration.								
Bound Number	Sets the bound number for talkback.								
Ringing Parameter	Sets the ringing parameter for the FXS module. The default value is <i>RING_F25_75VRMS_0VDC_LPR_SIN</i> Note: Usually there is no need to modify it; please contact our technicians if necessary.								
Feed Voltage Parameter	Sets the feed voltage parameter for the FXS module. The default value is <i>DCFEED_48V_20MA</i> . Note: Usually there is no need to modify it; please contact our technicians if necessary.								
Impedance Parameter	Sets the impedance for the FXS module. The default value is <i>ZSYN_200_680_100_30_0</i> . Note: Usually there is no need to modify it; please contact our technicians if necessary.								

After configuration, click **Modify** to save the settings into the gateway, click **Reset** to restore the configurations, or click **Cancel** to cancel the settings.

Or you can click **Batch** to modify several pieces of FXS settings at the same time. See Figure 3-56 below for the FXS batch modification interface. The configuration items on this interface are the same as those on the FXS modification interface (Figure 3-55).

FXS-Batch Modify

Starting Port

Ending Port

Register Port

Starting SIP Account

Starting Display Name

Starting Authentication Password

Display Name Preferred

☐ Enable

SIP Account Batch Rule

SIP Account Batch Step Size

Display Name Batch Rule

Display Name Batch Step Size

Authentication Password Batch Rule

Authentication Password Batch Step Size

Auto Dial Number

☐ Enable

Input Gain (dB)

Output Gain (dB)

CID

☒ Enable

Echo Canceller

☒ Enable

Forbid Outgoing Call

☐ Enable

Call Waiting

☐ Enable

DND (Do Not Disturb)

☐ Enable

Call Forward

☐ Enable

Advanced Configuration

☒ Enable

Ringing Parameter

Feed Voltage Parameter

Impedance Parameter

Note: 'Auto Dial Number' goes into effect only if no dialing occurs during 'Wait Time before Auto Dial'.

Figure 3-56 FXS Batch Modification




Some configuration items on this interface are the same as those on the **FXS Modification Interface**. The others are described in the table below.

Item	Description
Starting Port	The starting serial number of the FXS port on the device in the batch setting.
Ending Port	The ending serial number of the FXS port on the device in the batch setting.
Starting SIP Account	The starting SIP account in the batch setting.

Starting Display Name	The starting displayname in the batch setting.
Starting Authentication Password	The starting authentication password in the batch setting.
SIP Account Batch Rule	The rule for batch setting the SIP account, including Increase and Decrease two options.
SIP Account Batch Step Size	Sets the increase or decrease step size of the SIP account in the batch setting.
Display Name Batch Rule	The rule for batch setting the display name, including Increase , Decrease and All Same three options.
Display Name Batch Step Size	Sets the increase or decrease step size of the display name in the batch setting.
Authentication Password Batch Rule	The rule for batch setting the authentication password, including Increase , Decrease and All Same three options.
Authentication Password Batch Step Size	Sets the increase or decrease step size of the authentication password in the batch setting.

After configuration, click **Modify** to save the settings into the gateway, or click **Cancel** to cancel the settings.

3.6.2 FXO

FXO Settings													
Port	Type	SIP Account	Display Name	Connection Method	Bound Number	Forbid Outgoing Call	Caller ID Detection	Reg Status	Echo Cancellation	Polarity Reversal Detection	Input Gain	Output Gain	Modify
27	FXO	8027	---	Two Stages Dialing for Incoming Call	---	Disable	Enable	Unregistered	Enable	Disable	0	0	
28	FXO	8028	---	Two Stages Dialing for Incoming Call	---	Disable	Enable	Unregistered	Enable	Disable	0	0	
29	FXO	8029	---	Two Stages Dialing for Incoming Call	---	Disable	Enable	Unregistered	Enable	Disable	0	0	

3 Items Total 16 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total Batch Modify

Figure 3-57 FXO Settings Interface

See Figure 3-57 for the FXO settings interface. The list in the above figure shows the feature and properties of each FXO port. Click **Modify** in Figure 3-57 to modify the properties of the corresponding port. See Figure 3-58 for the FXO modification interface.

FXO-Modify

Port

Type

Register Port

SIP Account

Display Name

Password

Display Name preferred
☐ Enable

Connection Method

Bound Number

Input Gain (dB)

Output Gain (dB)

Echo Canceller
☒ Enable

Forbid Outgoing Call
☒ Enable

Caller ID Detection
☒ Enable

Polarity Reversal Detection
☐ Enable

Figure 3-58 FXO Modification

The table below explains the configuration items on the FXO modification interface.

Item	Description
Port	Serial number of the FXO port on the device.
Type	Type of the port on the device (FXO). This item is not configurable.
Register Port	Sets whether to register the port to the SIP server. When this item is set to <i>No</i> , the item Reg Status on the FXO settings interface (Figure 3-57) shows <i>Unregistered</i> ; when this item is set to <i>Yes</i> , the item Reg Status shows <i>Failed</i> or <i>Registered</i> .
SIP Account	Registration account of an FXO port. The default SIP account is 80XX among which XX represents the corresponding port number. For example, the default SIP account corresponding to Port 1 is 8001, and that corresponding to Port 32 is 8032.
Display Name	Set the content of the displayname field of the SIP message. If it doesn't set with any value, the displayname field will by default display the content of callerid.
Password	Registration password of the port. To register a port to the SIP server, both items SIP Account and Password must be filled in.

Display Name Preferred	In case this feature is enabled and the port group or the whole gateway is registered, if the display names set by the port are different from that set by the port group, the displayname in the sent SIP message will be the one set by the port. In case this feature is disabled, if the port group is registered, the displayname in the sent SIP message will be the display name set by the port group; if the whole gateway is registered, the displayname in the sent SIP message will be the displayname of the gateway.						
Server Index	The index of the SIP server which will be quoted by the current FXO port.						
Connection Method	<p>FXO connection methods include:</p> <table border="1"> <thead> <tr> <th>Option</th><th>Description</th></tr> </thead> <tbody> <tr> <td><i>Static Binding</i></td><td>Bind the number which corresponds to an FXS port to an FXO port. The number will be listed in the Bound Number column. This helps to achieve the corresponding binding between an FXO port and an FXS port (two-way).</td></tr> <tr> <td><i>Two Stages Dialing Mode (default)</i></td><td>Under this mode, an incoming call from an FXO port will go into the IVR system. Then IVR will play a speech prompt "Please dial the extension number". If you fail to input the correct target station number before IVR finishes the third repeat of the prompt, the FXO will hang up the call automatically; otherwise, the corresponding station will ring.</td></tr> </tbody> </table> <p>Note: Both items Connection Method and Bound Number will be hidden if the SIP Station feature is enabled on the SIP Settings interface.</p>	Option	Description	<i>Static Binding</i>	Bind the number which corresponds to an FXS port to an FXO port. The number will be listed in the Bound Number column. This helps to achieve the corresponding binding between an FXO port and an FXS port (two-way).	<i>Two Stages Dialing Mode (default)</i>	Under this mode, an incoming call from an FXO port will go into the IVR system. Then IVR will play a speech prompt "Please dial the extension number". If you fail to input the correct target station number before IVR finishes the third repeat of the prompt, the FXO will hang up the call automatically; otherwise, the corresponding station will ring.
Option	Description						
<i>Static Binding</i>	Bind the number which corresponds to an FXS port to an FXO port. The number will be listed in the Bound Number column. This helps to achieve the corresponding binding between an FXO port and an FXS port (two-way).						
<i>Two Stages Dialing Mode (default)</i>	Under this mode, an incoming call from an FXO port will go into the IVR system. Then IVR will play a speech prompt "Please dial the extension number". If you fail to input the correct target station number before IVR finishes the third repeat of the prompt, the FXO will hang up the call automatically; otherwise, the corresponding station will ring.						
Input Gain, Output Gain	Adjusts the gain of the voice input to/ output from the FXO port. The value must be multiples of 3. Range of value: -24~24, calculated by dB, with the default value of 0.						
Echo Cancellor	The echo cancellation feature for a call conversation over the FXO channel. By default, this feature is enabled and the effect can reach 128ms.						
Forbid Outgoing Call	If this feature is enabled, the FXO port will be forbidden to call out. The default setting is <i>disabled</i> .						
Caller ID Detection	If this feature is enabled, the FXO port will detect the caller IDs from the incoming calls. The default setting is <i>enabled</i> .						
Polarity Reversal Detection	Once this feature is enabled, only when the FXO port detects the polarity reversal signal will the corresponding channel go into the talking state. The default setting is <i>disabled</i> . Note: This feature and the Two Stages Dialing feature cannot be enabled at the same time.						

After configuration, click **Modify** to save the settings into the gateway, click **Reset** to restore the configurations, or click **Cancel** to cancel the settings.

Or you can click **Batch** to modify several pieces of FXO settings at the same time. See Figure 3-59 below for the FXO batch modification interface. The configuration items on this interface are the same as those on the FXO modification interface (Figure 3-58).

FXO-Batch Modify

Starting Port

27

Ending Port

29

Register Port

Yes

Starting SIP Account

Starting Display Name

Starting Authentication Password

Display Name Preferred

☐ Enable

SIP Account Batch Rule

Increase

SIP Account Batch Step Size

1

Display Name Batch Rule

Increase

Display Name Batch Step Size

1

Authentication Password Batch Rule

Increase

Authentication Password Batch Step Size

1

Connection Method

Static Binding for O

Starting Bound Number

Batch Rule of Bound Number

Increase

Batch Step Size of Bound Number

1

Input Gain (dB)

0

Output Gain (dB)

0

Echo Canceller

☒ Enable

Forbid Outgoing Call

☐ Enable

Caller ID Detection

☒ Enable

Polarity Reversal Detection

☐ Enable

Save

Cancel

Figure 3-59 FXO Batch Modification

Some configuration items on this interface are the same as those on the **FXO Modification Interface**. The others are described in the table below.

Item	Description
Starting Port	The starting serial number of the FXO port on the device in the batch setting.
Ending Port	The ending serial number of the FXO port on the device in the batch setting.
Starting SIP Account	The starting SIP account in the batch setting.
Starting Display Name	The starting displayname in the batch setting.
Starting Authentication Password	The starting authentication password in the batch setting.
SIP Account Batch Rule	The rule for batch setting the SIP account, including Increase and Decrease two options.

SIP Account Batch Step Size	Sets the increase or decrease step size of the SIP account in the batch setting.
Display Name Batch Rule	The rule for batch setting the display name, including Increase , Decrease and All Same three options.
Display Name Batch Step Size	Sets the increase or decrease step size of the display name in the batch setting.
Authentication Password Batch Rule	The rule for batch setting the authentication password, including Increase , Decrease and All Same three options.
Authentication Password Batch Step Size	Sets the increase or decrease step size of the authentication password in the batch setting.
Batch Rule of Bound Number	The rule for batch setting the bound number, including Increase , Decrease and Use the same number three options.
Batch Step Size of Bound Number	Sets the increase or decrease step size of the bound number in the batch setting.

After configuration, click **Save** to save the settings into the gateway, or click **Cancel** to cancel the settings.

3.6.3 FXO Port Timer





FXO Port Timer								
Check	Port	Type	Unit	Max Time(Single Call)	Max Time(Total Calls)	Used Call Time	Clear Call Time	Modify
<input type="checkbox"/>	1	FXO	60s	60	60/Month	0	1th day of month 00:00	
<input type="checkbox"/>	2	FXO	60s	Unlimited	Unlimited	---	---	
<input type="checkbox"/>	5	FXO	60s	Unlimited	Unlimited	---	---	
<input type="checkbox"/>	6	FXO	60s	Unlimited	Unlimited	---	---	
<input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Clear"/> <input type="button" value="reflash"/>								

Figure 3-60 FXO Port Timer Interface

See Figure 3-60 for the FXO Port Timer interface, which displays such information as the max call time limit for a single call, the max call time limit for the total calls on each FXO port, as well as the timer clear cycle. Click Modify for each port in Figure 3-60 to modify the timer settings. See Figure 3-61.

Timing

Port

Unit

Time Limit on a Single Call

Max Call Time

Time Limit on Total Calls

Max Call Time

Timing Cycle

Clear

☐ Set Spent Call Time

SIP Code Reply

Apply to Other Ports

1

60s

☐ Disable ☒ Enable

60

☐ Disable ☒ Enable

60

Month

1st 00 00

486

☒ Port ☐ Port Group

☒ 01 ☐ 02 ☐ 05 ☐ 06

Modify

Return

Figure 3-61 FXO Port Timing Setting Interface

The table below explains the configuration items shown in the above figure:

Item	Description
Port	Serial number of the FXO port on the device.
Unit	Sets the timing unit for the call. The actual call time will be calculated as the integral multiple of the setting time. Take an example: supposed the setting time is 30s and the actual call time is 72s, thus, the gateway will consider the call time as 90s.
Time Limit on a Single Call	Sets whether to enable the time limit on a single call.
Max Call Time	Sets the maximum time length of a call.
Time Limit on Total Calls	Sets whether to enable the time limit on all calls at the port.
Timing Cycle	Sets the time count cycle for the port.
Clear	Sets the time node to clear the time count.
Set Spent Call Time	Sets the spent call time length of the port.
SIP Code Reply	Once the spent call time reaches the total time limit, the FXO port will not be able to make outgoing calls and the gateway will reply the designated SIP code to the IP side.
Apply to Other Ports	Sets whether to apply above settings to other ports or port groups.

Click **Modify** to save the settings into the gateway, click **Return** to cancel the settings.

3.6.4 FXO List Timer

Figure 3-62 FXO List Timer Interface

See Figure 3-62 for the FXO List Timer interface, which displays the index information of the FXO port in timing. Click the **Setting** button on the top right corner to set the timer. See Figure 3-63. Click the **Add New** button at the bottom to add the list timing rule. See Figure 3-64.

Figure 3-63 List Timing Setting Interface

Figure 3-64 List Timing Rule Adding Interface

The table below explains the configuration items shown in the above figure:

Item	Description
Rule Index	The index of timing rule, used for the FXO port in list timing.
Set Spent Call Time	The length of the time already used in this rule.
Import Number	Import the matching numbers.

Number Matching Rule	There are two number matching modes: Prefix Matching and Whole Words only .
Max Call Time	The maximum call time in this rule
Timing Cycle	The timing cycle in this rule
Clear	The time to clear the timer within the timing cycle in this rule

Click **Save** to save the settings into the gateway; click **Reset** to restore the configurations; click **Return** to cancel the settings.

3.6.5 Port Group




Figure 3-65 Port Group Setting Interface

See Figure 3-65 for the Port Group Settings interface. By default, there is no available port group on the gateway. A port group is a set containing one or more than one port, having such properties as **Port Selection** and **Authentication Mode** the same for all the ports in it. A new port group can be added by the **Add New** button on the bottom right corner of the above list. See Figure 3-66 for the port group adding interface. Note that a port which has been occupied by one port group cannot be chosen by others.

Port Group-Add

Index

Description

Register Port Group

SIP Account

Display Name

Password

Authentication Username

Server Index

Authentication Mode

Port Select Mode

Rule for Ringing by Turns

Timeout for Ringing by Turns (s)

Port Reused by Multiple Groups ☐

Port

☐ Port 1(FXS)

☐ Port 2(FXS)

☐ Port 3(FXS)

☐ Port 4(FXS)

☐ Port 5(FXS)

☐ Port 6(FXS)

☐ Port 7(FXS)

☐ Port 8(FXS)

☐ Port 9(FXS)

☐ Port 10(FXS)

☐ Port 11(FXS)

☐ Port 12(FXS)

☐ Port 13(FXS)

☐ Port 14(FXS)

☐ Port 15(FXS)

☐ Port 16(FXS)

☐ Port 17(FXS)

☐ Port 18(FXS)

☐ Port 19(FXS)

☐ Port 20(FXS)

☐ Port 21(FXS)

☐ Port 22(FXS)

☐ Port 23(FXS)

☐ Port 24(FXS)

☐ Port 25(FXS)

☐ Port 26(FXS)

☐ Port 27(FXS)

☐ Port 28(FXS)

☐ Port 29(FXS)

☐ Port 30(FXS)

☐ Port 31(FXS)

☐ Port 32(FXS)

Figure 3-66 Add New Port Group

The table below explains the items in the above figure.

Item	Description
Index	The unique index of each port group, which is mainly used in the configuration of routing rules and number manipulation rules to correspond to port groups.
Description	More information about each port group, with default value of <i>default</i> .
Register Port Group	To register the port group to the SIP server. Only when this configuration item is set to <i>Yes</i> can you see the configuration items SIP Account and Password .
SIP Account	When the port group initiates a call to SIP, this item corresponds to the username of SIP.
Display Name	Set the content of the displayname field of the SIP message. If it doesn't set with any value, the displayname field will by default display the content of callerid.

Password	Registration password of the port group. To register the port group to the SIP server, both configuration items SIP Account and Password should be filled in.										
Authentication Username	Authentication username of a port, used to register the port to the SIP server when IMS network is enabled. Note: This item appears only when IMS Network is enabled.										
Server Index	The index of the SIP server which will be quoted by the current port group.										
Authentication Mode	<p>Sets the way for SIP to make outgoing calls (Tel→IP) on the gateway.</p> <table> <tr> <th>Option</th><th>Description</th></tr> <tr> <td><i>Do Not Register (default)</i></td><td>SIP initiates a call in a point-to-point mode.</td></tr> <tr> <td><i>Register Gateway</i></td><td>SIP initiates a call with the registered SIP account and password of the whole gateway. (Refer to 3.4.1 SIP for gateway registration.)</td></tr> <tr> <td><i>Register Port Group</i></td><td>SIP initiates a call with the registered SIP account and password of the port group.</td></tr> <tr> <td><i>Register Port</i></td><td>SIP initiates a call with the registered SIP account and password of the port.</td></tr> </table>	Option	Description	<i>Do Not Register (default)</i>	SIP initiates a call in a point-to-point mode.	<i>Register Gateway</i>	SIP initiates a call with the registered SIP account and password of the whole gateway. (Refer to 3.4.1 SIP for gateway registration.)	<i>Register Port Group</i>	SIP initiates a call with the registered SIP account and password of the port group.	<i>Register Port</i>	SIP initiates a call with the registered SIP account and password of the port.
Option	Description										
<i>Do Not Register (default)</i>	SIP initiates a call in a point-to-point mode.										
<i>Register Gateway</i>	SIP initiates a call with the registered SIP account and password of the whole gateway. (Refer to 3.4.1 SIP for gateway registration.)										
<i>Register Port Group</i>	SIP initiates a call with the registered SIP account and password of the port group.										
<i>Register Port</i>	SIP initiates a call with the registered SIP account and password of the port.										
Register Status	Registration status of the port group. When Register Port Group is set to <i>No</i> , the value of this item is <i>Unregistered</i> ; when Register Port Group is set to <i>Yes</i> , the value of this item may be <i>Failed</i> or <i>Registered</i> .										

Port Select Mode	When the port group receives a call, it will choose a port based on the select mode set by this configuration item to ring or to connect. The optional values and their corresponding meanings are described in the table below.														
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>Increase (default)</i></td><td>Search for an idle port in the ascending order of the port number, starting from the minimum. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.</td></tr><tr><td><i>Decrease</i></td><td>Search for an idle port in the descending order of the port number, starting from the maximum. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.</td></tr><tr><td><i>Cyclic Increase</i></td><td>Provided Port N is the available port found last time. Search for an idle port in the ascending order of the port number, starting from Port N+1. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.</td></tr><tr><td><i>Cyclic Decrease</i></td><td>Provided Port N is the available port found last time. Search for an idle port in the descending order of the port number, starting from Port N-1. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.</td></tr><tr><td><i>Group Ringing</i></td><td>Ring all the idle FXS ports in this port group.</td></tr><tr><td><i>Ringing by Turns</i></td><td>Ring the ports in this port group according to the <i>Rule for Ringing by Turns</i> which can be user-defined. Refer to the format of the rule in Figure 3-66. By default, the ringing will be carried out in the ascending order of the port number. <i>Timeout for Ringing by Turns</i> is used to set the overtime for ringing. Range of value: 15~60, calculated by s, with the default value of 20.</td></tr></table>	Option	Description	<i>Increase (default)</i>	Search for an idle port in the ascending order of the port number, starting from the minimum. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.	<i>Decrease</i>	Search for an idle port in the descending order of the port number, starting from the maximum. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.	<i>Cyclic Increase</i>	Provided Port N is the available port found last time. Search for an idle port in the ascending order of the port number, starting from Port N+1. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.	<i>Cyclic Decrease</i>	Provided Port N is the available port found last time. Search for an idle port in the descending order of the port number, starting from Port N-1. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.	<i>Group Ringing</i>	Ring all the idle FXS ports in this port group.	<i>Ringing by Turns</i>	Ring the ports in this port group according to the <i>Rule for Ringing by Turns</i> which can be user-defined. Refer to the format of the rule in Figure 3-66. By default, the ringing will be carried out in the ascending order of the port number. <i>Timeout for Ringing by Turns</i> is used to set the overtime for ringing. Range of value: 15~60, calculated by s, with the default value of 20.
	Option	Description													
	<i>Increase (default)</i>	Search for an idle port in the ascending order of the port number, starting from the minimum. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.													
	<i>Decrease</i>	Search for an idle port in the descending order of the port number, starting from the maximum. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.													
	<i>Cyclic Increase</i>	Provided Port N is the available port found last time. Search for an idle port in the ascending order of the port number, starting from Port N+1. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.													
	<i>Cyclic Decrease</i>	Provided Port N is the available port found last time. Search for an idle port in the descending order of the port number, starting from Port N-1. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.													
<i>Group Ringing</i>	Ring all the idle FXS ports in this port group.														
<i>Ringing by Turns</i>	Ring the ports in this port group according to the <i>Rule for Ringing by Turns</i> which can be user-defined. Refer to the format of the rule in Figure 3-66. By default, the ringing will be carried out in the ascending order of the port number. <i>Timeout for Ringing by Turns</i> is used to set the overtime for ringing. Range of value: 15~60, calculated by s, with the default value of 20.														
Preemptive Answer Keyboard Shortcut	When a channel in a port group is ringing, another channel in the same port group can press the keyboard shortcut set by this item to transfer the call from the ringing channel to the current channel. Note: This item will become invalid if the gateway works under the port select mode <i>Group Ringing</i> or <i>Ringing by Turns</i> .														
Port Reused by Multiple Groups	Once this feature is enabled, a port can be added to different port groups.														
Port	The ports in the port group. If the checkbox before a port is grey, it indicates that the port is not available or has been occupied. Once the feature “Port Reused by Multiple Groups” is enabled, a port which has been occupied is still available for other port groups. All selected ports for a port group will be displayed in the Ports column in Figure 3-67. Note: When a port group contains multiple ports, the automatic call forward feature is invalid.														

After configuration, click **Save** to save the settings into the gateway, click **Reset** to restore the configurations, or click **Cancel** to cancel the settings. **Check All** means to select all available ports on the current page; **Inverse** means to uncheck the selected items and check the unselected. **Check All FXO Ports** means to select all available FXO ports on the current page; **Check All FXS Ports** means to select all available FXS ports on the current page. See Figure 3-67 for the port group list with saved configurations.

Port Group Settings										
Check	Index	Description	SIP Account	Display Name	Authentication Username	Ports	Port Select Mode	Rule for Ringing by Turns	Timeout for Ringing by Turns (s)	Pre
<input type="checkbox"/>	1	default	---	---	---	1,2	Increase	---	---	Pre

1 Item Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-67 Port Group List

Click **Modify** at the end of the list in Figure 3-67 to modify the properties of a port group. See Figure 3-68 for the port group modification interface. The configuration items on this interface are the same as those on the **Add New Port Group** interface.

Port Group-Modify				
Index	<input type="text" value="1"/>			
Description	<input type="text" value="default"/>			
Register Port	<input type="text" value="Yes"/>			
SIP Account	<input type="text"/>			
Display Name	<input type="text"/>			
Password	<input type="text"/>			
Authentication Username	<input type="text" value="-1"/>			
Server Index	<input type="text" value="1:201.123.115.233"/>			
Authentication Mode	<input type="text" value="Do Not Register"/>			
Port Select Mode	<input type="text" value="Increase"/>			
Preemptive Answer Keyboard Shortcut	<input type="text"/>			
Port Reused by Multiple Groups	<input type="checkbox"/>			
Port	<div> <input checked="" type="checkbox"/> Port 1(FXS) <input checked="" type="checkbox"/> Port 2(FXS) <input type="checkbox"/> Port 3(FXS) <input type="checkbox"/> Port 4(FXS) </div> <div> <input type="checkbox"/> Port 5(FXS) <input type="checkbox"/> Port 6(FXS) <input type="checkbox"/> Port 7(FXS) <input type="checkbox"/> Port 8(FXS) </div> <div> <input type="checkbox"/> Port 9(FXS) <input type="checkbox"/> Port 10(FXS) <input type="checkbox"/> Port 11(FXS) <input type="checkbox"/> Port 12(FXS) </div> <div> <input type="checkbox"/> Port 13(FXS) <input type="checkbox"/> Port 14(FXS) <input type="checkbox"/> Port 15(FXS) <input type="checkbox"/> Port 16(FXS) </div> <div> <input type="checkbox"/> Port 17(FXS) <input type="checkbox"/> Port 18(FXS) <input type="checkbox"/> Port 19(FXS) <input type="checkbox"/> Port 20(FXS) </div> <div> <input type="checkbox"/> Port 21(FXS) <input type="checkbox"/> Port 22(FXS) <input type="checkbox"/> Port 23(FXS) <input type="checkbox"/> Port 24(FXS) </div> <div> <input type="checkbox"/> Port 25(FXS) <input type="checkbox"/> Port 26(FXS) <input type="checkbox"/> Port 27(FXS) <input type="checkbox"/> Port 28(FXS) </div> <div> <input type="checkbox"/> Port 29(FXS) <input type="checkbox"/> Port 30(FXS) <input type="checkbox"/> Port 31(FXS) <input type="checkbox"/> Port 32(FXS) </div>			
	<input type="button" value="Check All"/> <input type="button" value="Inverse"/> <input type="button" value="Check All FXO Ports"/> <input type="button" value="Check All FXS Ports"/>			
<div> <input type="button" value="Modify"/> <input type="button" value="Reset"/> <input type="button" value="Cancel"/> </div>				

Figure 3-68 Modify Port Group

To delete a port group, check the checkbox before the corresponding index in Figure 3-67 and click the '**Delete**' button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all port groups at a time, click the **Clear All** button in Figure 3-67.

3.6.6 Advanced FXO Settings

Advanced FXO Settings

Mailbox Settings
Mailbox Account
Password
Outgoing(SMTP)
SSL
Recipient
Subject
Content

asd@sfd.com

☐

Warning: gateway port disconn

gateway:[devinfo],port[port]

disconnection

Sending test

Port 25

Note:1,Multiple recipients must be separated by ','
2,In subject and content:
2.1,[devinfo] represents the device information i.e. device type and serial number.
2.2,[port] indicates the port number.

FXO Off-line Alarm
Port

<input type="checkbox"/> Port 1(FXO)	<input type="checkbox"/> Port 2(FXO)	<input type="checkbox"/> Port 3(---)	<input type="checkbox"/> Port 4(---)
<input type="checkbox"/> Port 5(FXO)	<input type="checkbox"/> Port 6(FXO)	<input type="checkbox"/> Port 7(---)	<input type="checkbox"/> Port 8(---)
<input type="checkbox"/> Port 9(FXS)	<input type="checkbox"/> Port 10(FXS)	<input type="checkbox"/> Port 11(---)	<input type="checkbox"/> Port 12(---)
<input type="checkbox"/> Port 13(FXS)	<input type="checkbox"/> Port 14(FXS)	<input type="checkbox"/> Port 15(---)	<input type="checkbox"/> Port 16(---)
<input type="checkbox"/> Port 17(---)	<input type="checkbox"/> Port 18(---)	<input type="checkbox"/> Port 19(---)	<input type="checkbox"/> Port 20(---)
<input type="checkbox"/> Port 21(---)	<input type="checkbox"/> Port 22(---)	<input type="checkbox"/> Port 23(---)	<input type="checkbox"/> Port 24(---)
<input type="checkbox"/> Port 25(---)	<input type="checkbox"/> Port 26(---)	<input type="checkbox"/> Port 27(---)	<input type="checkbox"/> Port 28(---)
<input type="checkbox"/> Port 29(---)	<input type="checkbox"/> Port 30(---)	<input type="checkbox"/> Port 31(---)	<input type="checkbox"/> Port 32(---)

Blacklist of FXO Incoming Calls
Blacklist
Processing Mode
Hang-up Delay (ms)

Hang up after pick-u

2000

Note:1,Multiple blacklists must be separated by ','
2,The "Caller ID Detection" feature should be enabled for the port to activate the blacklist feature.

Figure 3-69 Advanced FXO Settings Interface

See Figure 3-69 for the Advanced FXO Settings interface. The table below explains the configuration items on the interface.

Item	Description
Mailbox Account, Password	Sets the account and password of the mailbox.
Outgoing (SMTP), Port	Sets the server address and port for Email sending.
SSL	Sets whether to encrypt the sending/receiving mails via SSL.
Recipient	Sets the address of the recipient.
Subject	Sets the mail subject.
Content	Sets the mail content.
FXO Off-line Alarm	After selecting the ports, the gateway will send the alarm email when the selected ports are off-line.
Blacklist of FXO Incoming	Sets the blacklist of the FXO incoming calls.
Processing Mode	Sets the processing mode for the blacklist, including two options: <i>Hang up after pick-up</i> and <i>Hang up after ringing</i> . The default value is <i>Hang up after pick-up</i> .
Hang-up Delay	Sets the delay to hang up the call after the pick-up.

After configuration, click **Save** to save the settings into the gateway or click **Reset** to reset the settings.

3.7 Route Settings

Route Settings is used to specify the routing rules for calls on two directions: IP→Tel and Tel→IP. See Figure 3-70.




Figure 3-70 Route Settings

3.7.1 Routing Parameters

Routing Parameters	
IP->TEL	Route before Number Manipulate
TEL->IP	Route before Number Manipulate
Route Detection Cycle (s)	0
<input type="button" value="Save"/>	

Figure 3-71 Routing Parameters Configuration Interface

See Figure 3-71 for the routing parameters configuration interface. On this interface, you can set the routing rules for calls respectively on two directions IP→Tel and Tel→IP to be routing before or after number manipulation. The default value is *Route before Number Manipulate*. The gateway will send the option message to detect whether the TEL->IP routing is valid or not after setting the Route Detection Cycle. If the remote address doesn't respond this option message within the set cycle, this routing will be regarded as invalid and the outgoing calls won't be routed to this TEL->IP routing.

After configuration, click **Save** to save the above settings into the gateway.

3.7.2 IP to Tel




Figure 3-72 IP→Tel Routing Rule Configuration Interface (Standard)

See Figure 3-72 for the IP→Tel routing rule configuration interface. By default, there is no available routing rule on the gateway. The IP→Tel routing rule configuration has two modes: Standard and Character.

Under the Standard mode, click **Add New** to add them manually. See Figure 3-73. You may use the default values of all the configuration items herein.

Figure 3-73 Add New Routing Rule (IP→Tel)

The table below explains the items shown in the above figure.

Item	Description
Index	The unique index of each routing rule, which denotes its priority. A routing rule with a smaller index value has a higher priority. If a call matches several routing rules, it will be processed according to the one with the highest priority.
Description	More information about each routing rule, with the default value of <i>default</i> .
Source IP	IP address from where the call is initiated. This item can be set to a specific IP address or "*" which indicates any IP address
CallerID Prefix, CalleeID Prefix	A string of characters at the beginning of the caller/called party number. It can be a specific string consisting of digits 0~9, "[*]", "#", or character ranges defined by []. '[]' represents a character within the range it defines. Values in [] only can be characters '0~9', "[*]", "#", punctuations '-' and ','; '-' is used between two characters to indicate any character between these two characters; ',' is used to separate characters or character ranges, representing alternatives.) For example, 057[1-3,6] represents the string 0571, 0572, 0573 or 0576. Also these items can be set to "*" which indicates any string. These two configuration items together with Source IP specify a routing rule for calls. Note: "[*]" represents TFM symbol *, while "*" represents any string.
Route by Number	When this feature is enabled, the gateway will route a call from IP to a corresponding port based on its number. And the number of the port which this call will be routed to can be set via the item SIP Account on the FXS or FXO settings interface. In such case, the configuration item Call Destination goes invalid and shows <i>Route by Number</i> on the routing rule configuration interface. The default setting is <i>disabled</i> .
Call Destination	Port group to which the call will be routed.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

See Figure 3-74 for the IP→Tel routing rule configuration interface after your configuration. There is a rule displayed with Index 63 and Call Destination 'Route by Number', having no restriction on Source IP, CallerID Prefix and CalleeID Prefix, which indicates the gateway will route a call from any IP address to a corresponding port based on its number.

Press the **Add New** button on the bottom right corner of the list to add a new routing rule.

IP→Tel Routing Rule							
Check	Index	Source IP	CallerID Prefix	CalleeID Prefix	Call Destination	Description	Modify
<input type="checkbox"/>	63	*	*	*	Route by Number	default	
<div> <input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Inverse"/> <input type="button" value="Delete"/> <input type="button" value="Clear All"/> <input type="button" value="Add New"/> </div>							
1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page <input type="text" value="1"/> 1 Pages Total							

Figure 3-74 IP→Tel Routing Rule Configuration Interface

Click **Modify** in Figure 3-74 to modify a routing rule. The configuration items on the IP→Tel routing rule modification interface are the same as those on the **Add New Routing Rule (IP→Tel)** interface. Note that the item **Index** cannot be modified.

To delete a routing rule, check the checkbox before the corresponding index in Figure 3-74 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all routing rules at a time, click the **Clear All**

button in Figure 3-74.

See Figure 3-75 for the IP→Tel Routing Rule Configuration Interface under the Character mode. You can edit the routing rule list to add a new one or modify an old one. The exact meaning of each element of the rule is described on the page.

The screenshot shows the 'IP->Tel Routing Rule' configuration interface in 'Character Mode'. At the top, there are tabs for 'Standard Mode' and 'Character Mode'. Below the tabs, a blue header bar contains the title 'IP->Tel Routing Rule'. A note states: 'Note: The routing information contains such fields as Source IP, CallerID Prefix, CalleeID Prefix, Route by Number, Destination Port Group and Description. The priority decreases from top to bottom; adjacent fields are separated by a space. Symbol * in Source IP, CallerID Prefix and CalleeID Prefix indicates any IP address or string; When Route by Number is set to 1, the Destination Port Group will be enabled. Don't forget to save the configuration after your modification!'. Below the note, a large text area contains the text '*** 0 0 default'. At the bottom left, it says '1 Items Total'. At the bottom right, there is a 'Save' button.

Figure 3-75 IP→Tel Routing Rule Configuration Interface (Character)

3.7.3 Tel to IP

The screenshot shows the 'Tel→IP Routing Rule' configuration interface in 'Standard Mode'. On the left, there is a sidebar with a menu containing 'Operation Info', 'Quick Config', 'VoIP', 'Advanced', 'Port', 'Route', 'Routing Parameters', 'IP->Tel', and 'Tel->IP'. The 'Tel->IP' item is selected. The main area has tabs for 'Standard Mode' and 'Character Mode'. Below the tabs, the text 'No available routing rule!' is displayed. At the bottom right, there is an 'Add New' button.

Figure 3-76 Tel→IP Routing Rule Configuration Interface (Standard)

See Figure 3-76 for the Tel→IP routing rule configuration interface. By default, there is no available routing rule on the gateway. The Tel→IP routing rule configuration has two modes: Standard and Character.

Under the Standard mode, click **Add New** to add them manually. See Figure 3-77. You may use the default values of all the configuration items herein except for **Destination IP** and **Destination Port**.




Figure 3-77 Add New Routing Rule (Tel→IP)

The table below explains the items shown in the above figure.

Item	Description
Index	The unique index of each routing rule, which denotes its priority. A routing rule with a smaller index value has a higher priority. If a call matches several routing rules, it will be processed according to the one with the highest priority.
Description	More information about each routing rule, with the default value of <i>default</i> .
Source Port Group (Call Initiator)	Port group from which the call is initiated. This item can be set to a specific port group or '*' which indicates any port group.
CallerID Prefix, CalleeID Prefix	A string of characters at the beginning of the caller/called party number. It can be a specific string consisting of digits 0~9, "[*]", "#", or characters ranges defined by []. '[]' represents a character within the range it defines. Values in [] only can be digits '0~9', "[*]", "#", punctuations '-' and ';'. ('-' is used between two characters to indicates any characters between these two characters. ';' is used to separate characters or characters ranges, representing alternatives.) For example, 057[1-3,6] represents the string 0571, 0572, 0573 or 0576. Also these items can be set to "*" which indicates any string. These two configuration items together with Source Port Group (Call Initiator) specify a routing rule for calls. Note: "[*]" represents DTFM symbol *, while "*" represents any string.
Destination IP, Destination Port	IP address and port number of the remote end to which the call will be routed.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

See Figure 3-78 for the Tel→IP routing rule configuration interface after your configuration. There is a rule displayed with Index 63, Destination IP '192.168.1.101' and Destination Port '5060' (i.e. default IP address and port of the gateway), having no restriction on Call Initiator, CallerID Prefix and CalleeID Prefix, which indicates all the outgoing calls from Tel which conform to the dialing rule will be routed to the gateway.

Tel→IP Routing Rule								
Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	Destination IP	Destination Port	Description	Modify
<input type="checkbox"/>	63	*	*	*	192.168.1.101	5060	default	
Check All Uncheck All Inverse Delete Clear All Add New								
1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total								

Figure 3-78 Tel→IP Routing Rule Configuration Interface

Click **Modify** in Figure 3-78 to modify a routing rule. The configuration items on the Tel→IP routing rule modification interface are the same as those on the **Add New Routing Rule (Tel→IP)** interface. Note that the item **Index** cannot be modified.

To delete a routing rule, check the checkbox before the corresponding index in Figure 3-78 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all routing rules at a time, click the **Clear All** button in Figure 3-78.

See Figure 3-79 for the Tel→IP Routing Rule Configuration Interface under the Character mode. You can edit the routing rule list to add a new one or modify an old one. The exact meaning of each element of the rule is described on the page.

Standard Mode Character Mode

Tel→IP Routing Rule

Note: The routing information contains such fields as Source Port Group, CallerID Prefix, CalleeID Prefix, Destination IP, Destination Port and Description. The priority decreases from top to bottom; adjacent fields are separated by a space. CallerID Prefix, CalleeID Prefix, Destination IP Symbol * indicates any character; Source Port Group set to 0 denotes any port group.

Don't forget to save the configuration after your modification!

0***0 default

1 Items Total

Save

Figure 3-79 Tel→IP Routing Rule Configuration Interface (Character)

3.8 Number Manipulation

Number Manipulation includes four parts: **IP→Tel CallerID**, **IP→Tel CalleeID**, **Tel→IP CallerID** and **Tel→IP CalleeID**. See Figure 3-80.




Figure 3-80 Number Manipulation

3.8.1 IP to Tel CallerID




Figure 3-81 IP→Tel CallerID Manipulation Interface (Standard)

See Figure 3-81 for the IP→Tel CallerID manipulation interface under the Standard mode. A new number manipulation rule can be added by the **Add New** button on the bottom right corner of the list in the above figure. See Figure 3-82 for the IP→Tel CallerID manipulation rule adding interface. You may use the default values of all the configuration items herein.




Figure 3-82 Add IP→Tel CallerID Manipulation Rule

The table below explains the items shown in the above figure.


Item	Description
<i>Index</i>	The unique index of each number manipulation rule, which denotes its priority. A number manipulation rule with a smaller index value has a higher priority. If a call matches several number manipulation rules, it will be processed according to the one with the highest priority.
<i>Description</i>	More information about each number manipulation rule, with the default value of <i>default</i> .
<i>Call Initiator</i>	IP address from where the call is initiated. This item can be set to a specific IP address or "*" which indicates any IP address.

CallerID Prefix, CalleeID Prefix	<p>A string of characters at the beginning of the caller/called party number. It can be a specific string consisting of digits 0~9, "[*]", "#", or character ranges defined by []. '[' represents a character within the range it defines. Values in [] only can be digits '0~9', "[*]", "#", punctuations '-' and ';'. ('-' is used between two characters to indicates any character between these two characters. ';' is used to separate characters or character ranges, representing alternatives.) For example, 057[1-3,6] represents the string 0571, 0572, 0573 or 0576. Also these items can be set to "*" which indicates any string. These two configuration items together with Call Initiator specify a number manipulation rule for calls.</p> <p>Note: "[*]" represents DTFM symbol *, while "*" represents any string.</p>
Stripped Digits from Left	The amount of digits to be deleted from the left end of the number. If the value of this item exceeds the length of the current number, the whole number will be deleted. The default value is 0.
Stripped Digits from Right	The amount of digits to be deleted from the right end of the number. If the value of this item exceeds the length of the current number, the whole number will be deleted. The default value is 0.
Reserved Digits from Right	The amount of digits to be reserved from the right end of the number. Only when the value of this item is less than the length of the current number will some digits be deleted from left; otherwise, the number will not be manipulated. The default value is 20.
Prefix to Add	Designated information to be added to the left end of the current number.
Suffix to Add	Designated information to be added to the right end of the current number.

Note: The number manipulation is performed in 5 steps by the order of the following configuration items: **Stripped Digits from Left**, **Stripped Digits from Right**, **Reserved Digits from Right**, **Prefix to Add** and **Suffix to Add**.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-81 to modify a number manipulation rule. See Figure 3-83 for the IP→Tel CallerID manipulation rule modification interface. The configuration items on this interface are the same as those on the **Add IP→Tel CallerID Manipulation Rule** interface. Note that the item **Index** cannot be modified.



The image shows a configuration window titled "IP->Tel CallerID". It contains several input fields and buttons. The fields are: "Index:" with a dropdown menu showing "63"; "Description:" with a text box containing "default"; "Call Initiator:" with a text box containing "*"; "CallerID Prefix:" with a text box containing "*"; "CalleeID Prefix:" with a text box containing "*"; "Stripped Digits from Left:" with a text box containing "0"; "Stripped Digits from Right:" with a text box containing "0"; "Reserved Digits from Right:" with a text box containing "20"; "Prefix to Add:" with an empty text box; and "Suffix to Add:" with an empty text box. At the bottom, there are two buttons: "Save" and "Close".

Figure 3-83 Modify IP→Tel CallerID Manipulation Rule

To delete a number manipulation rule, check the checkbox before the corresponding index in Figure 3-81 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all number manipulation rules at a time, click the **Clear All** button in Figure 3-81.

See Figure 3-84 for the IP→Tel CallerID Manipulation Interface under the Character mode. You can edit the number manipulation rule list to add a new one or modify an old one. The exact meaning of each element of the rule is described on the page.

Standard Mode | Character Mode

IP->Tel CallerID Number Manipulation Rule

Note: The Number Manipulation Rule contains such fields as Call Initiator, CallerID Prefix, CalleeID Prefix, Delete Digits from Left, Delete Digits from Right, Reserve Digits from Right, Add Prefix, Add Suffix and Description
 The priority decreases from top to bottom; by default, the rule will be inserted to the end after you click 'Add'. If you want to increase its priority, please copy it to the corresponding position.
 Adjacent fields are separated by a space; Symbol * in Call Initiator, CallerID Prefix and CalleeID Prefix indicates any string; Symbol <@#> in Add Prefix and Add Suffix denotes not to add.
 Don't forget to save the configuration after your modification!

***0020 <@#> <@#> default

1Items Total

Save

Figure 3-84 IP→Tel CallerID Manipulation Interface (Character)

3.8.2 IP to Tel CalleeID

The number manipulation process for IP→Tel CalleeID is almost the same as that for IP→Tel CallerID; only the number to be manipulated changes from CallerID to CalleeID. See Figure 3-86 for IP→Tel CalleeID manipulation interface. The configuration items on this interface are the same as those on **IP→Tel CallerID Manipulation Interface** (Figure 3-81).

Standard Mode | Character Mode

IP->Tel CalleeID Number Manipulation Rule

Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	Stripped Digits from Left	Stripped Digits from Right	Reserved Digits from Right	Prefix to Add	Suffix to Add	Description	Modify
<input type="checkbox"/>	63	*	*	*	0	0	20			default	

Check All | Uncheck All | Inverse | Delete | Clear All | Add New

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-85 IP→Tel CalleeID Manipulation Interface(Standard)

Standard Mode | Character Mode

IP->Tel CalleeID Number Manipulation Rule

Note: The Number Manipulation Rule contains such fields as Call Initiator, CallerID Prefix, CalleeID Prefix, Delete Digits from Left, Delete Digits from Right, Reserve Digits from Right, Add Prefix, Add Suffix and Description
 The priority decreases from top to bottom; by default, the rule will be inserted to the end after you click 'Add'. If you want to increase its priority, please copy it to the corresponding position.
 Adjacent fields are separated by a space; Symbol * in Call Initiator, CallerID Prefix and CalleeID Prefix indicates any string; Symbol <@#> in Add Prefix and Add Suffix denotes not to add.
 Don't forget to save the configuration after your modification!

***0020 <@#> <@#> default

1Items Total

Save

Figure 3-86 IP→Tel CalleeID Manipulation Interface (Character)

3.8.3 Tel to IP CallerID

Standard Mode		Character Mode		Tel->IP CallerID Number Manipulation Rule							
Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	Stripped Digits from Left	Stripped Digits from Right	Reserved Digits from Right	Prefix to Add	Suffix to Add	Description	Modify
<input type="checkbox"/>	63	*	*	*	0	0	20			default	

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-87 Tel→IP CallerID Manipulation Interface (Standard)

See Figure 3-87 for the Tel→IP CallerID manipulation interface under the Standard mode. A new number manipulation rule can be added by the **Add New** button on the bottom right corner of the list in the above figure. See Figure 3-88 for the Tel→IP CallerID manipulation rule adding interface. You may use the default values of all the other configuration items herein.

Tel->IP CallerID

Index:

62

Description:

default

Source Port Group:

*

CallerID Prefix:

*

CalleeID Prefix:

*

Stripped Digits from Left:

0

Stripped Digits from Right:

0

Reserved Digits from Right:

20

Prefix to Add:

Suffix to Add:

Figure 3-88 Add Tel→IP CallerID Manipulation Rule

The table below explains the items shown in the above figure.

Item	Description
Index	The unique index of each number manipulation rule, which denotes its priority. A number manipulation rule with a smaller index value has a higher priority. If a call

	matches several number manipulation rules, it will be processed according to the one with the highest priority.
Description	More information about each number manipulation rule, with the default value of <i>default</i> .
Source Port Group (Call Initiator)	Port group from which the call is initiated. This item can be set to a specific port group or '*' which indicates any port group.
CallerID Prefix, CalleeID Prefix	<p>A string of characters at the beginning of the caller/called party number. It can be a specific string consisting of digits 0~9, "[*]", "#", or character ranges defined by []. '[' represents a character within the range it defines. Values in [] only can be digits '0~9', "[*]", "#", punctuations '-' and ','; '-' is used between two characters to indicates any character between these two characters. ',' is used to separate characters or character ranges, representing alternatives.) For example, 057[1-3,6] represents the string 0571, 0572, 0573 or 0576. Also these items can be set to "*" which indicates any string. These two configuration items together with Call Initiator specify a number manipulation rule for calls.</p> <p>Note: "[*]" represents DTFM symbol *, while "*" represents any string.</p>
Stripped Digits from Left	The amount of digits to be deleted from the left end of the number. If the value of this item exceeds the length of the current number, the whole number will be deleted. The default value is 0.
Stripped Digits from Right	The amount of digits to be deleted from the right end of the number. If the value of this item exceeds the length of the current number, the whole number will be deleted. The default value is 0.
Reserved Digits from Right	The amount of digits to be reserved from the right end of the number. Only when the value of this item is less than the length of the current number will some digits be deleted from left; otherwise, the number will not be manipulated. The default value is 20.
Prefix to Add	Designated information to be added to the left end of the current number.
Suffix to Add	Designated information to be added to the right end of the current number.

Note: The number manipulation is performed in 5 steps by the order of the following configuration items: **Stripped Digits from Left**, **Stripped Digits from Right**, **Reserved Digits from Right**, **Prefix to Add** and **Suffix to Add**.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-87 to modify a number manipulation rule. See Figure 3-89 for the Tel→IP CallerID manipulation rule modification interface. The configuration items on this interface are the same as those on the **Add Tel→IP CallerID Manipulation Rule** interface. Note that the item **Index** cannot be modified.

Tel→IP CallerID

Index: 63

Description: default

Source Port Group: *

CallerID Prefix: *

CalleeID Prefix: *

Stripped Digits from Left: 0

Stripped Digits from Right: 0

Reserved Digits from Right: 20

Prefix to Add:

Suffix to Add:

Save
Close

Figure 3-89 Modify Tel→IP CallerID Manipulation Rule

To delete a number manipulation rule, check the checkbox before the corresponding index in Figure 3-87 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all number manipulation rules at a time, click the **Clear All** button in Figure 3-87.

See Figure 3-90 for the Tel→IP CallerID Manipulation Interface under the Character mode. You can edit the number manipulation rule list to add a new one or modify an old one. The exact meaning of each element of the rule is described on the page.

Standard Mode Character Mode

Tel->IP CallerID Number Manipulation Rule

Note: The Number Manipulation Rule contains such fields as Source Port Group, CallerID Prefix, CalleeID Prefix, Delete Digits from Left, Delete Digits from Right, Reserve Digits from Right, Add Prefix, Add Suffix and Description
The priority decreases from top to bottom; Adjacent fields are separated by a space.
Symbol * in Call Initiator, CallerID Prefix and CalleeID Prefix indicates any string; Symbol <@#> in Add Prefix and Add Suffix denotes not to add.
Don't forget to save the configuration after your modification!

0 * * 0 0 20 <@#> <@#> default

1 Items Total

Save

Figure 3-90 Tel->IP CallerID Manipulation Interface (Character)

3.8.4 Tel to IP CalleeID

The number manipulation process for Tel->IP CalleeID is almost the same as that for Tel->IP CallerID; only the number to be manipulated changes from CallerID to CalleeID. See Figure 3-91, Figure 3-92 for the Tel->IP CalleeID manipulation interface. The configuration items on this interface are the same as those on **Tel->IP CallerID Manipulation Interface** (Figure 3-87).

Standard Mode Character Mode

Tel->IP CalleeID Number Manipulation Rule

Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	Stripped Digits from Left	Stripped Digits from Right	Reserved Digits from Right	Prefix to Add	Suffix to Add	Description	Modify
<input type="checkbox"/>	63	*	*	*	0	0	20			default	

Check All Uncheck All Inverse Delete Clear All Add New

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-91 Tel->IP CalleeID Manipulation Interface (Standard)

Standard Mode Character Mode

Tel->IP CalleeID Number Manipulation Rule

Note: The Number Manipulation Rule contains such fields as Source Port Group, CallerID Prefix, CalleeID Prefix, Delete Digits from Left, Delete Digits from Right, Reserve Digits from Right, Add Prefix, Add Suffix and Description
The priority decreases from top to bottom; Adjacent fields are separated by a space.
Symbol * in Call Initiator, CallerID Prefix and CalleeID Prefix indicates any string; Symbol <@#> in Add Prefix and Add Suffix denotes not to add.
Don't forget to save the configuration after your modification!

0 * * 0 0 20 <@#> <@#> default

1 Items Total

Save

Figure 3-92 Tel→IP CalleeID Manipulation Interface (Character)

3.9 System Tools

System Tools is mainly for gateway maintenance. It provides such features as IP modification, data backup and connectivity check. See Figure 3-93 for details.



Figure 3-93 System Tools

3.9.1 Management

Management Parameters

WEB Management

WEB Port

Access Setting Allow All IPs ▼

SYSLOG Parameters

SYSLOG ☒ Yes ☐ No

Server Address

SYSLOG Level INFO ▼

Remote Data Capture Config

Remote Data Capture ☒ Yes ☐ No

CDR Parameters

Send CDR ☒ Yes ☐ No

Server Address

Server Port

Time Parameters

NTP ☒ Yes ☐ No

NTP Server Address

Synchronizing Cycle

Daily Restart ☒ Yes ☐ No

Restart Time 0 h 0 m

System Time ☐ Modify 2018-01-17 15:35:19

Time Zone GMT+8:00 (Beijing, Singapore, Tai ▼

Save
Reset


Figure 3-94 Management Parameters Setting Interface

See Figure 3-94 for the Management Parameters Setting interface. The table below explains the items shown in the above figure.

Item	Description
WEB Port	The port which is used to access the gateway via WEB. The default value is 80.
Access Setting	Sets the IP addresses which can access the gateway via WEB. By default, all IPs are allowed. You can set an IP whitelist to allow all IPs within it to access the gateway freely. Also can set an IP blacklist to forbid all IPs within it to access the gateway.

SYSLOG	Sets whether to enable SYSLOG. It is required to fill in SYSLOG Server Address and SYSLOG Level in case SYSLOG is enabled. By default, SYSLOG is disabled.
Server Address	Sets the SYSLOG server address for log reception.
SYSLOG Level	Sets the SYSLOG level. There are three options: <i>ERROR</i> , <i>WARNING</i> and <i>INFO</i> . The default value is <i>INFO</i> .
Remote Data Capture	是否开启远程抓包服务程序
Send CDR	Sets whether to enable the feature of sending CDR. It is required to fill in Server Address and Server Port in case Send CDR is enabled. By default, Send CDR is disabled.
Server Address	The address of the server to receive CDR.
Server Port	The port of the server to receive CDR.
NTP	Sets whether to enable the NTP time synchronization feature. It is required to fill in NTP Server Address , Synchronizing Cycle and Time Zone in case NTP is enabled. By default, NTP is disabled.
NTP Server Address	Sets the Server address for NTP time synchronization.
Synchronizing Cycle	Sets the cycle for NTP time synchronization. The default value is 3600.
Daily Restart	Sets whether to restart the gateway regularly every day at the preset Restart Time . By default, this feature is disabled.
Restart Time	Sets the time to restart the gateway regularly.
System Time	The system time. Check the checkbox before Modify and change the time in the edit box.
Time Zone	The time zone of the gateway.

3.9.2 Configuration File



SMGConfig.ini

Config File

```
[Version]
GWSvrV=1.2.12_20130719
WebV=1.2.11_20130719
CpldV=0.3
[DbgLog]
LogLevel=3
LogCreatePeriod=24
LogMaxPeriod=4
LogMaxPeriodSaved=5
LogOverWrite=1
LogDirectory=/dev/shm/shcti
LogType=3
[WebCtrl]
LocalAddress=127.0.0.1
LocalPort=1001
MailAlarm=1
MailUser=asd@sfd.com
MailPassword=
SMTPAddress=
MailReceivers=
ChInfoPath=/usr/local/SMG/ch.data.php
PopInfoPath=/usr/local/SMG/pop.data.php
[UserInfo]
UserName=BqtTPNLUr/23x1wC/w
Pwd=BqtTPNLUr/23x1wC/w
[Monitor]
LocalAddress=127.0.0.1
LocalPort=1002
AutoExec=1
CheckSvrThread=1
ExecPath=E:\recorder\Recorder\Output\BIN\
UpgradeExecPath=/usr/local/apache/htdocs/RecUpgrade
[INIPath]
ShConfig=ShConfig.ini
[DBPARAM]
```


Save Reset

Note: You shall restart system to validate the modified configuration file!

Figure 3-95 Configuration File Interface

See Figure 3-95 for the Configuration File interface, including two files: SMGConfig.ini and ShConfig.ini. You can check and modify the items in these configuration files through this interface. Configurations about the gateway server, such as route rules, number manipulation and so on, are included in SMGConfig.ini; configurations about the board are included in ShConfig.ini. You can modify these configurations on the interface directly, and then click **Save** to save the above settings into the gateway or click **Reset** to restore the configurations.

3.9.3 Network



The image shows a 'Network Settings' window. It has a blue header bar with the title 'Network Settings'. Below the header, there are two sections: 'LAN 1' and 'LAN 2'. The 'LAN 1' section contains several configuration fields: 'Network Type' (a dropdown menu set to 'Static'), 'IP Address (I)' (a text box with '192.168.1.101'), 'Subnet Mask (U)' (a text box with '255.255.255.0'), 'Default Gateway (D)' (a text box with '192.168.1.1'), 'DNS Server (P)' (a text box with '0.0.0.0'), and 'Speed and Duplex Mode' (a dropdown menu set to 'Automatic Detection'). The 'LAN 2' section has a single checkbox labeled 'Enable' which is currently unchecked. At the bottom of the window, there are two blue buttons: 'Save' and 'Reset'. Below these buttons, a note states: 'Note: The service will be restarted automatically after saving the current setting. Please log in again using your new IP address if the IP address has been modified!'.

Figure 3-96 Network Settings Interface

See Figure 3-96 for the network settings interface. A gateway has two LANs, each of which can be configured with independent network type, IP address, subnet mask, default gateway and DNS server. Network Type has three options: Static, DHCP and PPPoE. If PPPoE is used, it is necessary to enter the username and the password of the network. By default, LAN1 is enabled and LAN2 is disabled.

Note:

1. The values of the *IP address*, *Subnet Mask*, *Default Gateway* and *DNS Server* shown in Figure 3-96 are all factory settings. The IP Address for LAN 1 and that for LAN 2 cannot be in the same segment.
2. LAN2 is disabled by default for the gateway Version 1.3.3 or above. If you want to use LAN2, please log in the gateway through LAN1 first, and then modify the network settings to enable LAN2.

After configuration, click **Save** to save the above settings into the gateway or click **Reset** to restore the configurations. After changing the IP address, you shall log in the gateway again using your new IP address.

3.9.4 Upgrade

Current Version	
Serial Num	000000057
WEB	Version 1.7.1_Release2017042109
Service	Version 1.7.1_Release2017042109
U-boot	Version Nov 24 2014 - 09:24:52
Kernel	Version #187 PREEMPT Tue Jan 19 10:35:29 CST 2016
Product Type	1032(RJ11)

Select an Update File

Figure 3-97 Upgrade Interface

See Figure 3-97 for the upgrade interface where you can upgrade the WEB, gateway service, kernel and firmware to new versions. Select the upgrade package “*.tar.gz” (The gateway will do MD5 verification before upgrading and will not start to upgrade until it passes the verification.) via **Browse...** and click **Update**. Then the file uploading interface will appear. See Figure 3-98.

Current Version	
Serial Num	000000057
WEB	Version 1.7.1_Release2017042109
Service	Version 1.7.1_Release2017042109
U-boot	Version Nov 24 2014 - 09:24:52
Kernel	Version #187 PREEMPT Tue Jan 19 10:35:29 CST 2016
Product Type	1032(RJ11)

Select an Update File

18% 3353kb/s

The file is uploading. Please do not leave this page!.....

Upgrade Information

start upload upgrade file...

Figure 3-98 File Uploading Interface

After a successful uploading of the file, the gateway will start to upgrade the system. See Figure 3-99 and you can learn the detailed upgrading information from the upgrade information box at the bottom.

Current Version	
Serial Num	000000057
WEB	Version 1.7.1_Release2017042109
Service	Version 1.7.1_Release2017042109
U-boot	Version Nov 24 2014 - 09:24:52
Kernel	Version #187 PREEMPT Tue Jan 19 10:35:29 CST 2016
Product Type	1032(RJ11)

Select an Update File

Upload completion!

10%

System updating, please do not leave this page!.....

Upgrade Information

start upload upgrade file...
 decompressing the upgrade package...

Figure 3-99 System Upgrading Interface

Note that clicking **Reset** can only delete the selected update file but not cancel the operation of **Update**.

Note: Please contact our technicians if you need to downgrade the gateway to an old version. An improper operation may cause unexpected problems.

3.9.5 Signaling Capture

Figure 3-100 Signaling Capture Interface

See Figure 3-100 for the Signaling Capture interface, including two parts: Packet Capture and Data Recording. Packet capture contains Signaling Packet Capture and RTP Packet Capture. You can select either of them to start the capture according to your requirement. Click **Start** to start capturing packets. Click **Stop** to stop the capture and download the captured packets.

Data Recording will execute the recording task on the set port with the set recording time length. You can choose 'Recording of Connected IP Channels' or 'Recording before Echo Cancellation'. Click **Start** to start recording data (consecutively recording 300 seconds at most) on the corresponding port with the corresponding time length. Click **Stop** to stop the recording and click **Download File** to download the recorded data.

3.9.6 Call Log

Figure 3-101 Call Log Interface




Figure 3-102 SIP Log Interface

See Figure 3-101, Figure 3-102 for the Call Log interface. Click the checkbox before **Enable Call Log** to enable the call log feature, including **Call Log** and **SIP Log**. **Call from IP Channel** displays the call log information generated on all IP channels, and **Call from Port** displays the call log information generated on the port you select. All the SIP related information will be displayed in **SIP Log**.

3.9.7 Operation Log




Figure 3-103 Operation Log Interface

See Figure 3-103 for the Operation Log interface, which is used to check the operation records on WEB. Click **Refresh** to refresh the log; click **Clear All** to clear all the operation logs and click **Download** to download the logs.

Note: The sign <@#> here means the configuration item is unconfigured.

3.9.8 Backup & Upload




Figure 3-104 Backup & Upload Interface

See Figure 3-104 for the backup and upload interface. To back up the configuration file to your PC, just click **Backup**. To upload a configuration file, select it via **Browse...** and click **Upload**.





Figure 3-105 Backup & Upload & Prompt Interface


Click **OK** on the prompt box (Figure 3-105) to upload the configuration file to the gateway. Now the prompt information 'The gateway service is restarting, please do not leave this page' appears. See Figure 3-106. The gateway will overwrite the current configurations with the uploaded data after restart. Click **Cancel** to cancel this upload directly.



The interface is divided into two main sections: 'Data Backup' and 'Data Upload'. The 'Data Backup' section has a 'Backup' button. The 'Data Upload' section has a 'Config File' input field with the path 'C:\Users\Administrator\Desktop\hasp\readme', a 'Browse...' button, and an 'Upload' button. A status message at the bottom states: 'The gateway service is restarting. Please do not leave this page' followed by a progress bar.

Figure 3-106 Configuration File Uploading Interface

3.9.9 Factory Reset




The 'Factory Reset' interface contains a single 'Reset' button. A message above the button says: 'Click the button 'Reset' below to restore to factory settings.'

Figure 3-107 Factory Reset Interface

See Figure 3-107 for the factory reset interface. Click **Reset** to restore all configurations on the gateway to factory settings.

3.9.10 System Monitor



The 'System Monitor' configuration interface includes the following settings:

- Watchdog:** ☒ Enable
- Dog Feeding Interval (s):**
- Automatically Restart the Service if Undetected:** ☒ Enable
- Threshold to Judge Heartbeat Loss for Service(s):**


At the bottom, there are 'Save' and 'Reset' buttons.

Figure 3-108 System Monitor Configuration Interface

See Figure 3-108 for the System Monitor Configuration interface. Watchdog is a timing reset system used to avoid application crash. You can set the dog feeding interval when this feature is enabled. The feeding interval is calculated by s, with the value range of 1~15s. By default, this feature is enabled with the default value of 5s. As the feature 'Automatically restart the service if undetected' is enabled, the service application will restart automatically if it is not detected by the gateway guard application. By default, this feature is enabled. Threshold to Judge Heartbeat Loss for Service is used to judge whether the gateway receives the heartbeat packets from the service

during the set time, if not, it is considered that the gateway service has been disconnected. It is calculated by s, with the value range of 20~120s and the default value of 60s.

3.9.11 Centralized Manage



The image shows a web-based configuration interface titled "Centralized Manage". It contains several settings:

- Centralized Manage:** A checkbox labeled "Enable" which is checked.
- Management Platform:** A dropdown menu currently showing "DCMS".
- Server Address *:** A text input field containing "127.0.0.1".
- Company Name *:** An empty text input field.
- Authorization Code *:** An empty text input field.
- Gateway Description:** An empty text input field.
- Advanced:** A checkbox labeled "Enable" which is checked.
- Enable Lock Feature Once Successfully Connected:** A checkbox labeled "Enable" which is checked.
- Lock Parameter:** Two checkboxes: "IP Address" (unchecked) and "Registrar Server" (checked).
- Working Status:** A label indicating the status is "Disabled".

At the bottom of the interface are three buttons: "Save", "Reset", and "Download MIB".

Figure 3-109 Centralized Manage Setting Interface

See Figure 3-109 for the Centralized Manage Setting interface. The gateway can register to a centralized management platform and accept the management of the platform. The table below explains the items shown in above figures.

Item	Description
Management Platform	Select a management platform for the gateway to register, including two options: DCMS and Others.
DCMS Server Address	The address of the server in which the DCMS locates, It can be IP or a domain name valid only when DCMS is selected. Note: To configure the domain name, the DNS should be already configured and the corresponding domain name must be analyzable.
Company Name	The name used to register the gateway to Synway DCMS, valid only when DCMS is selected.
Authorization Code	The authorization code is used for the connection verification. A device can connect to the DCMS successfully only after it passes the verification. This item is valid only when DCMS is selected.

Gateway Description	The description displayed on Synway DCMS after the gateway is registered to Synway DCMS, giving an easy identification of the gateway in device grouping. This item is valid only when DCMS is selected.
Enable Lock Feature Once Successfully Connected	Once this feature is enabled, you can lock the device according to the corresponding parameters. This item is valid only when DCMS is selected.
IP Address	Once this feature is enabled, you are required to fill in the authorization code while modifying the information related to the IP address in the Network interface. This item is valid only when DCMS is selected.
Registrar Server	Once this feature is enabled, you are required to fill in the authorization code while modifying the address and port of the registrar server in the SIP Settings interface. This item is valid only when DCMS is selected.
Working Status	The status of the connection between the gateway and the centralized management server. This item is valid only when DCMS is selected.
Centralized Management Protocol	Set the centralized management protocol. It only supports SNMP currently.
SNMP Version	Set the version of SNMP, three options available: V1, V2 and V3, with the default value of V2. This item is valid only when Others is selected.
Monitoring Port	Monitoring Port for SNMP on the gateway. This item is valid only when Others is selected.
Community String	Community string used for information acquisition.
Account	The account of SNMP, valid only when the SNMP version is set to V3.
Grade	The grade of SNMP, three options available: Neither authenticated nor encrypted, Authenticated but not encrypted and Authenticated and encrypted, with the default value of <i>Neither authenticated nor encrypted</i> . It is valid only when the SNMP version is set to V3.
Authentication Password	The authentication password required to enter when the item Grade is set to Authenticated but not encrypted or Authenticated and encrypted.
Encryption Password	The encryption password required to enter when the item Grade is set to Authenticated and encrypted.

3.9.12 Access Control




Figure 3-110 Access Control List Interface

See Figure 3-110 for the Access Control List interface. Once you add a piece of command to ACL, the network flow will be restricted: only the particular devices are allowed to visit the gateway and only the data packages on the designated ports can be forwarded. Click **Add New** to add a new piece of command. See Figure 3-111.

Figure 3-111 Add Access Control Command Interface

Input a piece of command into the Command item and click **Save** to save the settings to the gateway. Click **Close** to cancel your settings. After that, click **Apply** to make the new command valid.

Click **Modify** in Figure 3-110 to modify a command. See Figure 3-112 for the Access Control Command Modification interface. The configuration items on this interface are the same as those on the **Add Access Control Command** interface. Note that the item **Index** cannot be modified.


Figure 3-112 Access Control Command Modification Interface

To delete an Access Control Command, check the checkbox before the corresponding index in Figure 3-110 and click the **Delete** button, and then click the **Apply** button to make the deleted command invalid. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all access control commands at a time, click the **Clear All** button in Figure 3-110.

Note:

1. Currently, only the command iptables is supported by the gateway.
2. After you add, modify or delete a command manually, don't forget to click the **Apply** button to make your settings valid. However, in case the gateway restarts or the configuration is leading-in, the command will get valid automatically without the need for you to click the **Apply** button.

3.9.13 Call Test



The screenshot shows the 'Call Test' interface. At the top, there's a title bar 'Call Test'. Below it, the 'Test Type' is set to 'IP Call out'. There are input fields for 'Local Alias', 'Local SIP Account', 'Remote Alias', 'Remote SIP Account', 'Called IP Address', and 'Called Port'. A 'DTMF(RFC2833 Unsupported)' field is also present, followed by a 'Send' button. Below this is a section for 'Add or Modify Invite Header Field' with a table structure. The table has two columns: 'Field Name' and 'Field Content'. There are five rows, each with an 'Enable' checkbox, a text input for the field name, and a text input for the field content. At the bottom of this section are 'Start', 'Stop', and 'Clear' buttons. The bottom part of the interface is labeled 'Signaling Trace' and contains a large empty text area.

Field	Field Name	Field Content
<input type="checkbox"/> Enable		
<input type="checkbox"/> Enable		
<input type="checkbox"/> Enable		
<input type="checkbox"/> Enable		
<input type="checkbox"/> Enable		

Figure 3-113 Call Test Interface


See Figure 3-113 for the Call Test interface. A call test can be initiated from the gateway on a designated IP address to check the connection status between them. The table below explains the configuration items shown in the above figure.

Item	Description
------	-------------

Test Type	There are two types of call tests: PSTN Call out and IP Call out .
Channel	The channel on which the call test will be performed.
CalledID	The called party number of the call from the PSTN channel.
Delay after Dial	The time from the dial behavior on the PSTN channel to the call's going out.
Local Alias	The content of displayname in the from field of the invite message during the call out from the IP channel.
Local SIP Account	The content of username in the from field of the invite message during the call out from the IP channel.
Remote Alias	The content of displayname in the to field of the invite message during the call out from the IP channel.
Remote SIP Account	The content of username in the to field of the invite message during the call out from the IP channel.
Called IP Address	The called IP address of the call out from the IP channel.
Called Port	The called port of the call out from the IP channel.
DTMF	The DTMF digits sent by the IP channel after starting a call.
Add or Modify Invite Header Field	The field name and content added or modified in the message header during the call out from the IP channel.
Signaling Trace	Displays the call test process.

After configuration, click **Start** to execute the call test; click **Stop** to terminate it immediately; click **Clear** to clear the records of call tests.

3.9.14 PING Test



The image shows a 'Ping Test' window with a blue title bar. Inside, there are four configuration fields: 'Source IP Address' with a dropdown menu showing 'LAN 1: 192.168.1.101', 'Destination Address' with a text box containing '127.0.0.1', 'Ping Count (1-100)' with a text box containing '4', and 'Package Length (56-1024 bytes)' with a text box containing '56'. Below these fields are two blue buttons labeled 'Start' and 'End'. At the bottom, there is an 'Info' section with a large empty rectangular box for displaying test results.

Figure 3-114 Ping Test Interface

See Figure 3-114 for the Ping Test interface. A Ping test can be initiated from the gateway on a designated IP address to check the connection status between them. The table below explains the configuration items shown in the above figure.

Item	Description
Source IP Address	Source IP address where the Ping test is initiated.
Destination Address	Destination IP address or domain name on which the Ping test is executed.
Ping Count	The number of times that the Ping test should be executed. Range of value: 1~100.
Package Length	Length of the data package used in the Ping test. Range of value: 56~1024 bytes.
Info	The information returned during the Ping test, helping you to learn the network connection status between the gateway and the destination address.

After configuration, click **Start** to execute the Ping test; click **End** to terminate it immediately.

3.9.15 TRACERT Test


The image shows a software window titled "Tracert Test". It contains three input fields: "Source IP Address" with a dropdown menu showing "LAN 1: 192.168.1.101", "Destination Address" with a text box containing "127.0.0.1", and "Maximum Jumps (1-255)" with a text box containing "30". Below these fields are two buttons, "Start" and "End". At the bottom, there is a section labeled "Info" with a large empty rectangular box for displaying test results.


Figure 3-115 Tracert Test Interface

See Figure 3-115 for the Tracert test interface. A Tracert test can be initiated from the gateway on a designated IP address to check the routing status between them. The table below explains the configuration items shown in the above figure.

Item	Description
Source IP Address	Source IP address where the Tracert test is initiated.
Destination Address	Destination IP address on which the Tracert test is executed.
Maximum Jumps	Maximum number of jumps between the gateway and the destination address which are returned by the Tracert test. Range of value: 1~255.
Info	The information returned during the Tracert test, helping you to learn the detailed information about the jumps between the gateway and the destination address.

After configuration, click **Start** to execute the Tracert test; click **End** to terminate it immediately.

3.9.16 Change Password




The 'Change Password' interface features a light blue header bar with the title 'Change Password'. Below the header, there are five input fields arranged vertically. The first field is labeled 'Current Username' and contains the text 'admin'. The second field is labeled 'Current Password'. The third field is labeled 'New Username'. The fourth field is labeled 'New Password'. The fifth field is labeled 'Confirm New password'. At the bottom of the interface, there are two blue buttons: 'Save' and 'Reset'.

Figure 3-116 Password Changing Interface

See Figure 3-116 for the Password Changing interface where you can change your username and password of the gateway. Enter your current password, your new username and new password, and then confirm your new password. After configuration, click **Save** to apply your new username and password or click **Reset** to restore the configurations. After changing the username and password, you are required to log in again.

3.9.17 Restart



The 'Service/System Restart' interface is divided into two sections. The top section, titled 'Service Restart', contains the text 'Click the button 'Restart' to restart the service.' next to a blue 'Restart' button. To the right of this is a checkbox labeled 'Generate a Dump File'. Below this, it says 'Click the button 'download' to download the dump file.' next to a blue 'download' button. The bottom section, titled 'System Restart', contains the text 'Click the button 'Restart' to restart the system.' next to a blue 'Restart' button. To the right of this is another checkbox labeled 'Generate a Dump File'.

Figure 3-117 Service/System Restart Interface

See Figure 3-117 for the Restart interface. Click **Restart** on the service restart interface to restart the gateway service or click **Restart** on the system restart interface to restart the whole gateway system. A dump file will be generated each time you restart the service or the system. Click **download** and you can download it to help troubleshoot issues.

Appendix A Technical Specifications

Dimensions

440×44×267 mm³

Weight

About 4 kg

Environment

Operating temperature: 0℃—45℃

Storage temperature: -20℃—85℃

Humidity: 8%— 90% non-condensing

Storage humidity: 8%— 90% non-condensing

LAN

Amount: 2 (10/100 BASE-TX (RJ-45))

Self-adaptive bandwidth supported

Auto MDI/MDIX supported

FXS/FXO Port

Amount: 8/16/32

Type: RJ11, RJ21, RJ45

Maximum transmission distance: 1500m

Impedance

Input impedance:

≥1MΩ/500V DC; ≥10kΩ/1000V AC

Insulation resistance of telephone line from PC:

≥2MΩ/500V DC

Telephone line impedance: Compliant with the national standard impedance for three-component network

Console Port

Amount: 1 (RS-232)

Baud rate: 115200bps

Connector: RJ45 to DB-9 Connector

Data bits: 8 bits

Stop bit: 1 bit

Parity unsupported

Flow control unsupported

Note: Follow the above settings to configure the serial port; or it may work abnormally.

Power Requirements

Input power: 100~240V AC

Maximum power consumption: ≤50W

Signaling & Protocol

SIP signaling

Supported protocol: SIP V1.0/2.0, RFC3261

Audio Encoding & Decoding

G.711A 64 kbps

G.711U 64 kbps

G.729A/B 8 kbps

G.723 5.3/6.3 kbps

G.722 64 kbps

AMR 4.75/5.15/5.90/6.70/7.40/7.95/10.20/12.20 kbps

iLBC 13.3/15.2 kbps

SILK(16K) 20 kbps

OPUS(16K) 20 kbps

SILK(8K) 12 kbps

OPUS(8K) 12 kbps

Sampling Rate

8kHz

Appendix B Troubleshooting

Q1. What to do if I forget the IP address of the SMG gateway?

There are two ways to get the IP address:

- 1) Long press the Reset button on the gateway to restore to factory settings. The default IP address is as follows:
LAN1: 192.168.1.101
LAN2 (disabled by default): 192.168.0.101
- 2) Dial the corresponding function key through an FXS port to query the IP address. See [3.5.8 Function Key](#) for more details.

Q2. The SMG gateway only supports routing on two directions, i.e. Tel→IP and IP→Tel. What to do if I want to make a Tel→Tel call?

By default, you can make Tel→Tel calls without any routing configuration.

If you need to make Tel→Tel calls in a specific way, try via the routing of Tel→IP→IP→Tel. See below for detailed introductions.

Provided you are going to initiate a call from Port Group 1 to Port Group 2; the IP address and port number of your gateway are 192.168.1.101 and 5060 respectively.

- a) Add a new routing rule on the Tel→IP routing rule configuration interface. Select a port group (e.g. **Port Group 1**) as 'Source Port Group' to initiate the call and fill in 'Destination IP' and 'Destination Port' with the gateway's IP address (e.g. LAN1: **192.168.1.101**) and port number (e.g. **5060**). Then the call initiated from the station corresponding to Port Group 1 will be routed to the gateway.
- b) Add a new routing rule on the IP→Tel routing rule configuration interface. Fill in 'Source IP' with the gateway's IP address (e.g. LAN1: **192.168.1.101**) and select a port group (e.g. **Port Group 2**) as 'Destination Port Group' to be called. Then if the IP end of the gateway calls itself, the station corresponding to Port Group 2 will ring.
- c) Finishing the above configurations, you can perform a Tel→Tel call from Port Group 1 to Port Group 2 simply by the way you make a Tel→IP call.

Q3. Does call forwarding involve routing and number manipulation?

Case 1: If the forwarding number is the number of the gateway port. There is no need to use routing and number manipulation rules. Because the gateway will find the corresponding number according to the forwarding number and make a call.

Case 2: If the forwarding number is not the number of the gateway port. It is required to use routing and number manipulation rules. A call forward procedure can be regarded as a Tel→IP call. It uses the routing rules and number manipulation rules in the same way as the Tel→IP call. A complete call forward is performed as follows:

- a) An incoming IP call to the gateway rings the port which matches the IP→Tel routing and number manipulation rules and obtains a new CallerID.
- b) Then the gateway uses the newly obtained CallerID and the call forward number, via the Tel→IP routing and number manipulation rules, to make another call from the port to a remote IP address.

Q4. In what cases can I conclude that the SMG gateway is abnormal and turn to Synway's

technicians for help?

- a) During runtime, the run indicator does not flash or the alarm indicator lights up or flashes, and such error still exists even after you restart the device or restore it to factory settings.
- b) Voice problems occur during call conversation, such as that one party or both parties cannot hear the voice or the voice quality is unacceptable.
- c) The port of the gateway is well connected, but the channel indicator never lights up after the gateway startup or the color it lights up does not comply with the actual state or port type.

Other problems such as inaccessible calls, failed registrations, incorrect numbers and abnormal dialing operations on the FXS port are probably caused by configuration errors. We suggest you refer to [Chapter 3 WEB Configuration](#) for further examination. If you still cannot figure out or solve your problems, please feel free to contact our technicians.

Q5. What to do if I cannot enter the WEB interface of the SMG gateway after login?

This problem may happen on some browsers. To settle it, follow the instructions here to configure your browser. Enter 'Tools > Internet Options > Security Tab', and add the current IP address of the gateway into 'Trusted Sites'. If you changes the IP address of the gateway, add your new IP address into the above settings too.

Q6. How to configure the features Communication without Power and Communication without Network for the SMG analog gateway?

The feature **Communication without Power** is implemented with the help of composite modules equipped in the gateway. Once the power to the device is cut off, the station which is linked with the FXS port on the composite module and the trunk which is linked with the FXO port on the same module will connect to each other directly and keep the good communications between phones and networks. What you need to do is just to configure the composite module properly at your purchase of our gateway.

The feature **Communication without Network** is implemented via the WEB management over the analog gateway. It will automatically route a call to the proper port in case of network failure or call timeout.

Refer to [Q2](#) in this chapter for detailed information.

Q7. How many ports can be rung by turns according to the Ringing by Turns rule?

According to the 180s ringing timeout limit in RFC3261 protocol, the time used for ringing all ports by turns cannot exceed 180s. Therefore, based on the minimum timeout 15s for each port in the ringing queue, the maximum number of ports for ringing by turns is 12.

For example, if you set **Timeout for Ringing by Turns** to 20s, the maximum number of ports for ringing by turns should be $180s/20s=9$; if you set **Timeout for Ringing by Turns** to 30s, the maximum number of ports for ringing by turns should be $180s/30s=6$.

Q8. Is there any cell-phone APP can make calls to the SMG gateway?

Yes. Linphone is a soft SIP phone that is supported by multiple platforms, such as Linux, Windows, iOS, Android, etc. It must be registered to the SIP registrar server before dialing to other SIP devices or PSTN telephones,

Q9. Does the SMG gateway support fax?

Yes. Currently the SMG gateway supports two fax modes: T.38 and Pass-Through.

Q10. Which RTP codecs are supported by the SMG gateway?

At present, the supported RTP codecs are: G.711A, G.711u, G.729, G.723, G.722, AMR, iLBC, SILK(16K), OPUS(16K), SILK(8K) and OPUS(8K).

Appendix C Technical/sales Support

Thank you for choosing Synway. Please contact us should you have any inquiry regarding our products. We shall do our best to help you.

Headquarters

Synway Information Engineering Co., Ltd

<http://www.synway.net/>

9F, Synway D&R Center, No.3756, Nanhuan Road, Binjiang District, Hangzhou, P.R.China, 310053

Tel: +86-571-88860561

Fax: +86-571-88850923

Wechat QR Code: Scan the QR code below to add us on Wechat.



Technical Support

Tel: +86-571-88864579

Mobile: +86-18905817070

Email: techsupport@sanhuid.com

Email: techsupport@synway.net

MSN: synway.support@hotmail.com

Sales Department

Tel: +86-571-88860561

Tel: +86-571-88864579

Fax: +86-571-88850923

Email: sales@synway.net