



Synway SMG Series Wireless Gateway

SMG4004

SMG4008

SMG4016

SMG4032

Wireless Gateway

User Manual

Version 1.8.0

Synway Information Engineering Co., Ltd

www.synway.net

Content

Content	i
Copyright Declaration	iii
Revision History	iv
Chapter 1 Product Introduction.....	1
1.1 Typical Application	3
1.2 Feature List.....	3
1.3 Hardware Description	4
1.4 Indicator Info	7
Chapter 2 Quick Guide.....	9
Chapter 3 WEB Configuration	12
3.1 System Login	12
3.2 Operation Info	13
3.2.1 System Info	13
3.2.2 Port State.....	14
3.2.3 Call Count.....	15
3.2.4 SIP Message Count	18
3.3 Quick Config	19
3.4 VoIP Settings	21
3.4.1 SIP.....	22
3.4.2 SIP Compatibility	24
3.4.3 SIP Station.....	26
3.4.4 SIP Server	28
3.4.5 NAT Setting	30
3.4.6 Media.....	32
3.5 Advanced Settings.....	34
3.5.1 Network	35
3.5.2 System Param.....	36
3.5.3 Service Config.....	38
3.5.4 Dialing Rule	40
3.5.5 Function Key	43
3.5.6 Cue Tone	44
3.5.7 Color Ring	44
3.5.8 QoS	46
3.5.9 Tone Generator	47
3.5.10 CDR Query.....	48
3.5.11 VPN.....	48
3.6 Wireless Settings.....	49
3.6.1 Basic Parameters	51
3.6.2 Wireless Param	56
3.6.3 Call Forwarding	58
3.6.4 Short Message	59
3.6.5 IMEI	62

3.6.6	USSD.....	63
3.6.7	Email.....	64
3.6.8	SIM Card	66
3.6.9	PIN Manage	67
3.6.10	BS Select.....	69
3.6.11	Networking Settings	71
3.6.12	AMD.....	73
3.6.13	Hidden CallerID.....	74
3.7	Call Management.....	75
3.7.1	Balance	75
3.7.2	Port Timer.....	77
3.7.3	Name List Timer.....	79
3.7.4	Tel to IP Auto Route	81
3.7.5	Blacklist	82
3.7.6	SMS Count.....	83
3.7.7	Auto Function	84
3.7.8	Port Charge.....	85
3.8	Port Settings	87
3.8.1	Port.....	87
3.8.2	Port Group.....	91
3.9	Route Settings	94
3.9.1	Routing Parameters	94
3.9.2	IP to Tel/IP	95
3.9.3	Tel to IP	97
3.10	Number Manipulation.....	99
3.10.1	IP to Tel/IP CallerID	100
3.10.2	IP to Tel/IP CalleeID	104
3.10.3	Tel to IP CallerID	105
3.10.4	Tel to IP CalleeID.....	109
3.11	System Tools	110
3.11.1	Upgrade.....	110
3.11.2	Signaling Capture.....	112
3.11.3	Data Recording	113
3.11.4	Call Log	113
3.11.5	Operation Log.....	114
3.11.6	Change Password.....	115
3.11.7	Backup & Upload	115
3.11.8	Factory Reset.....	116
3.11.9	Restart.....	117
3.11.10	System Monitor	117
3.11.11	Centralized Manage	118
3.11.12	PING Test.....	119
3.11.13	TRACERT Test.....	120
3.11.14	Wireless Network Test.....	121
3.11.15	Access Control	122
3.11.16	Device Lock.....	123
Appendix A Technical Specifications		124
Appendix B Troubleshooting		125
Appendix C About VPN		126
Appendix D Technical/sales Support		130

Copyright Declaration

All rights reserved; no part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, without prior written permission from Synway Information Engineering Co., Ltd (hereinafter referred to as 'Synway').

Synway reserves all rights to modify this document without prior notice. Please contact Synway for the latest version of this document before placing an order.

Synway has made every effort to ensure the accuracy of this document but does not guarantee the absence of errors. Moreover, Synway assumes no responsibility in obtaining permission and authorization of any third party patent, copyright or product involved in relation to the use of this document.

Revision History

Version	Date	Comments
Version 1.0.0	2015-08	Initial publication
Version 1.1.0	2015-11	New Revision
Version 1.2.0	2016-1	New Revision
Version 1.3.0	2016-4	New Revision
Version 1.4.0	2016-6	New Revision
Version 1.5.0	2016-12	New Revision
Version 1.6.0	2017-03	New Revision
Version 1.7.0	2017-05	New Revision
Version 1.8.0	2017-10	New Revision

Note: Please visit our website <http://www.synway.net> to obtain the latest version of this document.

Chapter 1 Product Introduction

Thank you for choosing Synway SMG Series Wireless Gateway!

The Synway SMG series wireless gateway products (hereinafter referred to as ‘wireless gateway’), as a part of the Synway gateway products, works mainly for connecting the wireless network with the VoIP network. It adopts an updated VoIP processor and the wireless module, uses the push-pull SIM card socket for easy replacement of the SIM card, quite advanced in technology. So far, only SMG4008 is available.

See below table for the modules of SMG series wireless gateway:

Series	Module & Ports	Supported Frequency Band/Code
GSM Gateway	SMG4032-32G	GSM: 850/900/1800/1900MHz
	SMG4016-16G	
	SMG4008-8G	
	SMG4004-4G	
WCDMA Gateway	SMG4016-16W	GSM: 900/1800MHz UMTS: 900/2100MHz
	SMG4008-8W	
	SMG4004-4W	
WCDMA-A Gateway	SMG4032-32WA	GSM: 850/900/1800/1900MHz UMTS: 850/1900MHz
	SMG4016-16WA	
	SMG4008-8WA	
	SMG4004-4WA	
WCDMA-T Gateway	SMG4016-16WT	GSM: 850/900/1800/1900MHz UMTS: 850/2100MHz
	SMG4008-8WT	
	SMG4004-4WT	
WCDMA-Z Gateway	SMG4016-16WZ	GSM: 850/900/1800/1900MHz UMTS: 850/900/1900/2100MHz
	SMG4008-8WZ	

	SMG4004-4WZ	
CDMA Gateway	SMG4032-32C	CDMA: CDMA 2000 800MHz
	SMG4016-16C	
	SMG4008-8C	
	SMG4004-4C	
LTE Gateway	SMG4032-32LE	FDD LTE: B1/B3/B5/B7/B8/B20 TDD LTE: B38/B40/B41 WCDMA: B1/B5/B8 GSM: B3/B8
	SMG4016-16LE	
	SMG4008-8LE	
	SMG4004-4LE	
	SMG4032-32LC	FDD LTE: B1/B3 TDD LTE: B38/B39/B40/B41 TDSCDMA: B34/B39 WCDMA: B1 CDMA2000 1X/EVDO: BC0 GSM: 900/1800MHz
	SMG4016-16LC	
	SMG4008-8LC	
	SMG4004-4LC	

Table 1-1 Model List

1.1 Typical Application




Figure 1-1 Typical Application

1.2 Feature List

Basic Features	Description
TDM Call	Call initiated from TDM to IP, via routing and number manipulation to obtain the called IP address.
IP Call	Call initiated from IP to TDM, via routing and number manipulation to obtain the call destination.
Number Manipulation	Peels off some digits of a phone number from left/right, or adds a prefix/suffix to a phone number.
Call Forward	Three options available: Unconditional, Busy, No Reply and Unreachable.
CID	Displays the CallerID.
Echo Cancellation	Provides the echo cancellation feature for a call conversation over the wireless port.

TDM/VoIP Routing	Sets a routing path: from IP to TDM or from TDM to IP.	
Simultaneous Register to Multiple Servers	Registers the gateway to a master registrar server and a spare registrar server simultaneously.	
IMS Network	Registers the gateway to a server under IMS network.	
Custom IVR Recording	Provides the interface to customize the IVR Recording.	
White/Black List	Allows the setting of the white/black list for WEB access.	
Voice Gain Adjust	Supports the gain adjustment for the received or sent voice.	
Receive or Send SMS/USSD	Supports the SMS sending and receiving, as well as the USSD request and response.	
Auto Select Network	Supports the auto identification and selection of the network operator.	
SMS CODEC	Two options available: ASCII and UCS2.	
Signaling & Protocol	Description	
SIP Signaling	Supported protocol: SIP V1.0/2.0, RFC3261.	
Voice	CODEC	G.711A, G.711U, G.729A/B, G.723, G.722, AMR, iLBC
	DTMF Mode	RFC2833, SIP INFO, INBAND
Network	Description	
Network Protocol	Supported protocol: TCP/UDP, HTTP, ARP/RARP, DNS, NTP, TFTP, TELNET, STUN.	
Static IP	IP address modification support.	
DHCP	IP address dynamic allocation support.	
DNS	Domain Name Service support.	
Security	Description	
Admin Authentication	Supports admin authentication to guarantee the resource and data security.	
System Monitor	Monitors the running status of the system and the server.	
Maintain & Upgrade	Description	
WEB Configuration	Support of configurations through the WEB user interface.	
Language	Chinese, English.	
Software Upgrade	Support of user interface, gateway service, kernel and firmware upgrades based on WEB.	
Tracking Test	Support of Ping and Tracert tests based on WEB.	
SysLog Type	Three options available: ERROR, WARNING, INFO.	

1.3 Hardware Description

The wireless gateway supports two LANs and adopts an external 12V power supply. See below

for product appearance.



Figure 1-2 SMG4008 Front View



Figure 1-3 SMG4008 Rear View




Figure 1-4 SMG4016 Front View



Figure 1-5 SMG4016 Rear View




Figure 1-6 SMG4032 Front View



Figure 1-7 SMG4032 Rear View

The table below gives a detailed introduction to the interfaces, buttons and LEDs illustrated above:

Interface	Description
LAN	Amount: 2
	Type: RJ-45
	Bandwidth: 10/100 Mbps
	Self-Adaptive Bandwidth Supported
	Auto MDI/MDIX Supported
	Built-in Link indicator and ACTIVE indicator. For more details, refer to 1.4 Indicator Info
SIM Card Slot	Amount: 4, 8, 16*4, 32*4
	Network Supported: GSM, WCDMA, CDMA, VoLTE

Console Port	Amount: 1
	Type: RS-232
	Baud Rate: 115200bps
	Connector: RJ45 to DB-9 Connector (4004, 4008 series), Mini-USB connecting line (4016, 4032 series)
	Data Bits: 8 bits
	Stop Bit: 1 bit
	Parity Unsupported
	Flow Control Unsupported
External Power Supply Interface	Provide the 12V voltage with positive inside and negative outside, and the current is larger than 3A
Button	Description
Reset Button	Restore the gateway to factory settings by pressing this button persistently for 3 seconds
LED	Description
Power Indicator	Indicates the power state. It lights up when the gateway starts up with the power cord well connected
Run Indicator	Indicates the running status. For more details, refer to 1.4 Indicator Info .
Alarm Indicator	Alarms the device malfunction. For more details, refer to 1.4 Indicator Info .
Link Indicator	The green LED on the right of LAN, indicating the network connection status.
ACT Indicator	The orange LED on the left of LAN, whose flashing tells the data are being transmitted.
Port Indicator	<ol style="list-style-type: none"> When the port is idle, the LED Lights up in green and keeps on; When the port is unavailable, the LED Lights up in red and keeps on; When the port is in use, the LED flashes in green When the port module is disabled, the LED flashes in red For SMG4016 series, only the indicator of the card slot in which the SIM card is in using lights up and other indicators will go out in the case that there are more than one SIM cards inserted in the same channel.

For other hardware parameters, refer to [Appendix A Technical Specifications](#).

1.4 Indicator Info

The wireless gateway is equipped with two indicators denoting the system's running status: Run Indicator (green LED) and Alarm Indicator (red LED). The table below explains the states and meanings of the two indicators.

LED	State	Description
Run Indicator	Go out	System is not yet started.
	Light up and flash fast	System is starting.
	Flash slowly	Device is normal.
Alarm Indicator	Go out	Device is normal.
	Light up	Upon startup: Device is normal. In runtime: Device is abnormal.
	Flash	Device is abnormal.

Note:

- The startup process consists of two stages: System Booting and Gateway Service Startup. The system booting costs about 1 minute and once it succeeds, both the run indicator and the alarm indicator light up. Then after the gateway service is successfully started and the device begins to work normally, the run indicator flashes and the alarm indicator goes out.
- During runtime, if the alarm indicator lights up or flashes, it indicates that the device goes abnormal. If you cannot figure out and solve the problem by yourself, please contact our technicians for help. Go to [Appendix D Technical/sales Support](#) to find the contact way.

Chapter 2 Quick Guide

This chapter is intended to help you grasp the basic operations of the wireless gateway in the shortest time.

Step 1: Confirm that your packing box contains all the following things.

- Wireless Gateway *1
- External 12V Power Adapter *1
- GSM/WCDMA/CDMA/LTE Rubber Antenna *4/8/16/32
- Standard RJ45 to DB-9 Switcher (4004/4008 series) *1, Mini-USB connecting line (4016/4032 series) *1
- 8mm Antenna Wrench *1
- Rubber Foot Pad *4
- Network Cable *1
- Warranty Card *1
- Installation Manual *1

Step 2: Connect the network cable.

This product provides RJ-45 interfaces.

Step 3: Insert the SIM card (standard size) and install the antenna.

The wireless gateway provides a SIM card slot. You are required to insert the SIM card before using it. Take out the rubber antennae from the packing box, install them onto the wireless gateway, screw them up and evenly arrange them.

Step 4: Power on and start the gateway.

To use the wireless gateway, you need an external power supply. Insert it to the power interface of the wireless gateway and power it on with 100~240V AC. See the figure below:




Figure 2-1 Wireless Gateway Power Connection

Step 5: Log in the gateway.

Enter the original IP address (192.168.1.101) of the wireless gateway in the browser to go to the WEB interface of the gateway. The original username and password of the gateway are both 'admin'. For detailed instructions about login, refer to [3.1 System Login](#). We suggest you change the initial username and password via 'System Tools → Change Password' on the WEB interface as soon as possible after your first login. For detailed instructions about changing the password, refer to [3.11.6 Change Password](#). After changing the password, you are required to log in again.

Step 6: Modify IP address of the gateway.

You can modify the IP address of the gateway via 'Advanced Settings → Network' on the WEB interface to put it within your company's LAN. Refer to [3.5.1 Network](#) for detailed instructions about IP modification. After changing the IP address, you shall log in the gateway again using your new IP address.

Step 7: Make phone calls.

Note: For your easy understanding and manipulation, all examples given in this step do not involve registration, that is, SIP initiates calls in a point-to-point mode.

Situation 1: Call from a station to an IP phone (Tel→IP)

1. Go to 'Advanced Settings → Dialing Rule' on the WEB interface and click the 'Add New' button to add a new dialing rule. Refer to [3.5.4 Dialing Rule](#) for detailed instructions. Enter either a particular number or a string of 'x's to represent several random numbers. For example, 'xxx' denotes 3 random numbers. You may use the default value of 'Index' and are required not to leave 'Description' empty.

Example: Set **Index** to **99**, fill in **Description** with **test** and configure **Dial Rule** to **123**.

2. Go to 'Port Settings → Port Group' on the WEB interface and click the 'Add New' button to create a new port group and add the corresponding ports to it. Refer to [3.8.2 Port Group](#) for detailed instructions. You may use the default values of other configuration items and are required not to leave 'Description' empty.

Example: Provided the added port is Port1, check the checkbox before **Port1**, set **Index** to **1**, fill in **Description** with **test**, and keep the default values of other configuration items.

3. Go to 'Route Settings → Tel→IP' on the WEB interface and click the 'Add New' button to add a new routing rule. Refer to [3.9.3 Tel→IP](#) for detailed instructions. Select the port group created in Step2 as 'Source Port Group' and fill in 'Destination IP' and 'Destination Port' with the IP address and the Port number you plan to call. You may use the default values of other configuration items and are required not to leave 'Description' empty.

Example: Provided the remote IP address intended to call is 192.168.0.111 and the port is 5060. Set **Index** to **63**, **Source Port Group** to **1**, fill in **Description** with **test**, configure **Destination IP** to **192.168.0.111**, **Destination Port** to **5060**, and keep the default values of other configuration items.

4. Use an external phone to call the number of this SIM card, and then follow the cue tone to dial the number set in Step1 to ring the remote IP phone. If you have set a particular number in Step 1, only this number you can dial; if you have set a string of 'x's, how many 'x's there are, how many random numbers you can dial.

Example: The external phone dials the number of this SIM card, and then follows the cue tone to dial 123. Then the IP phone with the IP address 192.168.0.111 and the port 5060 will ring.

Situation 2: Call from an IP phone to a station (IP →Tel)

1. Go to 'Port Settings → Port Group' on the WEB interface and click the 'Add New' button to create a new port group and add the corresponding ports which are connected with stations to it. Refer to [3.8.2 Port Group](#) for detailed instructions. You may use the default values of other configuration items and are required not to leave 'Description' empty.

Example: Provided the added port is Port1, check the checkbox before **Port1**, set **Index** to **1**, fill in **Description** with **test**, and keep the default values of other configuration items.

2. Go to 'Route Settings → IP→Tel/IP' on the WEB interface and click the 'Add New' button to add a new routing rule. Refer to [3.9.2 IP→Tel/IP](#) for detailed instructions. Fill in 'Source IP' with the IP address which initiates the call and select the port group created in Step1 as 'Destination Port Group'. You may use the default values of other configuration items and required not to leave 'Description' empty.

Example: Provided the IP address of the IP phone which initiates the call is 192.168.0.111. Set **Index** to **63**, **Destination Port Group** to **1**, fill in **Description** with **test**, configure **Source IP** to **192.168.0.111**, and keep the default values of other configuration items.

3. Pick up the IP phone and call the IP address and port of the wireless gateway to make outgoing calls from the wireless channel.

Example: Provided the IP address of the wireless gateway is 192.168.0.101, the port is 5060, use the IP phone to call the IP address 13529101232@192.168.0.101 and then the first idle wireless port in the port group of step 2 will make an outgoing call to 13529101232.

Special Instructions:

- As the device will gradually heat up while being used, please maintain good ventilation to prevent sudden failure, ensuring that the ventilation holes are never jammed.
- During runtime, if the alarm indicator lights up or flashes, it indicates that the device goes abnormal. If you cannot figure out and solve the problem by yourself, please contact our technicians for help. Otherwise it may lead to a drop in performance or unexpected errors.

Chapter 3 WEB Configuration

3.1 System Login

Type the IP address into the browser and enter the login interface. See Figure 3-1.



Figure 3-1 Login Interface

The gateway only serves one user, whose original username and password are both 'admin'. You can change the username and the password via 'System Tools → Change Password' on the WEB interface. For detailed instructions, refer to [3.11.6 Change Password](#).

After login, you can see the main interface as below.




Figure 3-2 Main Interface

3.2 Operation Info

Operation Info includes four parts: **System Info**, **Port State**, **Call Count** and **SIP Message Count**, showing the current running status of the gateway. See Figure 3-3.




Figure 3-3 Operation Info

3.2.1 System Info



Figure 3-4 System Info Interface

See Figure 3-4 for the system info interface. You can click **Refresh** to obtain the latest system information. The table below explains the items shown in Figure 3-4.

Item	Description
MAC Address	MAC address of LAN.
IP Address	The three parameters from left to right are IP address, subnet mask and default gateway of LAN.
DNS Server	DNS server address of LAN.

Receive Packets	The amount of receive packets after the gateway's startup, including three options: All, Error and Drop.
Transmit Packets	The amount of transmit packets after the gateway's startup, including three options: All, Error and Drop.
Current Speed	Show the current speed of data receiving and transmitting.
Work Mode	Show the work mode of the network, including four modes: 10 Mbps Half Duplex, 10 Mbps Full Duplex, 100 Mbps Half Duplex, 100 Mbps Full Duplex.
Runtime	Time of the gateway keeping running normally after startup, which will be automatically updated.
WEB	Current version of the WEB interface.
Gateway	Current version of the gateway service.
Serial Num	Unique serial number of a wireless gateway.
Authorization Code	The authorization codes vary from different wireless modules.
FPGA	Current version of FPGA.
U-boot	Current version of Uboot.
Kernel	Current version of the system kernel on the gateway.
Device Type	Type of the wireless gateway.

3.2.2 Port State





























































Port State											
Port	Type	State	Voice Type	Direction	CallerID	CalleeID	SIM Card Used	Cell Phone No.	Connection	Signal	SIP Reg Status
1	GSM	 Idle	---	---	---	---		13023634112	Connect		Unregistered
2	GSM	 Idle	---	---	---	---		13023634183	Connect		Unregistered
3	GSM	 Unusable	---	---	---	---		---	Disconnect		Unregistered
4	GSM	 Unusable	---	---	---	---		---	Disconnect		Unregistered
5	GSM	 Unusable	---	---	---	---		---	Disconnect		Unregistered
6	GSM	 Unusable	---	---	---	---		---	Disconnect		Unregistered
7	GSM	 Unusable	---	---	---	---		---	Disconnect		Unregistered
8	GSM	 Unusable	---	---	---	---		---	Disconnect		Unregistered
9	GSM	 Unusable	---	---	---	---		---	Disconnect		Unregistered
10	GSM	 Unusable	---	---	---	---		---	Disconnect		Unregistered
11	GSM	 Unusable	---	---	---	---		---	Disconnect		Unregistered
12	GSM	 Unusable	---	---	---	---		---	Disconnect		Unregistered
13	GSM	 Unusable	---	---	---	---		---	Disconnect		Unregistered
14	GSM	 Unusable	---	---	---	---		---	Disconnect		Unregistered
15	GSM	 Unusable	---	---	---	---		---	Disconnect		Unregistered
16	GSM	 Unusable	---	---	---	---		---	Disconnect		Unregistered

Figure 3-5 Channel State Interface

See Figure 3-5 for the channel state interface where shows the channel type, the channel state for each channel on the gateway. The table below explains the items shown in Figure 3-5.

Item	Description
Port	Port number on the device.
Type	Port type on the device. So far, only GSM, WCDMA, CDMA and LTE types are supported.
State	Displays the port state in real time. You can move the mouse onto the port state icon for detailed state information.

	State	Icon	Description
	Idle		The port is available.
	Off-hook		The port picks up the call.
	Wait Answer		The port receives the ringback tone and is waiting for the called party to pick up the phone.
	Ringing		The port is in the ringing state.
	Talking		The port is in a conversation.
	Dialing		The port is dialing.
	Pending		The port is in the pending state.
	Internal State		Internal state of the port.
	Unusable		The port is unavailable.
Voice Type	Displays the voice type of the current call. Note: For the LTE series gateway, it is Net type and will display the network type of the current call.		
Direction	Displays the direction of the call on port.		
CallerID	Displays the CallerID of the call on port.		
CalleeID	Displays the CalleeID of the call on port.		
SIM Card	Displays the real-time state of the SIM card. Move the mouse onto the corresponding icon and you can find the exact state of the SIM card.  means card inserted,  means no card inserted,  means card in use. Note: This item is unavailable for SMG4004 and SMG4008 series.		
Cell Phone No.	Displays the number of the corresponding channel set in Wireless Parameters.		
Connection	Displays the connection status between the SIM card and the base station.		
Signal	Displays the signal intensity of the wireless module.		
SIP Reg Status	Displays the registration status of the port.		

3.2.3 Call Count

Call Count 1

Call Count 2

Call Count 1

Call Direction	Total Calls	Successful Calls	Busy	No Answer	Routing Failure	Dialing Failure	Unknown
IP->Tel	0	0	0	0	0	0	0
Tel->IP	0	0	0	0	0	0	0

Refresh

Figure 3-6 Call Count 1 Interface

Call Count 1

Call Count 2

Call Count 2 (TDM Outbound Calls)

Check	Port	Total Calls	Remote Ringing	Talking Count	Failure Count	Continuous Failure	Call Completion Rate	Accumulated Time	Average Time
<input type="checkbox"/>	1	0	0	0	0	0	0	0	0
<input type="checkbox"/>	2	0	0	0	0	0	0	0	0
<input type="checkbox"/>	3	0	0	0	0	0	0	0	0
<input type="checkbox"/>	4	0	0	0	0	0	0	0	0
<input type="checkbox"/>	5	0	0	0	0	0	0	0	0
<input type="checkbox"/>	6	0	0	0	0	0	0	0	0
<input type="checkbox"/>	7	0	0	0	0	0	0	0	0
<input type="checkbox"/>	8	0	0	0	0	0	0	0	0
	Total	0	0	0	0	---	0%	0	0

Check All

Uncheck All

Clear

Refresh

Figure 3-7 Call Count 2 Interface (4004/4008 Series)

Call Count 1		Call Count 2 (Outgoing Calls from TDM)							
Check	Port	Total Calls	Remote Ringing	Talking Count	Failure Count	Continuous Failure	Call Completion Rate	Accumulated Time	Average Time
<input type="checkbox"/>	1A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	1B	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	1C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	1D	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	2A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	2B	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	2C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	2D	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	3A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	3B	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	3C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	3D	15	13	13	2	0	87%	18	1.39
<input type="checkbox"/>	4A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	4B	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	4C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	4D	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	5A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	5B	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	5C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	5D	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	6A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	6B	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	6C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	6D	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	7A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	7B	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	7C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	7D	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	8A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	8B	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	8C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	8D	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	9A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	9B	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	9C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	9D	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	10A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	10B	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	10C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	10D	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	11A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	11B	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	11C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	11D	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	12A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	12B	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	12C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	12D	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	13A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	13B	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	13C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	13D	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	14A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	14B	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	14C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	14D	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	15A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	15B	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	15C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	15D	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	16A	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	16B	1	1	0	0	0	0%	0	0
<input type="checkbox"/>	16C	0	0	0	0	0	0%	0	0
<input type="checkbox"/>	16D	0	0	0	0	0	0%	0	0
Total		16	14	13	2	—	82%	18	1.39
Check All		Uncheck All		Clear		Refresh			

Figure 3-8 Call Count 2 Interface (4016/4032 Series)

See Figure 3-6, Figure 3-7 and Figure 3-8 for the call count Interface. The above list shows the detailed information about all the calls counted from the startup of the gateway service to the latest open or refresh of this interface. You can click **Refresh** to obtain the current call count information. The table below explains the items shown in above figures.

Item	Description
Call Direction	A condition for call count, two options available: <i>IP→Tel</i> and <i>Tel→IP</i> .
Total Calls	Total number of calls in a specified call direction.
Successful Calls	Total number of successful calls in conversation.
Busy	Total number of calls which fail as the called party has been occupied and replies a busy message.
No Answer	Total number of calls which fail as the called party does not pick up the call in a long time or the calling party hangs up the call before the called party picks it up.
Routing Failure	Total number of calls which fail because no routing rules are matched.
Dialing Failure	Total number of calls which fail as the called party number does not conform to the dialing rule or due to dialing timeout.
Unknown Failure	Total number of calls which fail due to unknown reasons.
Total Calls	The total numbers of the outgoing calls.
Remote Ringing	The count of the calls which bring the remote terminal into the ringing state.
Talking Count	The count of the outgoing calls which are answered by remote terminal.
Failure Count	The count of the failure calls, i.e. the counts of the calls which cannot be made out by the port.
Continuous Failure	The count of the calls which failed continuously twice or more.
Call Completion Rate	The percentage of successful calls to total calls.
Accumulated Time	The total time of the calls which are answered by the remote terminal.
Average Time	The average time length of each call answered by the remote terminal.

3.2.4 SIP Message Count

Request								
Request	REGISTER	INVITE	ACK	INFO	BYE	CANCEL	NOTIFY	OPTION
Send	0	1	1	0	1	0	0	0
Send Repeatedly	0	0	0	0	0	0	0	0
Receive	0	1	1	0	1	0	0	0
Receive Repeatedly	0	0	0	0	0	0	0	0

Common Response						
Common Response	100 Trying	180 Ringing	183 Session Prosess	200 OK	486 Busy	487 Request Already Terminated
Send	1	1	0	2	0	0
Receive	1	1	0	2	0	0

Refresh

Clear

Figure 3-9 SIP Message Count Interface

See Figure 3-9 for the SIP Message Count interface. This is used to record the amount of the normal SIP messages that are sent/received or repeatedly sent/received during the period from the startup of the gateway service to the latest open or refresh of the interface. Click **Refresh** to

refresh the count of SIP messages, or click **Clear** to clear the current count of SIP messages.

3.3 Quick Config





Figure 3-10 Quick Config Interface

See Figure 3-10 for the Quick Config interface. Follow the gateway Quick Configuration wizard and you can easily complete the settings on network, SIP and Port. The gateway can work normally after configuration.

See Figure 3-11 for the Quick Config-Network Settings interface. Refer to [3.5.1 Network](#) for detailed settings. After configuration, click **Next** to enter the SIP Settings interface.



Quick Config-Network Settings	
Network Type:	Static
IP Address (I)	192.168.1.101
Subnet Mask (U)	255.255.255.0
Default Gateway (D)	192.168.1.1
DNS Server (P)	0.0.0.0
Speed and Duplex Mode	Automatic Detection
Next	

Figure 3-11 Quick Config-Network Settings Interface

See Figure 3-12 for the Quick Config-SIP Settings interface. The configuration items on this interface are the same as those on the SIP interface. Refer to [3.4.1 SIP](#) for detailed settings. You are required to fill with the information about the registrar if the gateway must be registered. After configuration, click **Back** to go back to the Network Settings interface; click **Next** to enter the Port Settings interface.

Quick Config-SIP Settings

Registrar IP Address

Registrar Port

Spare Registrar IP Address

Spare Registrar Port

Registry Validity Period (s)

Figure 3-12 Quick Config-SIP Settings Interface

See Figure 3-13 for the Port Settings interface. The configuration items on this interface are the same as those on the Port interface. Refer to [3.8.1 Port](#) for detailed settings. After configuration, click **Back** to go back to the SIP Settings interface; click **Next** to enter the Quick Config-Completion interface.

Port Settings													Batch Modify
Port	SIP Account	Authentication Username	Connection Method	Bound Number	Forbid Outgoing Call	Forbid Incoming Call	Caller ID Detection	Reg Status	Echo Canceller	Color Ring	Color Ring Index	Server Index	Modify
1	8001	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	
2	8002	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	
3	8003	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	
4	8004	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	
5	8005	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	
6	8006	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	
7	8007	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	
8	8008	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	
9	8009	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	
10	8010	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	
11	8011	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	
12	8012	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	
13	8013	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	
14	8014	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	
15	8015	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	
16	8016	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	---	

Figure 3-13 Port Settings Interface

Quick Config-Completion

The configuration is finished. Please click 'Finish' to quit the Quick Config!

Note: the gateway will restart the system after you click 'Finish'. Please log in the gateway again using your new IP address.

Figure 3-14 Quick Config-Completion Interface

Click **Back** to go back to the Port Settings interface; click **Finish** to finish the Quick Config wizard and now the gateway can work normally with basic configuration.


3.4 VoIP Settings

VoIP Settings includes six parts: **SIP**, **SIP Compatibility**, **SIP Station**, **SIP Server**, **NAT Setting** and **Media**. See Figure 3-15. **SIP Settings** is used to configure the general SIP parameters, **SIP Compatibility** is used to set which SIP servers and SIP messages will the gateway be compatible with, **SIP Station** is to set the basic information of the SIP station, **SIP Server** is to set the basic information of the SIP server, **NAT Setting** is used to configure the parameters for NAT, and **Media Settings** is to set the RTP port and the payload type.



Figure 3-15 VoIP Settings

3.4.1 SIP



The image shows a web-based configuration interface titled "SIP Settings". It contains various input fields and checkboxes for configuring SIP parameters. The settings are as follows:

- SIP Port:** 5060
- Send 180:** ☒ Enable
- Called Number Prefix for 180 Reply (separated by '.'):** (empty field)
- Register Status:** Unregistered
- Register Gateway:** Yes
- SIP Account:** (empty field)
- Password:** (empty field)
- Authentication Username:** (empty field)
- Registrar IP Address:** (empty field)
- Registrar Port:** (empty field)
- Spare Registrar Server:** ☒ Enable
- Spare Registrar IP Address:** (empty field)
- Spare Registrar Port:** (empty field)
- Registry Validity Period (s):** 600
- Multi-Registrar Server Mode:** ☐ Enable
- SIP Transport Protocol:** UDP
- Switch Signal Port if SIP Registration Failed:** ☐ Enable
- IMS Network:** ☒ Enable
- Externally Bound Address:** (empty field)
- Externally Bound Port:** 5060

At the bottom of the interface are two buttons: "Save" and "Reset".

Figure 3-16 SIP Settings Interface


See Figure 3-16 for the SIP settings interface where you can configure the general SIP parameters. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the system, do it immediately to apply the changes. Refer to [3.11.9 Restart](#) for detailed instructions. The table below explains the items shown in Figure 3-16.

Item	Description
SIP Port	Monitoring port of SIP signaling. The value range of it must be greater than 1024 and less than 65535, with the default value of 5060.
Send 180	Sets whether to send the 180 message to respond to the ringing tone when the SIP end serves as the called party.
Called Number	Once the feature "Send 180" is enabled, the gateway will reply the 180 message to

Prefix for 180 Reply	those calls which have the calleelD with the designated prefix; otherwise, it will reply the 183 message. By default, the value is null, that is, replying the 183 message to all calls.
Register Status	Registration status of the gateway. When Register Gateway is set to <i>No</i> , the value of this item is <i>Unregistered</i> ; when Register Gateway is set to <i>Yes</i> , the value of this item is either <i>Failed</i> or <i>Registered</i> .
Register Gateway	Sets whether to register the gateway as a whole. The default value is <i>No</i> . Only when this configuration is set to <i>Yes</i> can you see the configuration items SIP Account and Password .
SIP Account	When the gateway initiates a call to SIP, this item corresponds to the username of SIP.
Password	Registration password of the gateway. To register the gateway to SIP, both configuration items SIP Account and Password should be filled in.
Authentication Username	Authentication username for registration.
Registrar IP Address	Address of the registry server for the gateway to register.
Registrar Port	Signaling port of the registry server.
Spare Registrar Server	Check the enable checkbox to enable the spare registrar server. By default, it is disabled .
Spare Registrar IP Address	Address of the spare registry server for the gateway to register. The gateway will enable the spare registrar server if the master registrar server has no reply, or the master server is detected with no response in case the item Detection Server Cycle is enabled.
Spare Registrar Port	Signaling port of the spare registry server.
Registry Validity Period	Validity period of the SIP registry. Once the registry is overdue, the gateway should be registered again. This configuration item is valid only when Register Gateway is set to <i>Yes</i> . Range of value: 10~3600, calculated by s, with the default value of 600.
Multi-Registrar Server Mode	Tick the checkbox before to enable the multi-registrar server mode. By default, it is <i>disabled</i> .
SIP Transport Protocol	There are two modes <i>UDP</i> and <i>TCP</i> available for running the SIP protocol. The default value is <i>UDP</i> .
Switch Signal Port if SIP Registration Failed	If the SIP registration fails, the SIP signaling port N will switch to N+1 for a new registration. It will continue until the registration succeeds. By default, it is disabled.
IMS Network	Once this feature is enabled, the gateway will send signaling messages to the corresponding externally bound address and port when it registers to the server. By default, this feature is <i>disabled</i> . Only when this feature is <i>enabled</i> will these items Externally Bound Address , Externally Bound Port and Authentication Username be shown.
Externally Bound Address	Externally bound IP address for registration.
Externally Bound Port	Externally bound port for registration.

3.4.2 SIP Compatibility

See Figure 3-17 for the SIP Compatibility interface where you can configure the SIP parameters to determine which SIP servers and SIP messages will the gateway be compatible with. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations.



The image shows a web-based configuration interface titled "SIP Compatibility". It contains various settings for SIP parameters, organized into sections. At the bottom, there are "Save" and "Reset" buttons.

Item	Description
Obtain CalleeID from	"Request" Field
Set CallerID position	Username of From Field
Obtain CallerID from	Username of From Field
Use Contact Address	<input type="checkbox"/> Enable
Reply To Source Address	<input type="checkbox"/> Enable
Two Stage Dialing for SIP Incoming Call	<input type="checkbox"/> Enable
Maximum Wait Answer Time (s)	60
SIP Station Supported	<input type="checkbox"/> Enable
Set SIP Identifying	Gateway
Call Hangup when RTP Timeout(s)	0
Ignore ACK	<input type="checkbox"/> Enable
Iptable for SIP Calls	<input type="checkbox"/> Enable
SIP Encryption	<input checked="" type="checkbox"/> Enable
Encryption Criterion	VOS1.1
Identifier	
Key	
RTP Encryption	<input type="checkbox"/> Enable
Abnormal Call Hangup Detection	<input checked="" type="checkbox"/> Enable
Cycle(s)	0
Server Status Detection	<input checked="" type="checkbox"/> Enable
Cycle(s)	0
Available Port Negotiation	<input checked="" type="checkbox"/> Enable
Cycle(s)	0
Address	
Occasion to Reply 183	Immediately
Occasion to Reply 200 ok	After pickup

Figure 3-17 SIP Compatibility Setting Interface

The table below explains the items shown in Figure 3-17.

Item	Description
Obtain CalleeID	There are two optional ways to obtain the called party number: from "To" Field and

from	from "Request" Field. The default value is "Request" Field.
Set CallerID Position	There are two options to set the position of the calling party number: "Displayname of From Field" and "Username of From Field". The default value is "Username of From Field".
Obtain CallerID from	There are two optional ways to obtain the calling party number: from "Displayname of From Field" and from "Username of From Field". The default value is "Username of From Field".
Use Contact Address	Sets whether to send the request message according to the content of Contact, with the default setting of <i>disabled</i> . As it is disabled, if the Contact field indicates an IP address within the LAN, the request message will be sent according to the source address; if the Contact field indicates an IP address belonging to the WAN, the request message will be sent according to this IP address.
Reply To Source Address	Once this feature is enabled, the gateway will reply the source address in the invite message. As the item Use Contact Address conflicted with this item, you may now shield the other one while enabling one of them.
Two Stage Dialing for SIP Incoming Call	Once this feature is enabled, the incoming call from SIP should perform the two stage dialing operation. By default this feature is disabled.
Maximum Wait Answer Time	Sets the maximum time for the SIP channel to wait for the answer from the called party of the outgoing call it initiates. If the call is not answered within the specified time period, it will be canceled by the channel automatically. The default value is 60, calculated by s.
SIP Station Supported	Once this feature is enabled, a SIP terminal can be registered to the gateway to become a SIP station. By default this feature is disabled.
Set SIP Identifying	Sets the SIP identifying content in the SIP call message. The default setting is <i>Gateway</i> .
Maximum Wait RTP Time	Sets the maximum time for the SIP channel to wait for the RTP packet. If no RTP packet is received within the specified time period, the channel will enter the pending state automatically and release the call. The default value is 0 (<i>disabled</i>), calculated by s.
Ignore ACK	Once this feature is enabled, it is not necessary for the gateway to wait for the ACK message after sending the 200OK message to establish a call. By default it is <i>disabled</i> .
Iptable for SIP Calls	Only some special SIP messages, which can be configured by users, are allowed to send to the gateway.
SIP Encryption	Once this feature is enabled, you can encrypt the SIP signal following selecting an encryption criterion and setting a key. By default it is <i>disabled</i> .
Encryption Criterion	The criterion used to encrypt the SIP signal. At present only VOS1.1 is supported.
Identifier	The identifier field of the VOS encryption, which is used to obtain the key of the SIP encryption.
Key	The key to encrypt the SIP signal.
RTP Encryption	Once this feature is enabled, you can encrypt the RTP package. By default it is <i>disabled</i> .

Abnormal Call Hangup Detection	Sets the interval between checks of the remote end's abnormal hangup, with the default value of 0 (feature disabled), calculated by s. It is suggested to set to 10s if this feature is necessary to be used.
Server Status Detection	The interval of sending a heartbeat packet to detect the master registrar server status, with the default value of 0 (feature disabled), calculated by s. It is suggested to set to 15s if this feature is necessary to be used.
Available Port Negotiation	When this feature is enabled, the gateway will send messages to the preset negotiation server (e.g. VOS server) to let it know the number of available ports on the gateway. By default this feature is disabled.
Cycle, Address	Cycle means how soon will the gateway send a message; Address indicates the server address (e.g. VOS server).
Occasion to Reply 183	Sets the occasion to reply the 183 message. Two options including: Immediately and After ringing, with the default value of <i>Immediately</i> .
Occasion to Reply 200 Ok	Sets the occasion to reply 200 OK. Two options including: After pickup and After ringing, with the default value of <i>After pickup</i> .

3.4.3 SIP Station

A SIP terminal can be registered to the gateway to become a SIP station. Tick the option of '**SIP Station Supported**' on [3.4.2 SIP Compatibility](#) interface, and you will see the item SIP Station on the VoIP Settings menu. Click '**SIP Station**' to go into the SIP Station interface. By default, there is no available SIP station. See Figure 3-18 below.




Figure 3-18 SIP Station Setting Interface

Click **Add New** to add SIP stations manually. See Figure 3-19. You can configure basic SIP station information on this interface. The bound port to a SIP station must be a wireless port and unique. The username must be the same as that used to register the SIP terminal to the gateway.

The dialog box titled 'SIP Station' contains the following fields and controls:

- Number:** A text input field containing the value '0'.
- Username:** An empty text input field.
- Password:** An empty text input field.
- Bound Port:** A dropdown menu showing '1'.
- Description:** A text input field containing the value 'default'.
- Batch Setting:** A checkbox labeled 'Enable' which is currently unchecked.
- Buttons:** 'Save' and 'Close' buttons at the bottom.

Figure 3-19 Add New SIP Station

The table below explains the items shown above:

Item	Description
Number	The logical number for a SIP station to register to the gateway.
Username	The username used to register a SIP station to the gateway.
Password	The password used to register a SIP station to the gateway.
Bound Port	The wireless port which is bound to the SIP station.
Description	It is user-defined, with the default value of <i>default</i> .
Batch Setting	Used to set multiple SIP stations at the same time.

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings. See Figure 3-20 for the applied SIP station information.


SIP Station									
Check	Number	Username	IP Address	Bound Port	Register Status	Register Duration (s)	Voice Channel State	Description	Modify
<input type="checkbox"/>	0	120	--	1	Unregistered	--	--	default	

Check All Uncheck All Inverse Delete Clear All Add New

1 Item Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-20 SIP Station Interface

Click **Modify** in the above figure to modify the configuration of the SIP station. See Figure 3-21. The configuration items on this interface are the same as those on the **Add New SIP Station** interface.



The interface is titled "SIP Station". It contains several input fields and a checkbox:

- Number:** A text box containing the value "0".
- Username:** A text box containing the value "120".
- Password:** A text box containing three dots "..." indicating a masked password.
- Bound Port:** A dropdown menu showing the value "1".
- Description:** A text box containing the value "default".
- Batch Setting:** A checkbox labeled "Enable", which is currently unchecked.

At the bottom of the form are two buttons: "Save" and "Close".

Figure 3-21 SIP Station Modification Interface

To delete a SIP station, check the checkbox before the corresponding index in Figure 3-20 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all SIP stations at a time, click the **Clear All** button in Figure 3-20.

3.4.4 SIP Server

The gateway supports the multi-registrar server feature. Enable the feature of '**Multi-Registrar Server Mode**' on the [SIP](#) interface (see [3.4.1 SIP](#)) and you will see the item SIP Server under the VoIP Settings menu. Click '**SIP Server**' to go into the SIP Server interface. By default, there is no available SIP server. See Figure 3-22 below.




Figure 3-22 SIP Server Interface

Click **Add New** to add SIP servers manually. See Figure 3-23. You can configure basic SIP server information on this interface.

Figure 3-23 Add New SIP Server

All the items except Index and Description are the same as those on [the SIP](#) interface ([3.4.1 SIP](#)).

Item	Description
Index	The index of each SIP server. The gateway supports up to 8 SIP servers.
Description	More information about each SIP server, with the default value of <i>default</i> .


After configuration, click **Save** to save the above settings into the gateway or click **Cancel** to cancel the settings. See Figure 3-24 for the SIP server management interface.

Check	Index	Description	IP Address	Port	IMS Network	Externally Bound Address	Externally Bound Port	Registry Validity Period	Port	Port Group	Modify
<input type="checkbox"/>	1	default	201.123.115.233	5060	Disable	---	---	600	---	---	

Figure 3-24 SIP Server Management

Click **Modify** in the above figure to modify the configuration of the SIP server. See Figure 3-25.

The configuration items on this interface are the same as those on the **Add New SIP Server** interface.



Modify SIP Server	
Index	1
Description	default
Registrar IP Address	201.123.115.233
Registrar Port	5060
Registry Validity Period (s)	600
IMS Network	<input type="checkbox"/> Enable


Save Cancel

Figure 3-25 SIP Server Modification Interface

To delete a SIP server, check the checkbox before the corresponding index in Figure 3-24 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all SIP servers at a time, click the **Clear All** button in Figure 3-24.

3.4.5 NAT Setting

See Figure 3-26 for the NAT setting interface where you can configure the parameters for NAT. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations.



NAT Settings	
STUN Server	<input checked="" type="checkbox"/> Enable
NAT Type	Unknown
STUN Server Address	127.0.0.1
Mapping Address	
RTP Self-adaption	<input type="checkbox"/> Enable
Rport	<input checked="" type="checkbox"/> Enable
Auto Detect NAT IP	<input type="checkbox"/> Enable
Note: Auto Detect NAT IP: This feature only works cooperatively with the port mapping setting on router.	

Save Reset

Figure 3-26 NAT Setting Interface

The table below explains the items shown in Figure 3-26.

Item	Description
STUN Server	Sets whether to enable the STUN server for NAT traversal. By default the STUN server is disabled.
NAT Type	Detected NAT (Network Address Translation) type. The gateway will return the NAT type automatically in case STUN Server is enabled. It includes 9 types: unknown; no NAT; ConeNat; RestrictedNat; PortRestrictedNat; Symmetric NAT; Symmetric NAT with firewall; can't detect over (fail to send detect message) and fail to detect (No reply from the stun server).
STUN Server Address	Address of the server for STUN traversal.
Mapping Address	<p>It should be filled in when there exists NAT or other mapping relationships which leads to the failure of direct communication between the gateway and the destination address, so as to ask the remote end to send signaling messages or voice data to it during the signaling or voice communication between the gateway and the destination.</p> <p>Note: Once this item is filled out, it will be used as the first choice even if Rport and NAT IP are enabled.</p>
RTP Self-adaption	When this feature is enabled, the RTP reception address or port carried by the signaling message from the remote end, if not consistent with the actual state, will be updated to the actual RTP reception address or port. By default, this feature is <i>disabled</i> .
Rport	When this feature is enabled, a corresponding Rport field will be added to the Via message of SIP. The default value is <i>enabled</i> .
Auto Detect NAT IP	<p>When this feature is enabled, the gateway will parse the corresponding address and port in the message returned by Rport so as to use them for the following communication. By default, this feature is <i>disabled</i>.</p> <p>Note: This feature gets valid only when Rport is enabled.</p>

3.4.6 Media

Media Parameters

DTMF Transmit Mode

RFC2833 ▼

RFC2833 Payload

101

RTP Port Range

50000,50767

Silence Suppression

Disable ▼

JitterBuffer

20

Voice Gain Output from IP (dB)

0

AGC

☒ Enable

Target Energy Threshold (dB)

0

Maximum Gain Threshold (dB)

48

Maximum Attenuation Threshold (dB)

0

Minimum Input Energy (dB)

-60

CODEC Priority

Check	Priority	CODEC	Packing Time	Bit Rate (kbs)
<input checked="" type="checkbox"/>	1	G711A ▼	20 ▼	64 ▼
<input checked="" type="checkbox"/>	2	G711U ▼	20 ▼	64 ▼
<input checked="" type="checkbox"/>	3	G729 ▼	20 ▼	8 ▼
<input checked="" type="checkbox"/>	4	G723 ▼	30 ▼	6.3 ▼
<input checked="" type="checkbox"/>	5	G722 ▼	30 ▼	64 ▼
<input checked="" type="checkbox"/>	6	AMR ▼	20 ▼	4.75 ▼
<input checked="" type="checkbox"/>	7	iLBC ▼	30 ▼	13.3 ▼

Save

Reset

Figure 3-27 Media Settings Interface

See Figure 3-27 for the media settings interface where you can configure the RTP port and payload type depending on your requirements. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the system, do it immediately to apply the changes. Refer to [3.11.9 Restart](#) for detailed instructions. The table below explains the items shown in Figure 3-27.

Item	Description
DTMF Transmit Mode	Sets the transmit mode for the IP channel to send DTMF signals. The optional values are <i>RFC2833</i> , <i>In-band</i> and <i>Signaling</i> , with the default value of <i>RFC2833</i> .
RFC2833 Payload	Payload of the RFC2833 formatted DTMF signals on the IP channel. Range of value: 90~127, with the default value of 101.

<i>RTP Port Range</i>	Supported RTP port range for the IP end to establish a call conversation, with the lower limit of 10000 and the upper limit of 60000 and the difference between larger than 480. The default value is 50000-50767.
<i>Silence Suppression</i>	Sets whether to send comfort noise packets to replace RTP packets or never to send RTP packets to reduce the bandwidth usage when there is no voice signal throughout an IP conversation. The optional values are <i>Enable</i> and <i>Disable</i> , with the default value of <i>Disable</i> .
<i>JitterBuffer</i>	Acceptable jitter for data packets transmission over IP, which indicates the buffering capacity. A larger JitterBuffer means a higher jitter processing capability but as well as an increased voice delay, while a smaller JitterBuffer means a lower jitter processing capability but as well as a decreased voice delay. Range of value: 20~200, calculated by ms, with the default value of 20.
<i>Voice Gain Output from IP</i>	Adjusts the gain of the voice output from IP. Range of value: -24~12, calculated by dB, with the default value of 0.
<i>AGC</i>	If the AGC (Automatic Gain Control) feature is enabled, the gateway will automatically adjust the input signal amplitude, increasing that of small signals and decreasing that of large signals.
<i>Target Energy Threshold</i>	Set the target energy of the AGC, range of value: -50~0, calculated by dB, with the default value of 0.
<i>Maximum Gain Threshold</i>	Set the maximum gain threshold that will be applied to the signal. Range of value: 0~48, calculated by dB, with the default value of 48.
<i>Maximum Attenuation Threshold</i>	Set the maximum attenuation that will be applied to the signal. Range of value: -42~0, calculated by dB, with the default value of 0.
<i>Minimum Input Energy</i>	Set the minimum threshold for the energy processed by AGC. Signals below this threshold will not be processed by AGC. Range of value: -60~ -25, calculated by dB, with the default value of -60.

CODEC Priority	Supported CODECs and their corresponding priority for the IP end to establish a call conversation. The table below explains the sub-items:	
	Sub-item	Description
	<i>Priority</i>	Priority for choosing the CODEC in an SIP conversation. The smaller the value is, the higher the priority will be.
	<i>CODEC</i>	Three optional CODECs are supported: G711A, G711U, G729A/B, G723, G722, AMR and iLBC.
	<i>Packing Time</i>	Time interval for packing an RTP packet, calculated by ms.
	<i>Bit Rate</i>	The number of thousand bits (excluding the packet header) that are conveyed per second.
	By default, all of the seven CODECs are supported and ordered G711A, G711U, G729A/B, G723, G722, AMR and iLBC by priority from high to low.	
	The packing time and bit rate supported by different CODECs are listed in the table below. Those values in bold face are the default values.	
	CODEC	Packing Time (ms) Bit Rate (kbps)
	G711A	10 / 20 / 30 / 40 / 60 64
	G711U	10 / 20 / 30 / 40 / 60 64
	G729A/B	10 / 20 / 30 / 40 / 60 8
	G723	30 / 60 5.3 / 6.3
	G722	10 / 20 / 30 / 40 64
	AMR	20 / 40 / 60 4.75
	iLBC	20 / 40 15.2
		30 / 60 13.3


3.5 Advanced Settings

Advanced Settings includes eleven parts: **Network**, **System Param**, **Service Config**, **Dialing Rule**, **Function Key**, **Cue Tone**, **Color Ring**, **QoS**, **Tone Generator**, **CDR Query** and **VPN**. See Figure 3-28. **Network** is used to configure the general properties of the network port; **System Param** is used to configure some properties of the system; **Service Config** is used to configure some properties which corresponds to the service; **Dialing Rule** is used to set the judging conditions for dialing; **Function Key** is used to set a cluster of combination keys for you to query or set the network port; **Cue Tone** is used to set the gateway language for playing voice and the voice file used for the two-stage dialing; **Color Ring** is used to upload the color ring file which can be set as a ringback tone for an incoming call from IP to wireless port; **QoS** uses the differentiated services technology to increase the gateway's service quality; **Tone Generator** is used to configure some properties of tones sent from gateway; **CDR Query** is used to inquire the detailed call record; **VPN** makes use of the tunnel technology to transport the data, and the methods of user authentication and data encryption to prevent the data being read and distorted when they are transported on the public network.



Figure 3-28 Advanced Settings

3.5.1 Network




The image shows the 'Network Settings' interface. It has a blue header bar with the text 'Network Settings'. Below the header, there are five rows of settings, each with a label on the left and a text input field on the right. The settings are: Network Type (Static), IP Address (I) (192.168.1.101), Subnet Mask (U) (255.255.255.0), Default Gateway (D) (192.168.1.1), and DNS Server (P) (0.0.0.0). Below the settings, there is a red note: 'Note:1.Please log in again using your new IP address if the IP address has been modified! 2.If you select 'DHCP', your IP address will be allocated randomly Please dial the port's number and press the corresponding function key to inquire it.' At the bottom, there are two blue buttons: 'Save' and 'Reset'.

Figure 3-29 Network Settings Interface

See Figure 3-29 for the network settings interface. A gateway has two LANs which can be configured with the same network type, IP address, subnet mask, default gateway and DNS server to realize the feature of hot backup. There are three options in type: Static, DHCP and PPPoE.

After configuration, click **Save** to save the above settings into the gateway or click **Reset** to restore the configurations. After changing the IP address, you shall log in the gateway again using your new IP address.

3.5.2 System Param



System Param

WEB Management

WEB Port: 80

Access Setting: Allow All IPs

SYSLOG Parameters

SYSLOG Enabled: ☒ Yes ☐ No

Server Address: 201.123.115.138

SYSLOG Level: INFO

AT Debug Enabled: ☒ Yes ☐ No

Echo Mode Enabled: ☒ Yes ☐ No

Port: all ports

CDR Parameters

CDR Enabled: ☒ Yes ☐ No

Server Address: 127.0.0.1

Server Port: 3

Save CDR: ☒ Yes ☐ No

Amount of Saved CDR: 5000

API Parameters

API Enabled: ☒ Yes ☐ No

Remote IP Address Allowed to Invoke API: *

(Separated by ';;' '*' denotes all IP addresses)

Username for API Call: ApiUserAdmin

Password for API Call:

Time Parameters

Time Calibration: ☒ NTP ☐ Synchronized with Operator ☐ Close

NTP Server Address: 127.0.0.1

Synchronizing Cycle: 3600

System Time: ☐ Modify 2017-10-11 17:28:34

Time Zone: GMT+8:00 (Beijing, Singapore, Taipei, Kuala Lumpur)

Restart Parameters

Daily Restart: ☒ Yes ☐ No

Restart Time: 0 h 0 m

Clear Call Count 2 After Restart: ☐ Yes ☒ No

Buttons: Save, Reset

Figure 3-30 System Parameters Setting Interface

See Figure 3-30 for the System Parameters Setting interface. The table below explains the items shown in the above figure.

Item	Description
WEB Port	The port which is used to access the gateway via WEB. The default value is 80.

Access Setting	Sets the IP addresses which can access the gateway via WEB. By default, all IPs are allowed. You can set an IP whitelist to allow all IPs within it to access the gateway freely. Also you can set an IP blacklist to forbid all IPs within it to access the gateway.
SYSLOG Enabled	Sets whether to enable SYSLOG. It is required to fill in SYSLOG Server Address and SYSLOG Level in case SYSLOG is enabled. By default, SYSLOG is disabled.
Server Address	Sets the SYSLOG server address for log reception.
SYSLOG Level	Sets the SYSLOG level. There are three options: <i>ERROR</i> , <i>WARNING</i> , <i>INFO</i> and <i>DEBUG</i> . The default value is <i>INFO</i> .
AT Debug Enabled	Sets whether to enable the AT debug feature, with the default value of <i>No</i> . Once this feature is enabled, the related information about AT will be output to the SYSLOG.
Echo Mode Enabled	Sets whether to enable the echo mode, with the default value of <i>No</i> . Once this feature is enabled, both the sent and received information will be displayed.
Port	Select the port to execute the AT debug. It is allowed to choose a port or all ports.
CDR Enabled	Sets whether to enable the feature of CDR. It is required to fill in Server Address and Server Port in case CDR is enabled. By default, CDR is disabled.
Server Address	Sets the server address to receive CDR.
Server Port	Sets the server port to receive CDR.
Save CDR	Sets whether to save CDR, with the default value of <i>NO</i> .
Amount of Saved CDR	Sets the amount of saved CDR. Range of value: 200~10000, with the default value of 5000.
API Enabled	When this feature is enabled, the remote terminal can invoke the API interface. The default value is <i>No</i> .
Remote IP Address allowed to Invoke API	Sets the remote IP addresses which are allowed to invoke the API interface. Up to 5 addresses can be configured and each of them are separated by “,”. “*” denotes all IP addresses are allowed.
Username for API Call, Password for API Call	The authorized username and password for calling the API interface.
Time Calibration	Sets the calibration mode for the time. Three options available: <i>NTP</i> , <i>Synchronized with Operator</i> and <i>Close</i> , with the default value of <i>Synchronized with Operator</i> .
NTP Server Address	Sets the Server address for NTP time synchronization.
Synchronizing Cycle	Sets the cycle for NTP time synchronization. The default value is 3600.
System Time	The system time. Check the checkbox before Modify and change the time in the edit box if <i>Time Calibration</i> is set to <i>Close</i> .
Time Zone	The time zone of the gateway.
Daily Restart	Sets whether to restart the gateway regularly every day at the preset Restart Time . By default, this feature is disabled.
Restart Time	Sets the time to restart the gateway regularly.
Clear Call Count 2 after Restart	When this feature is enabled, the gateway will clear the data of Call Count 2 upon its restart. By default this feature is disabled.

3.5.3 Service Config

The screenshot shows the 'Service Config' window with the following sections and settings:

- Service Parameters**
 - Enable Two Stage Dialing Mode for PSTN Outgoing Calls: ☒ Disable ☐ Enable
 - Maximum Wait Time for PSTN Outgoing Calls: 60 s
 - Dial Interval: 6 s
 - Waiting for Idle Time: 1500 ms
 - Busy Tone Detection Mode: ☐ Common ☒ Delay ☐ Ignore
 - Delay Time: 5 s
 - Auto Hangup upon Ringback: ☐ Disable ☒ Enable
 - Note: Set 'SIP Compatibility-Occasion to Reply 183' After ringing
- Abnormality Handling**
 - Communicate without Network: ☐ Disable ☒ Enable
 - IP->Tel Call Failure, Auto Transfer FWD to Register Server: ☐ Disable ☒ Enable
 - Target IP: [Empty field]
 - Target Port: [Empty field]
 - Tel->IP Call Failure, Auto SMS Reply: ☐ Disable ☒ Enable
 - ☐ Unconnected
 - ☐ No Answer
 - ☐ Rejected
 - ☐ Fail to Connect
 - Auto Disable Module if Fail to Register to SIP Server: ☐ Disable ☒ Enable
 - Note: The feature of 'FWD on Unreachable' must be enabled once the feature "Auto Disable Module if Fail to Register to SIP Server" is enabled.
 - Auto Lock SIM Card after Consecutive Call Failure: ☐ Disable ☒ Enable
 - Call Failure Mode: ☐ Busy ☐ No Answer ☐ Dial Failure
 - Consecutive Call Failures: 0 (times)
 - Locking Time: 0 (Min)
 - Unlock by Plugging SIM Card in and out: ☒ Disable ☐ Enable
 - Note: Locking Time being -1 means the card is always being locked while it being 0 means the card is unlocked.
 - Auto Reconnect to BS after Consecutive Call Failure: after 0 times' Failure (0 disabled)
 - Record SIM Card Number at Gateway Restart: ☐ Disable ☒ Enable
- Echo Cancellation**
 - Work Mode: Both near-end a
 - Non-linear Processing: ☒ Enable
 - Fixed Window Size (Near-end, Narrowband 8kHz): 8ms
 - Moving Window Size (Far-end, Narrowband 8kHz): 8ms

Buttons: Save, Reset

Figure 3-31 Service Config Interface

See Figure 3-31 for the Service Config interface. The table below explains the items shown in the above figure.

Item	Description
Enable Two Stage Dialing Mode for PSTN Outgoing Calls	Sets whether to enable the two stage dialing mode for PSTN outgoing calls. Under this mode, for an outgoing call from a wireless port, the IP side will hear the dial tone. If you fail to input the number during the schedule time, the wireless port will hang up the call automatically; otherwise, it will make an outgoing call to the number. The default value is <i>disabled</i> .
Maximum Wait Time for PSTN Outgoing Calls	Sets the maximum wait time waiting for the called party pickup during an outgoing call. Range of value: 5~120, calculated by s, with the default value of 60.
Dial Interval	Sets the largest interval between two digits of a dialing number. Range of value: 1~10, calculated by s, with the default value of 6. In case your dialing rules do not include ".", the call will fail if there is no digit dialed or no dialing rule matched during this interval; in case your dialing rules include ".", the gateway will wait until this interval ends and match to the dialing rule "." if there is no digit dialed or no other dialing rule matched during this interval.
Waiting for Idle Time	Set the waiting time of the channel before it goes into the idle state after the call finishes. The default value is 1500ms, and the value range is 0~60000.

Busy Tone Detection Mode	Sets the busy tone detection mode, three options available: Common (hangup on busy), Delayed (Delayed hangup on busy), Undetected (no busy detection). By default it is set to Common.
Auto Hangup upon Ringback	This feature is only supported by the GSM module. Note that when it is enabled, you are required to set 'SIP compatibility-Occasion to Reply 183' after ringing.
Communication without Network	Automatically routes a call to the wireless port in case of network failure or call timeout. The default value is <i>disabled</i> .
IP→Tel Call Failure, Auto Transfer	Sets whether to enable the feature of transferring the call to a designated IP automatically when a call from IP to Tel fails, with the default value of <i>disable</i> . If this feature is enabled, you are required to enter Target Number (Registered) or Target IP and Target Port (Unregistered).
Tel → IP Call Failure, Auto SMS Reply	Sets whether to enable the feature of automatic SMS reply when a call from Tel to IP fails, with the default value of <i>disable</i> . The following four options will be available if this feature is enabled. They are Unconnected, No Answer, Rejected, Fail to Connect. You can select any one of them and define the corresponding content to reply.
Auto Disable Module if Fail to Register to SIP Server	Once this feature is enabled, the gateway will automatically close this SIM card module to achieve the feature "Communication without Network" when it failed to register to the SIP server. The default value is <i>disabled</i> . It works with the feature <i>FWD on Unreachable</i> .
Auto Lock SIM Card after Consecutive Call Failure	When this feature is enabled, the times of call failure reaching the set value will trigger the operation of card locking. Call Failure Mode includes: <i>Busy</i> , <i>No Answer</i> , <i>Dial Failure</i> . Locking Time means the time of the port being locked: -1 means the card is always being locked; 0 means the card is unlocked; other values mean the exact time of the card being locked. When the feature 'Unlock by Plugging SIM Card in and out' is enabled, the port will be unlocked after you plug in and out the SIM card.
Auto Reconnect to BS after Consecutive Call Failure	When the outgoing calls from a port has failed for several times consecutively: for the SMG4004/SMG4008 series, the gateway will automatically reconnect the SIM card on this port to the base station; for the SMG4016/SMG4032 series, the gateway will automatically switch to other card slots available for the port and reconnect, the SIM card to the base station if there is no available card slot.
Record SIM Number at Gateway Restart	Once this feature is enabled, the number of the SIM card will be recorded when the gateway restarts and this SIM card will recover to work after restarting. The default value is <i>enabled</i> .
Work Mode	Sets the work mode for the echo canceller. There are two options: <i>Near-end cancellation</i> and <i>Both near-end and far-end cancellation</i> , with the default value of <i>Near-end cancellation</i> .
Non-linear Processing	Sets whether to enable the mode of non-linear processing. By default, this feature is <i>enabled</i> .
Fixed Window Size	Sets the size of the window for the fixed cancellation.
Moving Window Size	Sets the size of the window for the moving cancellation.

3.5.4 Dialing Rule

Considering efficiency, it is not acceptable that the gateway reports to the PBX or relevant devices every time it receives a number. Instead, we hope that the gateway can automatically judge the received number to see if it meets the set rule, if it is complete and if it is qualified to make outgoing calls. Therefore, a whole dialing plan, which consists of multiple dialing rules specifying the auto judging conditions, is required. Each dialing rule has a priority, which is used to restrict the sequence and avoid conflict.

Standard Mode

Character Mode

Dialing Rule				
Check	Index	Dialing Rule	Description	Modify
<input type="checkbox"/>	81	400xxxxxxx	default	
<input type="checkbox"/>	82	40[1-9]xxxx	default	
<input type="checkbox"/>	83	4[1-9]xxxxxx	default	
<input type="checkbox"/>	84	800xxxxxxx	default	
<input type="checkbox"/>	85	80[1-9]xxxx	default	
<input type="checkbox"/>	86	8[1-9]xxxxxx	default	
<input type="checkbox"/>	87	[2-3,5-7]xxxxxxx	default	
<input type="checkbox"/>	88	1[3-5,7-8]xxxxxxxxxxx	default	
<input type="checkbox"/>	89	100xx	default	
<input type="checkbox"/>	90	95xxx	default	
<input type="checkbox"/>	91	123xx	default	
<input type="checkbox"/>	92	111xx	default	
<input type="checkbox"/>	93	11[0,2-9]	default	
<input type="checkbox"/>	94	120	default	
<input type="checkbox"/>	95	0[3-9]xxxxxxxxxxx	default	
<input type="checkbox"/>	96	02xxxxxxxxxxx	default	
<input type="checkbox"/>	97	010xxxxxxxxxxx	default	
<input type="checkbox"/>	98	01[3-5,7-8]xxxxxxxxxxx	default	
<input type="checkbox"/>	99	.	default	

Check All

Uncheck All

Inverse

Delete

Clear All

Add New

19 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-32 Dialing Rule Configuration Interface (Standard)

See Figure 3-32 for the Dialing Rule Configuration interface under the standard mode. The list in the above figure shows the dialing rules with their priorities and description, which can be added by the **Add New** button on the bottom right corner. See Figure 3-33 for the dialing rule adding interface.

Dialing Rule

Index: 98 ▼

Description:

Dialing Rule:

Figure 3-33 Add New Dialing Rule


The table below explains the items shown in Figure 3-33.

Item	Description																													
Index	The unique index of each dialing rule, which denotes its priority. A dialing rule with a smaller index value has a higher priority and will be checked earlier while matching.																													
Description	Remarks for the dialing rule. It can be any information, but not be left empty.																													
Dialing Rule	Up to 100 dialing rules can be configured in the gateway, and the maximum length of each dialing rule is 127 characters. See below for the meaning of each character in the dialing rule. The gateway will do instant matching for your dialing number based on the dialing rule and regard your dialing as finished upon receiving '#' or dialing timeout.																													
	<table><tr><th>Character</th><th>Description</th></tr><tr><td>"0"~"9"</td><td>Digits 0~9.</td></tr><tr><td>"A"~"D"</td><td>Letters A~D.</td></tr><tr><td>"x"</td><td>A random number. A string of 'x's represents several random numbers. For example, 'xxx' denotes 3 random numbers.</td></tr><tr><td>"."</td><td>'.' indicates a random amount (including zero) of characters after it.</td></tr><tr><td>"[]"</td><td>'[]' is used to define the range for a number. Values within it only can be digits '0~9', punctuations '-' and ','. For example, [1-3,6,8] indicates any one of the numbers 1, 2, 3, 6, 8.</td></tr><tr><td>"_"</td><td>'-' is used only in '[]' between two numbers to indicates any number between these two numbers.</td></tr><tr><td>" , "</td><td>',' is used to separate numbers or number ranges, representing alternatives.</td></tr><tr><td>"*"</td><td>Only represents symbol "*".</td></tr><tr><td>"#"</td><td>Only set it at the beginning of the string, representing symbol "#".</td></tr></table>	Character	Description	"0"~"9"	Digits 0~9.	"A"~"D"	Letters A~D.	"x"	A random number. A string of 'x's represents several random numbers. For example, 'xxx' denotes 3 random numbers.	"."	'.' indicates a random amount (including zero) of characters after it.	"[]"	'[]' is used to define the range for a number. Values within it only can be digits '0~9', punctuations '-' and ','. For example, [1-3,6,8] indicates any one of the numbers 1, 2, 3, 6, 8.	"_"	'-' is used only in '[]' between two numbers to indicates any number between these two numbers.	" , "	',' is used to separate numbers or number ranges, representing alternatives.	"*"	Only represents symbol "*".	"#"	Only set it at the beginning of the string, representing symbol "#".									
	Character	Description																												
	"0"~"9"	Digits 0~9.																												
	"A"~"D"	Letters A~D.																												
	"x"	A random number. A string of 'x's represents several random numbers. For example, 'xxx' denotes 3 random numbers.																												
	"."	'.' indicates a random amount (including zero) of characters after it.																												
	"[]"	'[]' is used to define the range for a number. Values within it only can be digits '0~9', punctuations '-' and ','. For example, [1-3,6,8] indicates any one of the numbers 1, 2, 3, 6, 8.																												
	"_"	'-' is used only in '[]' between two numbers to indicates any number between these two numbers.																												
	" , "	',' is used to separate numbers or number ranges, representing alternatives.																												
"*"	Only represents symbol "*".																													
"#"	Only set it at the beginning of the string, representing symbol "#".																													
There are 19 dialing rules already configured on the gateway for easy use. See below for detailed information.																														
<table><tr><th>Priority</th><th>Dialing Rule</th><th>Description</th></tr><tr><td>99</td><td>.</td><td>Any number in any length.</td></tr><tr><td>98</td><td>01[3-5,7-8]xxxxxxxx.</td><td>Any 12-digit number starting with 013, 014, 015, 017 or 018</td></tr><tr><td>97</td><td>010xxxxxxxx</td><td>Any 11-digit number starting with 010</td></tr><tr><td>96</td><td>02xxxxxxxx</td><td>Any 11-digit number starting with 02</td></tr><tr><td>95</td><td>0[3-9]xxxxxxxx</td><td>Any 12-digit number starting with 03, 04, 05, 06, 07, 08 or 09</td></tr><tr><td>94</td><td>120</td><td>Number 120.</td></tr><tr><td>93</td><td>11[0,2-9]</td><td>Number 110, 112, 113, 114, 115, 116, 117, 118 or 119</td></tr><tr><td>92</td><td>111xx</td><td>Any 5-digit number starting with 111</td></tr><tr><td>91</td><td>123xx</td><td>Any 5-digit number starting with 123</td></tr></table>	Priority	Dialing Rule	Description	99	.	Any number in any length.	98	01[3-5,7-8]xxxxxxxx.	Any 12-digit number starting with 013, 014, 015, 017 or 018	97	010xxxxxxxx	Any 11-digit number starting with 010	96	02xxxxxxxx	Any 11-digit number starting with 02	95	0[3-9]xxxxxxxx	Any 12-digit number starting with 03, 04, 05, 06, 07, 08 or 09	94	120	Number 120.	93	11[0,2-9]	Number 110, 112, 113, 114, 115, 116, 117, 118 or 119	92	111xx	Any 5-digit number starting with 111	91	123xx	Any 5-digit number starting with 123
Priority	Dialing Rule	Description																												
99	.	Any number in any length.																												
98	01[3-5,7-8]xxxxxxxx.	Any 12-digit number starting with 013, 014, 015, 017 or 018																												
97	010xxxxxxxx	Any 11-digit number starting with 010																												
96	02xxxxxxxx	Any 11-digit number starting with 02																												
95	0[3-9]xxxxxxxx	Any 12-digit number starting with 03, 04, 05, 06, 07, 08 or 09																												
94	120	Number 120.																												
93	11[0,2-9]	Number 110, 112, 113, 114, 115, 116, 117, 118 or 119																												
92	111xx	Any 5-digit number starting with 111																												
91	123xx	Any 5-digit number starting with 123																												

	90	95xxx	Any 5-digit number starting with 95
	89	100xx	Any 5-digit number starting with 100
	88	1[3-5,7-8]xxxxxxxx	Any 11-digit number starting with 13, 14, 15, 17 or 18
	87	[2-3,5-7]xxxxxxx	Any 8-digit number starting with 2, 3, 5, 6 or 7
	86	8[1-9]xxxxxx	Any 8-digit number starting with 81, 82, 83, 84, 85, 86, 87, 88 or 89
	85	80[1-9]xxxxx	Any 8-digit number starting with 801, 802, 803, 804, 805, 806, 807, 808 or 809
	84	800xxxxxxx	Any 10-digit number starting with 800
	83	4[1-9]xxxxxx	Any 8-digit number starting with 41, 42, 43, 44, 45, 46, 47, 48 or 49.
	82	40[1-9]xxxxx	Any 8-digit number starting with 401, 402, 403, 404, 405, 406, 407, 408 or 409
	81	400xxxxxxx	Any 10-digit number starting with 400

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-32 to modify the dialing rules. See Figure 3-34 for the dialing rule modification interface. The configuration items on this interface are the same as those on the **Add New Dialing Rule** interface.



The image shows a 'Dialing Rule' configuration window. It has a title bar 'Dialing Rule'. Inside, there are three input fields: 'Index:' with a dropdown menu showing '99', 'Description:' with a text box containing 'test', and 'Dialing Rule:' with a text box containing 'xxx'. At the bottom, there are two buttons: 'Save' and 'Close'.

Figure 3-34 Modify Dialing Rule

To delete a dialing rule, check the checkbox before the corresponding index in Figure 3-32 and click the '**Delete**' button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all dialing rules at a time, click the **Clear All** button in Figure 3-32.

See Figure 3-35 for the Dialing Rule Configuration interface under the Character mode. You can edit the dialing rule list to add a new one or modify an old one. The exact meaning of each rule element is described on the page.

Standard Mode | Character Mode

Dialing Rule

Note: The Dialing Rule contains such fields as Dialing Rule and Description.
The priority decreases from top to bottom; adjacent fields are separated by a space; Symbol . denotes any string.
Don't forget to save the configuration after your modification!

400xxxxxx default
40[1-9]xxxx default
4[1-9]xxxxxx default
800xxxxxx default
80[1-9]xxxx default
8[1-9]xxxxxx default
[2-3,5-7]xxxxxx default
1[3-5,7-8]xxxxxxxx default
100xx default
95xxx default
123xx default
111xx default
11[0,2-9] default
120 default
0[3-9]xxxxxxxxxx default

20 Items Total

Save

Figure 3-35 Dialing Rule Configuration Interface (Character)

3.5.5 Function Key

See Figure 3-36 for the function key configuration interface where you can set a cluster of combination keys. An external phone can dial the wireless port and press the combination keys after hearing the speech prompt “Please dial the extension number” to query or set the network port.

Function	Enable	Function Key	Mode
Query LAN	<input checked="" type="checkbox"/>	*11*	Default ▼
Set LAN	<input checked="" type="checkbox"/>	*61*	Default ▼

Note: Please enable the feature of "Two Stage Dialing for Incoming Call" before using the function key.

Save

Figure 3-36 Function Key Configuration Interface

Click “Enable” to enable the corresponding function key. The gateway will use the default function keys when the mode is set to default; and it will allow you to set new function keys when the mode is set to user-defined. Click **Save** to save your settings into the gateway.

3.5.6 Cue Tone




Figure 3-37 Cue Tone Interface

See Figure 3-37 for the Cue Tone interface. The table below explains the items shown in the above figure.

Item	Description
Language	Sets the language for the gateway to play voice, including two options Chinese and English. The default setting is <i>English</i> .
Upload a file of cue tone	Uploads a user-defined cue tone file to the gateway.
Two Stage Dialing for PSTN Outgoing Calls Tips	Sets the cue tone of two stage dialing for the PSTN outgoing calls, including two options: Dial Tone and File Playback. You are required to upload a file for playing if File Playback is selected.

Click **Save** to save the above settings into the gateway.

3.5.7 Color Ring





Figure 3-38 Color Ring Interface

By default, there is no available color ring on the gateway. See Figure 3-38. Click **Upload** to upload a new color ring manually. Follow Figure 3-39 to upload the required color ring file to the gateway.




The interface is titled "Color Ring-Upload". It contains three input fields: "Index" with a dropdown menu showing "1", "Description" with a text box containing "default", and "Color Ring" with a file selection area and a "Browse..." button. Below these fields is a note: "Note: The file should be a wav file with 8000Hz sampling rate, 16-bit mono, A-law formatted, and less than 200KB in size." At the bottom are two buttons: "Upload" and "Return".

Figure 3-39 Color Ring Upload Interface

The table below explains the items shown above:

Item	Description
Index	The unique index of each color ring to be uploaded.
Description	It is user-defined, with the default value of <i>default</i> .
Color Ring	The file of the color ring to be uploaded.


After configuration, click **Upload** to upload the color ring file to the gateway or click **Return** to cancel the upload. See Figure 3-40 for the Color Ring Management interface after the upload.



The interface is titled "Color Ring Manage". It features a table with columns: Check, Index, Color Ring, Port, Port Group, and Modify. The table contains one row with Index "1", Color Ring "default", Port "--", Port Group "--", and a Modify icon. Below the table are buttons: "Check All", "Uncheck All", "Inverse", "Delete", "Clear All", and "Upload". At the bottom is a pagination bar showing "1 Item Total", "20 Items/Page", "1/1", "First", "Previous", "Next", "Last", "Go to Page", "1", and "1 Pages Total".

Figure 3-40 Color Ring Management Interface

Click **Modify** in Figure 3-40 to modify the configuration of the color ring. See below for the color ring modification interface. The configuration items on this interface are the same as those on the **Color Ring Upload** interface.



The interface is titled "Color Ring-Modify". It contains three input fields: "Index" with a text box showing "1", "Description" with a text box showing "default", and "Upload" with a checkbox. At the bottom are two buttons: "Save" and "Cancel".

Figure 3-41 Color Ring Modification Interface

To delete a color ring, check the checkbox before the corresponding index in Figure 3-40 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck**

All means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all color rings at a time, click the **Clear All** button in Figure 3-40.

3.5.8 QoS

Figure 3-42 Differentiated Services Setting Interface

See Figure 3-42 for the Differentiated Services setting interface. Using this technology, the gateway can meet various application requirements under a limited bandwidth and ensure neither delay nor discard for important services so as to improve its quality of services.

The table below explains the items shown in the above figure.

Item	Description
QoS	Sets whether to enable the QoS differentiated services. By default, it is disabled.
Media Premium QoS	Sets the priority of the media premium for QoS. A media premium QoS with a bigger value has a higher priority. The value range is 0~63, with the default value of 46.
Control Premium QoS	Sets the priority of the control premium for QoS. A control premium QoS with a bigger value has a higher priority. The value range is 0~63, with the default value of 26.

3.5.9 Tone Generator

Tone Generator	
Tone Energy (dB) <input type="text" value="0"/>	
Dial Tone <input type="text" value="450/1500"/>	<p>FreqA/TimeA,FreqB+FreqC/TimeB Repeatedly play tones in turn: first, TimeA, a single tone with FreqA, then, Time B, a dual tone composed of FreqB and FreqC.</p>
Ringback Tone <input type="text" value="450/1000,0/4000"/>	<p>FreqA+FreqB+FreqC/TimeA,FreqD/TimeB Repeatedly play tones in turn: first, TimeA, a triple tone composed of FreqA, FreqB and FreqC, then, TimeB, a single tone with FreqD.</p>
Busy Tone <input type="text" value="450/350,0/350"/>	<p>Note: The play time is calculated by ms and cannot be larger than 16383ms for each toneunit. A tone is allowed to contain at most 5 different toneunits and 4 different frequencies, but the frequency and duration of the first toneunit cannot be 0. Frequency being 0 means the toneunit is a piece of silence.</p>
<div> <input type="button" value="Save"/> <input type="button" value="Reset"/> </div>	

Figure 3-43 Tone Generator Setting Interface

See Figure 3-43 for the Tone Generator Setting interface. By default, there are three tones on it: Dial Tone—a single tone with 450HZ frequency, plays continuously; Ringback Tone—a single tone with 450HZ frequency, repeatedly playing in the method of 1s play and 4s pause; Busy Tone—a single tone with 450HZ frequency, repeatedly playing in the method of 350ms play and 350ms pause. You can configure the tone generator manually. The exact explanation about the format and the meaning is described on the right of the interface. The value range of the tone energy herein above is -12~17, calculated by dB, with the default value of 0.

3.5.10 CDR Query

CDR Inquire

Starting Date: 2015-10-22

Ending Date: 2015-10-23

Port: All

Call Direction: All

CallerID:

CalleeID:

Call Duration(s): -- --

Query

Figure 3-44 CDR Query Setting Interface

See Figure 3-44 for the CDR Query Setting interface. The table below explains the items shown in the above figure.

Item	Description
Starting Date, Ending Date	Sets the starting and ending dates for CDR query.
Port	Sets the port on which CDR query will proceed.
Call Direction	Sets the call direction for CDR query.
CallerID, CalleeID	Sets the CallerID/CalleeID for CDR query.
Call Duration	Sets the minimum/maximum call duration for CDR query.

Click **Query** to query the CDR information corresponds to the above settings.

CDR Info [CDR Export](#)

Port	Starting Time	Answer Time	Call Direction	CallerID	CallerIP	CalleeID	Hungup Side	Pending Reason	Call Duration(s)
2	2015-10-23 16:37:47	2015-10-23 16:37:47	Tel->IP	057188861158	---	---	Gateway	MATCH_DIALDIGIT_FAILED	13

Delete All

1 Item Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-45 CDR Information Interface

Note: This page will appear only when the CDR feature is enabled (set in [3.5.2 System Param](#)).

3.5.11 VPN

VPN Settings

Enable OPENVPN

☐ Yes ☒ No

Save

Figure 3-46 VPN Settings Interface

Thanks to the embedded VPN Client, the wireless gateway can access the VPN network via OPENVPN directly, not requiring extra VPN client, which simplifies the network deployment. Meanwhile, the design of both SIP signaling messages and voice streams transporting via VPN avoids possible problems induced by the SIP protocol in passing through the firewall and NAT. See Figure 3-46 for the VPN Settings interface. The table below gives the explanation to the items shown in the above figure.

Item	Description
Enable OPENVPN	Sets whether to enable the VPN feature, with the default value of <i>No</i> . If this feature is enabled, the gateway will work as a VPN client.

You are required to upload the VPN certificate after enabling the VPN feature. See Figure 3-47.

Figure 3-47 VPN Certificate Upload Interface

Note: Refer to [Appendix C About VPN](#) for how to make a VPN certificate.

3.6 Wireless Settings

Wireless Settings includes the following parts: **Basic Param**, **Wireless Param**, **Call Forwarding**, **Short Message**, **IMEI (GSM&WCDMA series)**, **USSD (GSM&WCDMA series)**, **Email**, **SIM Card**, **PIN Manage**, **BS Select (GSM series)**, **Networking Setting (WCDMA series)**, **AMD (CDMA series)** and **Hidden CallerID (WCDMA series)**. See Figure 3-48, Figure 3-49 and Figure 3-50.




Figure 3-48 Wireless Settings for GSM




Figure 3-49 Wireless Settings for WCDMA




Figure 3-50 Wireless Settings for CDMA

3.6.1 Basic Parameters

Basic Parameters		
Voice	GSM Voice Encoding	Automatic
DTMF	GSM DTMF Send Mode	Voice Playback
	DTMF Transmission Intensity	6
	Duration at ON (ms)	120
	Duration at OFF (ms)	100
	Disconnect Voice while Sending DTMF	No
	GSM DTMF Receive Mode	Wireless Module Receive
	DTMF Voltage Detection for GSM	Off 0ms On 40ms
SMS	SMS Sending Interval(s)	1
	Maximum Pieces of Saved Logs	100
	SMS Receipt	Disable
Call Forwarding	AT Command Mode	CCFC Command Mode
SIP Answer Code	Busy/Rejected	486
	No Answer	408
	Other Fault	480
		Save Reset

Figure 3-51 Basic Parameters Setting Interface for GSM

Basic Parameters		
Voice	WCDMA Voice Encoding	AMR
Network	Network Scan Mode	Automatic
	Network Scan Sequence	Automatic
DTMF	WCDMA DTMF Send Mode	Voice Playback
	DTMF Transmission Intensity	1
	Duration at ON (ms)	120
	Duration at OFF (ms)	100
	Disconnect Voice while Sending DTMF	No
	WCDMA DTMF Receive Mode	Wireless Module Receive
SMS	SMS Sending Interval(s)	1
	Maximum Pieces of Saved Logs	100
	SMS Receipt	Disable
Call Forwarding	AT Command Mode	CCFC Command Mode
SIP Answer Code	Busy/Rejected	486
	No Answer	408
	Other Fault	480
		<div>Save</div> <div>Reset</div>

Figure 3-52 Basic Parameters Setting Interface for WCDMA

Basic Parameters		
DTMF		
CDMA DTMF Send Mode	Voice Playback	
Duration at ON (ms)	120	
Duration at OFF (ms)	100	
Disconnect Voice while Sending DTMF	No	
CDMA DTMF Receive Mode	Chip Receive	
Minimum Duration at ON	28 ms	
SMS		
SMS Sending Interval(s)	1	
Maximum Pieces of Saved Logs	100	
Call Forwarding		
AT Command Mode	ATD Command Mode	
Set/Cancel Service Number. for FWD Unconditionally	*72	*720
Set/Cancel Service Number. for FWD on Busy	*90	*900
Set/Cancel Service Number. for FWD on No Reply	*92	*920
Set/Cancel Service Number. for FWD on Unreachable	*68	*680
Cancel All FWD Service Numbers	*730	
Cancel All Waiting Service Numbers	*740	
SIP Answer Code		
Busy/Rejected	486	
No Answer	408	
Other Fault	480	
<div>Save</div> <div>Reset</div>		

Figure 3-53 Basic Parameters Setting Interface for CDMA

Basic Parameters

Voice

LTE Voice Encoding

AMR

VoLTE

Enable

Network

Network Scan Mode

Automatic

Network Scan Sequence

Automatic

DTMF

LTE DTMF Send Mode

Remote Transmission

Duration at ON (ms)

120

Duration at OFF (ms)

100

Disconnect Voice while Sending DTMF

No

LTE DTMF Receive Mode

Wireless Module Receive

SMS

SMS Sending Interval(s)

1

Maximum Pieces of Saved Logs

100

SMS Receipt

Disable

Call Forwarding

AT Command Mode

CCFC Command Mode

SIP Answer Code

Busy/Rejected

486

No Answer

408

Other Fault

480

Save

Reset

Figure 3-54 Basic Parameters Setting Interface for LTE

See Figure 3-51, Figure 3-52, Figure 3-53, Figure 3-54 for the basic parameters setting interface. The table below explains the items shown in the above figures.

Item	Description
GSM (WCDMA/LTE) Voice Encoding	Sets the mode of the GSM (WCDMA/LTE) voice encoding. By default, the voice encoding for GSM is <i>Automatic</i> and for WCDMA/LTE is <i>AMR</i> .
VoLTE	Once this feature is enabled, the 4G function will be enabled when there is a call ongoing on; Otherwise, only 2G or 3G function is available.
GSM (WCDMA/CDMA/LTE) DTMF Send Mode	Sets the mode to send the GSM (WCDMA/CDMA/LTE) DTMF, three options available for GSM (WCDMA/CDMA): Voice Playback, Remote Transmission and Chip Transmission. The default value is <i>Voice Playback</i> . Two options are available for LTE: Remote Transmission and Chip Transmission. The default value is <i>Remote Transmission</i> .
DTMF Transmission Intensity	Sets the transmission intensity of the DTMF. The default values for the GSM gateway and the WCDMA gateway are respectively 6 and 1.

	<p>Note:</p> <p>1, This configuration item is unsupported when the DTMF send mode is set to Remote Transmission;</p> <p>2, This configuration item is unsupported for the CDMA gateway.</p>
Duration at ON	Sets the duration of the DTMF signal at ON state, calculated by ms. The default value is 120.
Duration at OFF	Sets the duration of the DTMF signal at OFF state, calculated by ms. The default value is 100.
Disconnect Voice while Sending DTMF	<p>Sets whether to disconnect the voice channel while sending the DTMF, with the default value of No.</p> <p>Note: This configuration item is unsupported when the DTMF send mode is set to Remote Transmission;</p>
GSM (WCDMA/CDMA/LTE) DTMF Receive Mode	Sets the mode to receive the GSM (WCDMA/CDMA/LTE) DTMF, two options available: Chip Receive and Wireless Module Receive. The default values for GSM WCDMA and LTE are <i>Wireless Module Receive</i> ; the default value for CDMA is <i>Chip Receive</i> .
DTMF Voltage Detection for GSM	Set the On and off of the DTMF detection for GSM.
Network Scan Mode	Sets a network for the call, three options available for the WCDMA gateway: Automatic, GSM Only and WCDMA Only. The default value is <i>Automatic</i> . Nine options are available for the LTE gateway: Automatic, GSM Only, WCDMA Only, LTE Only, TD-SCDMA Only, UMTS Only, CDMA Only, HDR Only, CDMA and EVDO Only. The default value is <i>Automatic</i>
Network Scan Sequence	Sets the priority of the network, three options available for the WCDMA gateway: <i>Automatic</i> , <i>GSM prior to WCDMA</i> and <i>WCDMA prior to GSM</i> . The default value is <i>Automatic</i> . Only the option Automatic is available for the LTE gateway.
SMS Sending Interval	Sets the interval to send SMS for each port. Range of value: 1~60, with the default value of 1.
Maximum Pieces of Saved Logs	Sets the amount of the logs to be saved for each port. Range of value: 50~500, with the default value of 100.
SMS Receipt	<p>Once this feature is enabled, the gateway will receive a receipt upon the remote side receiving the SMS.</p> <p>Note: This configuration item is unsupported for the CDMA gateway.</p>
AT Command Mode	Sets the AT command sent with the call forwarding. There are two options available: CCFC command mode and ATD command mode. The GSM gateways support both modes, while the WCDMA/LTE gateways only support the CCFC command mode and the CDMA gateways only support the ATD command mode.
Set/Cancel Service Number for FWD Unconditionally, Set/Cancel Service Number for FWD on Busy, Set/Cancel	Sets or Cancels the service No. for FWD unconditionally, FWD on busy, FWD on no reply or FWD Unreachable. The former box is used to set the service No, while the latter one is to cancel the service No,.

Service Number for FWD on No Reply, Set/Cancel Service Number for FWD on Unreachable	
Cancel All FWD Service Numbers	Used to cancel all service numbers for FWD unconditional, FWD on busy and FWD on no reply.
Cancel All Waiting Service Numbers	Used to cancel the service number for call waiting.
SIP Answer Code	Sets the SIP answer code for each state of the called party.

Click Save to save the setting into the gateway, click Reset to restore the configurations.

3.6.2 Wireless Param

















Wireless Param														Export ICCID
Check	Port	Cell Phone No.	IP→GSM Voice Volume	GSM→IP Voice Volume	IMSI	ICCID(Card A)	ICCID(Card B)	ICCID(Card C)	ICCID(Card D)	IMEI	Operator	Working Frequency Band	Status	Modify
<input type="checkbox"/>	1	13750845957	3	70	460000842532641	---	---	89860075111651005239	---	865740032035615	CHINA MOBILE	GSM850_EGSM_DCS_PCS_MODE	Enable	
<input type="checkbox"/>	2	13588242026	3	70	460008470848142	---	---	89860058111551226475	---	865740032294048	CHINA MOBILE	GSM850_EGSM_DCS_PCS_MODE	Enable	
<input type="checkbox"/>	3	13082813431	3	70	460012818007570	---	---	89860114838051438050	---	865740032436771	CHINA UNICOM GSM	GSM850_EGSM_DCS_PCS_MODE	Enable	
<input type="checkbox"/>	4	---	3	70	---	---	---	---	---	865740032338258	---	---	Enable	
<input type="checkbox"/>	5	---	3	70	---	---	---	---	---	864504037182322	---	---	Enable	
<input type="checkbox"/>	6	---	3	70	---	---	---	---	---	864504037182108	---	---	Enable	
<input type="checkbox"/>	7	---	3	70	---	---	---	---	---	865740032297207	---	---	Enable	
<input type="checkbox"/>	8	---	3	70	---	---	---	---	---	865740032309382	---	---	Enable	
<input type="checkbox"/>	9	---	3	70	---	---	---	---	---	865740032309598	---	---	Enable	
<input type="checkbox"/>	10	---	3	70	---	---	---	---	---	865740032295953	---	---	Enable	
<input type="checkbox"/>	11	---	3	70	---	---	---	---	---	865740032191673	---	---	Enable	
<input type="checkbox"/>	12	---	3	70	---	---	---	---	---	865740032353802	---	---	Enable	
<input type="checkbox"/>	13	---	3	70	---	---	---	---	---	865740032109402	---	---	Enable	
<input type="checkbox"/>	14	---	3	70	---	---	---	---	---	865740032214632	---	---	Enable	
<input type="checkbox"/>	15	---	3	70	---	---	---	---	---	865740032214558	---	---	Enable	
<input type="checkbox"/>	16	---	3	70	---	---	---	---	---	865740032205473	---	---	Enable	
Check All Uncheck All Get number Disable Enable														

Figure 3-55 Wireless Parameters Configuration Interface

See Figure 3-55 for the Wireless Parameters Configuration interface. Click **Modify** in Figure 3-55 to modify the properties of the corresponding module. See Figure 3-56 for the Wireless Parameters Modification interface.

Wireless Param-Modify

Port 1 ▼

Cell Phone No. 13750845957

Auto Get Cell Phone No.

Query Mode SMS ▼

Destination Number 10086

Content to Send 102

Keywords to Match 号码

Bits of Prefix to be Removed from Phone No. 0

Get Phone No after SIM Card Registration No ▼

IP→GSM Voice Volume 3 (Range:0-15)

GSM→IP Voice Volume 70 (Range:0-100)

Operator Auto Select ▼

Apply to all the modules (Cell Phone No. excluded) ☐

Modify

Reset

Back

Figure 3-56 Wireless Parameters Modification Interface

The table below explains the configuration items on the Wireless Parameters Modification interface.

Item	Description
Port	The number of the port corresponding to the wireless module.
Cell Phone No.	The number of the SIM card corresponding to the wireless module. This number should be configured manually.
Query Mode	It is supported to acquire the SIM card number by two modes SMS and USSD.
Destination Number	Sets the destination number to receive the short message.
Content to Send	Sets the content of the short message.
Keywords to Match	Sets the keywords used to get the cell phone No. from the received SMS.
Bits of Prefix to be Removed from Phone No.	Sets the bits of the prefix to be removed from the cell phone No.. Up to 4 bits can be removed.
Get Phone No. after SIM Card Registration	Sets whether to get the cell phone No. after the SIM card being registered successfully.
IP→GSM(WCDMA/CDMA) Voice Volume	The volume of the voice from IP to GSM/WCDMA/CDMA. By default, the value for GSM is 3; the value for WCDMA is 10000; the value for CDMA is 1; the value for SIMCOM is 10400.

GSM(WCDMA/CDMA)->IP Voice Volume	The volume of the voice from GSM/WCDMA/CDMA to IP. By default, the value for GSM is 70; the value for WCDMA is 3; the value for CDMA is 2; the value for SIMCOM is 7000.
IMSI	International Mobile Subscriber Identification Number, the unique identity of the SIM card.
ICCID	Integrate Circuit Card Identity (ICCID) is just the SIM card number which serves as the identification card of a phone number. It is the unique identification number of the IC card, consisting of 20 digits.
IMEI	International Mobile Equipment Identity. Note: This configuration item is unsupported for the CDMA gateway.
Operator	The operator of the wireless module. It is obtained automatically. This configuration is unavailable for CDMA module.
Working Frequency Band	Displays the working frequency band of the wireless module. This configuration is unavailable for CDMA module.
Status	Displays the current state of the wireless module.
Apply to all the modules	Sets whether to apply all the settings except for the cell phone number to all the modules.

Click **Modify** to save the settings into the gateway, click **Reset** to restore the configurations, or click **Back** to cancel the settings.

3.6.3 Call Forwarding

Call Forwarding									
Check	Port	Cell Phone No.	FWD Unconditionally	FWD on Busy	FWD on No Reply	FWD on Unreachable	FWD Setting Status	FWD Query Status	Modify
<input type="checkbox"/>	1	---	---	---	---	---	---	---	--
<input checked="" type="checkbox"/>	2	13023618645	---	---	---	---	---	---	
<input type="checkbox"/>	3	---	---	---	---	---	---	---	--
<input checked="" type="checkbox"/>	4	13023634112	---	---	---	---	---	---	
<input type="checkbox"/>	5	---	---	---	---	---	---	---	--
<input type="checkbox"/>	6	---	---	---	---	---	---	---	--
<input type="checkbox"/>	7	---	---	---	---	---	---	---	--
<input type="checkbox"/>	8	---	---	---	---	---	---	---	--

Figure 3-57 Call Forwarding Configuration Interface

See Figure 3-57 for the Call Forwarding Configuration interface. The table below explains the items shown in the above figure.

Item	Description
Port	The number of the port corresponding to the wireless module.
Cell Phone No.	The number of the SIM card corresponding to the wireless module.
FWD Unconditionally	Sets whether to enable the feature of FWD unconditionally and the FWD number if it is enabled.
FWD on Busy	Sets whether to enable the feature of FWD on busy and the FWD number if it is enabled. Note: Be sure to disable the Call Waiting feature before using it.
FWD on No Reply	Sets whether to enable the feature of FWD on no reply and the FWD number if it is

	enabled.
FWD on Unreachable	Sets whether to enable the feature of FWD on unreachable and the FWD number if it is enabled.
FWD Setting Status	Displays the setting status of the call forwarding service.
FWD Query Status	Displays the query status of the FWD settings. This configuration is unavailable for CDMA module.
Cancel All	Cancels all the setting on call FWD service. This item will appear if none of the call FWD is selected.

Click **Modify** in Figure 3-57 to modify the properties of the corresponding port. See Figure 3-58 for the call forwarding modification interface. Then click **Modify** to save the settings into the gateway. It will take some time to apply the settings, and you can check the result in the 'FWD Setting Status' column. Click **Reset** to restore the configurations, or click **Cancel** to cancel the settings.

Figure 3-58 Wireless Service Modification Interface

3.6.4 Short Message

Short Message						
Check	Port	Cell Phone No.	SMS Center	Inbox	Outbox	Send SMS
<input type="checkbox"/>	1	---	---	[0] A[0] B[0] C[0] D[0]	[1] A[1] B[0] C[0] D[0]	--
<input type="checkbox"/>	2	---	---	[0] A[0] B[0] C[0] D[0]	[0] A[0] B[0] C[0] D[0]	--
<input type="checkbox"/>	3	13750843861	8613800571500	[1] A[1] B[0] C[0] D[0]	[1] A[1] B[0] C[0] D[0]	
<input type="checkbox"/>	4	---	---	[0] A[0] B[0] C[0] D[0]	[0] A[0] B[0] C[0] D[0]	--
<input type="checkbox"/>	5	---	---	[0] A[0] B[0] C[0] D[0]	[0] A[0] B[0] C[0] D[0]	--
<input type="checkbox"/>	6	---	---	[0] A[0] B[0] C[0] D[0]	[0] A[0] B[0] C[0] D[0]	--
<input type="checkbox"/>	7	---	---	[0] A[0] B[0] C[0] D[0]	[0] A[0] B[0] C[0] D[0]	--
<input type="checkbox"/>	8	---	---	[0] A[0] B[0] C[0] D[0]	[0] A[0] B[0] C[0] D[0]	--
<input type="checkbox"/>	9	---	---	[0] A[0] B[0] C[0] D[0]	[0] A[0] B[0] C[0] D[0]	--
<input type="checkbox"/>	10	---	---	[0] A[0] B[0] C[0] D[0]	[0] A[0] B[0] C[0] D[0]	--
<input type="checkbox"/>	11	---	---	[0] A[0] B[0] C[0] D[0]	[0] A[0] B[0] C[0] D[0]	--
<input type="checkbox"/>	12	---	---	[0] A[0] B[0] C[0] D[0]	[0] A[0] B[0] C[0] D[0]	--
<input type="checkbox"/>	13	---	---	[0] A[0] B[0] C[0] D[0]	[0] A[0] B[0] C[0] D[0]	--
<input type="checkbox"/>	14	---	---	[0] A[0] B[0] C[0] D[0]	[0] A[0] B[0] C[0] D[0]	--
<input type="checkbox"/>	15	---	---	[0] A[0] B[0] C[0] D[0]	[0] A[0] B[0] C[0] D[0]	--
<input type="checkbox"/>	16	---	---	[1] A[0] B[1] C[0] D[0]	[0] A[0] B[0] C[0] D[0]	--
<input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Clear All"/> <input type="button" value="Refresh"/>						

Figure 3-59 Short Message Interface

Short Message						
Check	Port	Cell Phone No.	SMS Center	Inbox	Outbox	Send SMS
<input type="checkbox"/>	1	13750843861	8613800571500	 [0]	 [0]	
<input type="checkbox"/>	2	---	---	 [1]	 [0]	--
<input type="checkbox"/>	3	---	---	 [1]	 [0]	--
<input type="checkbox"/>	4	---	---	 [1]	 [0]	--
<input type="checkbox"/>	5	---	---	 [1]	 [0]	--
<input type="checkbox"/>	6	---	---	 [1]	 [0]	--
<input type="checkbox"/>	7	---	---	 [1]	 [0]	--
<input type="checkbox"/>	8	---	---	 [0]	 [0]	--

Figure 3-60 Short Message Interface for SMG4008

See Figure 3-59, Figure 3-60 for the Short Message interface which displays the related information about the received/sent SMS.

Click **SMS Center** to go into the SMS Center Modification interface. See Figure 3-61. Click **Save** to save the settings into the gateway, click **Close** to cancel the settings.

SMS Center


Port

SMS Center

Figure 3-61 SMS Center Modification Interface

Note: The configuration of SMS Center is unavailable for CDMA gateway.

Click **Inbox** in Figure 3-59 to go into the SMS Receiver Details interface. See Figure 3-62. Such information as the remote cell phone number, the time and the content will be displayed on this page.

Check	No.	Port	Cell Phone No.	Receive/Send	Remote Phone Number	Time	Content
<input type="checkbox"/>	1	4	---	 Receive	10658139125581033464	2017-01-10 09:53:13	12 139



Port4 ▾ Filter

1 Item Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-62 Inbox Interface

To delete a piece of SMS receiving detail, check the checkbox before the corresponding index in Figure 3-62 and click the **Delete** button.

Click **Outbox** in Figure 3-59 to go into the SMS Sending interface. See Figure 3-63. Such information as the send status of the SMS, the remote cell phone number, the time, and the content will be displayed on this page.

Check	No.	Port	Cell Phone No.	Receive/Send	Remote Phone Number	Time	Content	Result	Send Receipt	From
<input type="checkbox"/>	1	1A	---	 Send	13516774256	2017-01-11 11:35:32	Device IP: 201.123.115.179	 Successful	---	SYSTEM

Port1 ▾ All Cards ▾ Filter

1 Item Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-63 Outbox Interface

To delete a piece of record, check the checkbox before the corresponding index in Figure 3-63 and click the **Delete** button. To filter the receive/send short messages according to the setting conditions, click the **Filter** button on the bottom right corner in Figure 3-62 or Figure 3-63. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; to clear all records at a time, click the **Clear All** button; to go back to the previous page, click **Return**.

Click **Send SMS** in Figure 3-59 to go into the Send SMS interface. See Figure 3-64.

Send SMS

Port

Group Send
▼

☒ 01
☐ 02
☐ 03
☐ 04
☐ 05
☐ 06
☐ 07
☐ 08
☐ 09
☐ 10
☐ 11
☐ 12
☐ 13
☐ 14
☐ 15
☐ 16

Check All

Inverse

Number Import

Browse...

Import

Send to

(Separated by ',')

Encoding Format

GSM 7bit
▼

Content

Note: 1.SMS can be sent to 50 numbers at most.

2.Number file must be *.txt,number separated by ',' or 'enter'.

3.The length of SMS cannot exceed 600 characters.

Send

Clear Result

Time

Port

Number

Result

Result

Return

Reset

Figure 3-64 Send SMS Interface

The table below explains the configuration items on the Send SMS interface.

Item	Description
------	-------------

Port	Select a port to send the SMS. There are three options available: Assignment Port, Automatic, Group Send.
Number Import	Click <i>Browse</i> to select the required number file and then click <i>Import</i> to import this file.
Send to	Enter the remote number to receive the SMS.
Encoding Format	The encoding format for the SMS, two options available: GSM 7bit and UCS2.
Content	The content of the SMS required to be sent.
Result	Display the send result of the SMS.

Click **Send** to send out the SMS, click **Clear Result** to clear all results. Click **Reset** to restore the configurations, or click **Return** to go back to the previous

3.6.5 IMEI



IMEI

IMEI Modification Service Agreement

Welcome to use the IMEI modification service. By using this service you accept all the following terms.

(1) Used for test only
This service is only provided to individuals for test.


(2) Can not be used for any commercial purposes
You should use this service under the premise of not violating any laws or regulations.

(3) Exemption
You are liable for any possible losses in your use of this service,
Our company will take no legal responsibility for it.

☐ Accept

Figure 3-65 IMEI Interface

See Figure 3-65 for the IMEI interface. Read the agreement carefully and click **Accept** before you go into the IMEI Modification interface. There are two optional modes for IMEI modification: Manual Modify and Auto Modify. Click Manual Modify to go into the IMEI manual modification interface (Figure 3-66).



IMEI - Modify Initial Value


Port	IMEI	Port	IMEI
1	123456785003126	2	123456785003134
3	123456785003142	4	123456785003159
5	123456785003167	6	123456785003175
7	123456785003183	8	123456785003191

Note: 1. IMEI is a 15-digit number!
2. The digits from the first to the fourteenth are valid. According to them, the fifteenth digit is generated as a check value.

Figure 3-66 IMEI Manual Modification Interface

The default IMEI information will be displayed after clicking Initial Value in Figure 3-66, you can save and use it according to your requirement.

Click Auto Modify to go into the IMEI auto modification interface (Figure 3-67).



The interface is titled "IMEI - Auto Modify". It contains the following elements:

- IMEI Auto Modification:** Radio buttons for ☐ Disable and ☒ Enable.
- Mode:** Radio buttons for ☒ Based on Time/Call, ☐ Based on Time (Minute), ☐ Based on Call (Times), and ☐ Switch Card per Time.
- IMEI Generation Mode:** A dropdown menu currently set to "Automatic".
- IMEI TAC:** A text input field containing "-1".
- IMEI Serial Number Range:** Two text input fields containing "100000" and "900000".
- Notes:**
 - Note: 1. IMEI = TAC(8 digits) + Serial Number(6 digits) + Check Bit(1 digit).
 - Note: 2. IMEI value: TAC(Set value) + Serial Number(Value in the range accumulated cyclically) + Check Bit(Auto calculated).
- Buttons:** "Save" and "Reset".


Figure 3-67 IMEI Auto Modification Interface

If the modification mode is set to *Based on Time/Call*, IMEI Generation Mode has only one option Automatic; if the modification mode changes to *Switch Card per Time*, there are four modes available for the IMEI Generation Mode: Automatic, Based on Number (Server), Based on Number (Corresponding table) and Based on IMSI (Corresponding table). You are required to fill in the IMEI TAC and IMEI Serial Number Range. See Figure 3-67 for the detailed generation mode for IMEI. If the Based on Number (Server) mode is selected, the IMEI value will be obtained from the server and you are required to fill in the server address (Example: http : //201.123.115.111); If the Based on Number (Corresponding table) mode is selected, the IMEI value will be obtained from the cell phone number and the corresponding IMEI table, and you can directly fill in the corresponding table on the interface or upload the file. For the format of the corresponding table, refer to the notes at the bottom of the interface. If the Based on IMSI (Corresponding table) mode is selected, the IMEI value will be obtained from the corresponding IMSI table of the SIM card, and you can easily import the table file. For the format of the corresponding table, refer to the notes at the bottom of the interface.

After configuration, click **Save** to save the above settings into the gateway or click **Reset** to restore the configurations.

Note: This configuration is unavailable for CDMA module.

3.6.6 USSD



The interface is titled "USSD". It contains the following elements:

- Default USSD Encoding:** A dropdown menu set to "ASCII".
- Buttons:** "Save", "Send", and "Clear Data".
- Response Fields:** Eight text input fields labeled "Respond" with indices 1 through 8.
- Request Field:** A text input field labeled "Request".
- Checkboxes:** ☐ All and ☐ 1.

Figure 3-68 USSD Setting Interface

See Figure 3-68 for the USSD Setting interface. The table below explains the items shown in the above figure.

Item	Description
Default USSD Encoding	Sets the default encoding format for USSD, two options available: ASCII and UCS2.
Port	Sets the port used to send the USSD request.
Request	Inputs the content of the USSD request.
Respond	Displays the result of the USSD respond.
All	Selects all the available ports to send the same USSD request.

Click **Send** in Figure 3-68 to send out the USSD request. Click **Clear Data** to clear all data.

Note: This configuration is unavailable for CDMA module.

3.6.7 Email

The image shows the 'Email Config' interface. It has a blue header bar with the title 'Email Config'. Below the header, there are two main sections. The first section is 'Mailbox Settings' with fields for 'Mailbox Account', 'Password', 'Outgoing(SMTP)', 'Incoming(POP3)', and 'SSL'. To the right of these fields are 'Port' fields for SMTP (25) and POP3 (110), and buttons for 'Send test' and 'Receive test'. The second section is 'Conversion between Email & SMS'. It has a 'Show Log' button, a 'Bind Mailbox to Port' checkbox (checked), a 'Setting' button, and a note: '("Bind Mailbox to Port" has a priority in setting)'. Below this are 'Convert SMS to Email' (checked) and 'Convert Email to SMS' (checked). There are fields for 'Target Address' (with a note '(Separated by \',')'), 'Subject' (with 'SMStoEmail' and 'EmailtoSMS' as examples), 'Receiving Cycle' (5 Minute(Range:1~60)), 'Mail Filtering' (Subject matching), 'SMS Sending Port' (Automatic), and 'Return Receipt' (Successful and Failed checkboxes). At the bottom, there are 'Save' and 'Reset' buttons. A red note at the bottom of the interface states: 'Note:1,Only UTF-8 and ASCII Formatted mails are supported to covert to SMS. 2.The pure text mode and Unicode(UTF-8) are recommended. 3.Mails exceeding 300 characters may fail to be converted. 4.Mails have same subject as the settings can be converted (Case Insensitive). 5.Email Format: [Number]XXX[End] [SMS]ZZZ[End];(Case Insensitive). XXX:Send Target Number,ZZZ:SMS content'.

Figure 3-69 Email Setting Interface

See Figure 3-69 for the Email Setting interface. The table below explains the configuration items on the Email Setting interface.

Item	Description
------	-------------

Mailbox Account, Password	Sets the account and password of the mailbox.
Outgoing (SMTP), Port	Sets the server address and port for Email sending.
Incoming (POP3), Port	Sets the server address and port for Email receiving.
SSL	Sets whether to encrypt the sending/receiving mails via SSL.
Show Log	Click it to display the log which contains the Email to SMS converted information.
Bind Mailbox to Port	Once this feature is enabled, the mailbox can be bound to the designated port. Click Setting to go into the "Bind Mailbox to Port-Settings" interface.
Convert SMS to Email	SMS can be converted to Emails if this feature is enabled.
Target Address	The target address to which the Email converted by SMS will be sent.
Subject	Sets the subject for the Email converted by SMS.
Covert Email to SMS	When this feature is enabled, the mails in a designated format (See Note 4 and 5 in Figure 3-69) can be converted to SMS.
Receiving Cycle	Sets the cycle to receive mails. Range of value: 1~60, calculated by minute, with the default value of 5.
Mail Filtering	Sets the condition to convert the mail to SMS, two options including: Subject matching and Number matching, with the default value of <i>Subject matching</i> . If the Subject matching mode is selected, you can set the subject of your own choice, and the email format is "[Number]XXX[End] [SMS]YYY[End]; (Case Insensitive)"; If the Number matching mode is selected, the mail subject must be numbers, multiple numbers are supported which should be separated by ",", and the email format is "[SMS].....[end]".
SMS Sending Port	Sets the port from which the SMS will be sent out. The default value is automatic .
Return Receipt	Sets whether to receive a return receipt telling the mail is sent successfully or not.

After configuration, click **Save** to save the settings into the gateway or click **Reset** to reset the settings.

3.6.8 SIM Card

Port	Card A	Cell Phone No.	Card B	Cell Phone No.	Card C	Cell Phone No.	Card D	Cell Phone No.	Auto Switch to Available Card Slot	Switch Strategy for SIM Card	SIM Group	Modify
1	Using	13588231847	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	
2	Using	13588277410	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	
3	Using	13588268249	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	
4	Using	---	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	
5	Using	---	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	
6	Empty	---	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	
7	Empty	---	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	
8	Empty	---	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	
9	Empty	---	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	
10	Empty	---	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	
11	Empty	---	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	
12	Empty	---	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	
13	Empty	---	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	
14	Empty	---	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	
15	Empty	---	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	
16	Empty	---	Empty	---	Empty	---	Empty	---	Enable	Disable	Disable	

Figure 3-70 SIM Card List Interface

See Figure 3-70 for the SIM Card List interface, which displays the states of each SIM card and the strategy to switch the SIM, etc. Click the SIM card in Exist state to set it to Using state, at the same time, the SIM card which is ever in Using state at first will switch to Exist state. Click Modify to modify the parameters. See Figure 3-71.

SIM Card Management

Port

1

Auto Switch to Available Card Slot

☐ Disable
 ☒ Enable

Switch Strategy for SIM Card

☐ Based on Time

(Minutes)

☒ Based on Call

(Times)

Count Method

☒ Call Out
 ☐ Ring Back

☐ Based on SMS

(Pieces)

☐ Fixed Time

0 H 0 M

☐ Disable

SIM Card Grouping

☐ Disable
 ☒ Enable

Grouping

Group 1: ☒ Card A ☒ Card B ☐ Card C ☐ Card D
 Group 2: ☐ Card A ☐ Card B ☒ Card C ☒ Card D

Use Strategy

☒ Only One Group

Group 1

☐ Two Groups in Turn

Based on Time

0

 (Minutes)

Note: The item "Auto Switch to Available Card Slot" has priority over the item "SIM Card Grouping", Please do not enable them simultaneously.

Apply to All Ports

☐

Modify

Reset

Return

Figure 3-71 SIM Card Management Interface

The table below explains the items shown in the above figure.

Item	Description
Port	Serial number of the port on the device.
Auto Switch to Available SIM Card	Once this feature is enabled, it will switch to other available SIM card automatically if the current SIM card is drawn out or the corresponding port is unavailable due to the SIM card is damaged. The default value is <i>enable</i> .
Switch Strategy for SIM Card	Sets the switch strategy for the SIM card. There are five options: <i>Based on Time</i> , <i>Based on Call</i> , <i>Based on SMS</i> , <i>Fixed Time</i> and <i>Disable</i> . Among them, the option <i>Based on Call</i> provides two count methods: <i>Call out</i> and <i>Ring back</i> . The default value is <i>Disable</i> .
SIM Card Grouping	Once this feature is enabled, the SIM cards in the port can be divided into groups, with the default value of <i>disable</i> .
Grouping	Sets the grouping of the SIM cards.
Use Strategy	Sets the strategy to group the SIM cards, including two options: Only One Group and Two Groups in Turn.
Apply to All Ports	Sets whether to apply the above configurations to all ports.

Click **Modify** to save the above settings into the gateway or click **Reset** to restore the configurations. Click **Return** to cancel the modification.

Note:

- 1, Only the SMG4016 and SMG4032 series gateways support this configuration;
- 2, The priority of these three switching modes is: Auto Switch to Available Card Slot > SIM Card Grouping > Switch Strategy for SIM Card. It is suggested not to enable them simultaneously.

3.6.9 PIN Manage

PIN Manage					
Port	SIM Card State	PIN Required	PUK Required	Setting Status	Modify
1	Unlocked	No	No	---	
2	---	---	---	---	--
3	---	---	---	---	--
4	Unlocked	No	No	---	
5	---	---	---	---	--
6	---	---	---	---	--
7	---	---	---	---	--
8	---	---	---	---	--

Figure 3-72 PIN Manage Interface

See Figure 3-72 for the PIN Manage interface, which display the status of the SIM card and the setting status of PIN and PUK. Click Modify to go into the modification interface. See Figure 3-73.

PIN Manage-Modify	
Port	<input type="text" value="Port1"/>
Lock SIM Card	<input checked="" type="radio"/> Yes <input type="radio"/> No
PIN	<input type="text"/>
<p>Note: There is a restriction on the number of input times of PIN and PUK. Please proceed with caution.</p> <div> <input type="button" value="Modify"/> <input type="button" value="Reset"/> <input type="button" value="Cancel"/> </div>	

Figure 3-73 PIN Manage Modification Interface

Click “Yes” and input the correct PIN to lock the SIM card. The incoming/outgoing calls will not be initiated once the SIM card is locked. See Figure 3-74.

PIN Manage					
Port	SIM Card State	PIN Required	PUK Required	Setting Status	Modify
1	Locked	Yes	No	---	
2	---	---	---	---	--
3	---	---	---	---	--
4	Unlocked	No	No	---	
5	---	---	---	---	--
6	---	---	---	---	--
7	---	---	---	---	--
8	---	---	---	---	--

Figure 3-74 SIM Card Locked PIN Required

Click Modify in Figure 3-74, you are required to input PIN again. See Figure 3-75.

PIN Manage-Modify

Port

Port1

PIN

Note: There is a restriction on the number of input times of PIN and PUK. Please proceed with caution.

Modify

Reset

Cancel

Figure 3-75 Input PIN Interface

After the correct PIN is input, the SIM card is still locked but the channel turns idle and allows the initiation of incoming/outgoing calls. See Figure 3-76.

PIN Manage					
Port	SIM Card State	PIN Required	PUK Required	Setting Status	Modify
1	Locked	No	No	Successful	
2	---	---	---	---	--
3	---	---	---	---	--
4	Unlocked	No	No	---	
5	---	---	---	---	--
6	---	---	---	---	--
7	---	---	---	---	--
8	---	---	---	---	--

Figure 3-76 SIM Card Locked without PIN

Click Modify in Figure 3-76 to unlock the SIM card or modify the PIN. See the figure below.

PIN Manage-Modify

Port

Port1

Lock SIM Card

☒ Yes
 ☐ No

Modify PIN

☐ Yes
 ☒ No

Note: There is a restriction on the number of input times of PIN and PUK. Please proceed with caution.

Modify

Reset

Cancel

Figure 3-77 Lock SIM Card or Modify PIN Interface

The SIM card will also be locked and cannot make incoming/outgoing calls if you input a wrong

PIN code three times. You are required to input the PUK to reset the PIN. See Figure 3-78.



PIN Manage					
Port	SIM Card State	PIN Required	PUK Required	Setting Status	Modify
1	Locked	Yes	Yes	---	
2	---	---	---	---	--
3	---	---	---	---	--
4	Unlocked	No	No	---	
5	---	---	---	---	--
6	---	---	---	---	--
7	---	---	---	---	--
8	---	---	---	---	--

Figure 3-78 SIM Card Locked Need PIN and PUK

Click Modify in Figure 3-78 to input PUK and reset a new PIN, see Figure 3-79.

PIN Manage-Modify

Port

Port1

PUK

New PIN

Confirm New PIN

Note: There is a restriction on the number of input times of PIN and PUK. Please proceed with caution.

Modify

Reset

Cancel

Figure 3-79 New PIN setting interface

The SIM card is still locked but do not need PIN and PUK again after inputting the correct PUK and resetting a new PIN. The status of the port displaying in [Port State](#) is idle. So the port can make incoming/outgoing calls. Click **Modify** to save the above settings into the gateway or click **Reset** to restore the configurations. Click **Cancel** to cancel the modification.

Note: The SIM card will be locked forever if you input a wrong PUK more than 10 times. You need to insert a new card.

3.6.10 BS Select

































BS Select										
Check	Port	BS1	BS2	BS3	BS4	BS5	BS6	Setting State	Signal	Modify
<input type="checkbox"/>	1	---	---	---	---	---	---	--		
<input type="checkbox"/>	2	---	---	---	---	---	---	--		
<input type="checkbox"/>	3	---	---	---	---	---	---	--		
<input type="checkbox"/>	4	---	---	---	---	---	---	--		
<input type="checkbox"/>	5	---	---	---	---	---	---	--		
<input type="checkbox"/>	6	---	---	---	---	---	---	--		
<input type="checkbox"/>	7	---	---	---	---	---	---	--		
<input type="checkbox"/>	8	---	---	---	---	---	---	--		
<input type="checkbox"/>	9	---	---	---	---	---	---	--		
<input type="checkbox"/>	10	---	---	---	---	---	---	--		
<input type="checkbox"/>	11	---	---	---	---	---	---	--		
<input type="checkbox"/>	12	---	---	---	---	---	---	--		
<input type="checkbox"/>	13	---	---	---	---	---	---	--		
<input type="checkbox"/>	14	---	---	---	---	---	---	--		
<input type="checkbox"/>	15	---	---	---	---	---	---	--		
<input type="checkbox"/>	16	---	---	---	---	---	---	--		

Figure 3-80 Base Station Select Interface

See Figure 3-80 for the Base Station Select interface, which displays the information of the base stations which can be searched and connected. The base station has the priority to be connected will be listed on the left according to its comprehensive ability. Click Modify in Figure 3-80 to go into the Lock BS interface. See Figure 3-81.

port

4

BS Details

Serial No.	BS	LAC	CELLID
1	7	5814	3EE4
2	82	9106	0008
3	72	5814	5065
4	605	5814	974C
5	619	5814	492C
6	--	--	--

Manual Lock

☐1
☐2
☐3
☐4
☐5
☐6

Lock

Automatic Lock

☐Disable
☒Enable

Switching Time

12

(Range: 10-1440 minutes)

BS in use

☒1
☐2
☐3
☐4
☒5
☐6

(The parameter should be reset after the change of a SIM card)

Lock

Return

Figure 3-81 Lock BS Interface

The table below explains the items shown in the above figure.

Item	Description
Port	The number of the port corresponding to that on the wireless module.
Serial No.	The serial number of the base station which can be searched.
BS	The frequency point of each base station.
LAC	The location number of each base station. It's a hexadecimal number.
CELLID	The cell number of each base station. It's a hexadecimal number.
Manual Lock	Select the serial number and click the Lock button behind to lock the base station manually. Thus, the SIM card will connect to the locked base station randomly.

Automatic Lock	Select the serial number to lock the base station automatically. The SIM card will connect to the locked base station in a cyclic order according to the set switching time.
Switching Time	Sets the switching time for connecting the base station.
BS in Use	Selects the serial number of the base station to be locked automatically.

Click **Lock** to save the above settings into the gateway or click **Return** to cancel the modification and return back to the previous page.

To cancel the lock, check the checkbox before the corresponding index in Figure 3-80 and click the '**Cancel**' button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Query** means to query the information of all the base stations which can be connected.

Note: This configuration is only supported by the GSM gateway.

3.6.11 Networking Settings









Networking Management					
Check	Port	Cell Phone No.	Time to Access Network	Consumed Flow(KB)	Modify
<input type="checkbox"/>	1	13588273487	---	0	
<input type="checkbox"/>	2	---	---	0	
<input type="checkbox"/>	3	---	---	0	
<input type="checkbox"/>	4	---	---	0	
<input type="checkbox"/>	5	---	---	0	
<input type="checkbox"/>	6	---	---	0	
<input type="checkbox"/>	7	---	---	0	
<input type="checkbox"/>	8	---	---	0	
<input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Clear All"/> <input type="button" value="Refresh"/>					

Figure 3-82 Networking Management Interface


















Networking Management					
Check	Port	Cell Phone No.	Time to Access Network	Consumed Flow(KB)	Modify
<input type="checkbox"/>	1	---	---	A:0 B:0 C:0 D:0	
<input type="checkbox"/>	2	---	---	A:0 B:0 C:0 D:0	
<input type="checkbox"/>	3	---	---	A:0 B:0 C:0 D:0	
<input type="checkbox"/>	4	---	---	A:0 B:0 C:0 D:0	
<input type="checkbox"/>	5	---	---	A:0 B:0 C:0 D:0	
<input type="checkbox"/>	6	---	---	A:0 B:0 C:0 D:0	
<input type="checkbox"/>	7	---	---	A:0 B:0 C:0 D:0	
<input type="checkbox"/>	8	---	---	A:0 B:0 C:0 D:0	
<input type="checkbox"/>	9	---	---	A:0 B:0 C:0 D:0	
<input type="checkbox"/>	10	---	---	A:0 B:0 C:0 D:0	
<input type="checkbox"/>	11	---	---	A:0 B:0 C:0 D:0	
<input type="checkbox"/>	12	---	---	A:0 B:0 C:0 D:0	
<input type="checkbox"/>	13	---	---	A:0 B:0 C:0 D:0	
<input type="checkbox"/>	14	---	---	A:0 B:0 C:0 D:0	
<input type="checkbox"/>	15	---	---	A:0 B:0 C:0 D:0	
<input type="checkbox"/>	16	---	---	A:0 B:0 C:0 D:0	
<input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Clear All"/> <input type="button" value="Refresh"/>					

Figure 3-83 Networking Management Interface for SMG4016

See Figure 3-82, Figure 3-83 for the Networking Management interface, which displays the networking information about the SIM card, such as the time to start accessing the network, the consumed flow, etc. Click Modify in Figure 3-82 to go into the Networking Settings Modification

interface. See Figure 3-84.



The image shows a 'Networking Settings' window. It contains the following fields and controls:

- Port:** A dropdown menu with '1' selected.
- Auto Consume Flow:** Radio buttons for 'Disable' and 'Enable' (selected).
- URL:** A text input field containing 'http://www.sina.com.cn/'.
- APN:** An empty text input field.
- Access Times:** An empty text input field.
- Timing Cycle:** A dropdown menu with 'Month' selected.
- Time to Access:** Three dropdown menus showing '1st', '00', and '00'.
- Network:** A label with no input field.
- Apply to Other Ports:** Radio buttons for 'Port' (selected) and 'Port Group'. Below them are checkboxes for ports 01 through 08, with '01' checked.
- Note:** A red text note stating: 'Note:Flow statistics error is approximately 10%. You can get the actual consumption from the operator.'
- Buttons:** 'Save' and 'Return' buttons at the bottom.

Figure 3-84 Networking Settings Modification Interface

The table below explains the items shown in the above figure.

Item	Description
Port	The number of the port corresponding to that on the wireless module.
Auto Consume Flow	Once this feature is enabled, the SIM card will surf the internet and consume the flow automatically. The default value is <i>disabled</i> .
URL	Sets the URL address.
APN	Sets the APN. Please get the detailed information from the operator of the SIM card.
Access Times	Sets the times for the SIM card to surf the internet. Range of value: 1~500.
Timing Cycle	Sets the timing cycle for the SIM card to surf the internet.
Time to Access Network	Sets the start time of the SIM card to surf the internet.
Apply to Other Ports	Sets whether to apply the above configurations to other ports.

Click **Save** to save the above settings into the gateway or click **Reset** to restore the configurations. Click **Cancel** to cancel the modification.

Note: This configuration is only supported by the WCDMA and LTE modules.

3.6.12 AMD

AMD

AMD Detection for Outgoing Call ☐ Disable ☒ Enable

AMD Parameters

Line Silence Overtime after Dial Tone	30000	ms
Silence Overtime after Tone or Color Ring Being Detected	15000	ms
Overtime for a Complete AMD Detecting Process	70000	ms
Upper Limit of Detected Continuous Tones	5	
Shortest Voice Duration at ON State	150	ms
Shortest Voice Duration at OFF State	400	ms
Maximum Greeting Duration at OFF State	0	ms
Shortest Silence Duration before Greeting	600	ms
Shortest Greeting Duration	180	ms
Maximum Greeting Duration	1200	ms
Shortest Silence Duration after Greeting	1200	ms
Silence Energy Threshold	180	%
Energy Difference Proportion of Tone	30	%

AMD Debugging

Output AMD Debugging Info to Syslog ☒ Disable ☐ Enable

Do not Detect Other Pickup Signal ☒ Disable ☐ Enable

Save Reset

Figure 3-85 AMD Configuration Interface

See Figure 3-85 for the AMD Configuration interface, which is to set the parameters for judging whether the phone is picked up by a man or not. The table below explains the items shown in the above figure.

Item	Description
AMD Detection for Outgoing Call	Sets whether to enable the AMD detection while making an outgoing call, with the default value of <i>Disabled</i> .
Line Silence Overtime after Dial Tone	Judges if the line silence after dial tone lasts overtime or not, calculated by ms, with the default value of <i>30000</i> .
Silence Overtime after tone or Color Ring Being Detected	Judges if the silence after tone or color ring lasts overtime or not, calculated by ms, with the default value of <i>15000</i> .
Overtime for a Complete AMD Detecting Process	Judges the whole AMD detecting process overtime or not, calculated by ms, with the default value of <i>70000</i> .
Upper Limit of Detected Continuous Tones	Judges if the tone detected time is overtime or not.
Shortest Voice Duration at ON State	Sets the shortest duration when the voice goes into the High voltage state, calculated by ms, with the default value of <i>150</i> .

Shortest Voice Duration at OFF State	Sets the shortest duration when the voice goes into the low voltage state, calculated by ms, with the default value of 400.
Maximum Greeting Duration at OFF State	Sets the longest duration of the greetings at the OFF state after a call is picked up by a man, calculated by ms, with the default value of 0.
Shortest Silence Duration before Greeting	Sets the shortest silence duration before the phone is picked up by a man, calculated by ms, with the default value of 600.
Shortest Greeting Duration	Sets the shortest greeting duration in case the phone is picked up by a man, calculated by ms, with the default value of 180.
Maximum Greeting Duration	Sets the longest greeting duration in case the phone is picked up by a man, calculated by ms, with the default value of 1200.
Shortest Silence Duration after Greeting	Sets the shortest silence duration after the phone is picked up by a man, calculated by ms, with the default value of 1200.
Silence Energy Threshold	Sets an energy value that can judge the voice is silence or not, calculated by ms, with the default value of 180.
Energy Difference Proportion of Tone	Sets the difference proportion of the high and low energies in the signal.
Output AMD Debugging Info to Syslog	Sets whether to output the AMD debugging information to Syslog.
Do not Detect Other Pickup Signal	Sets whether to detect other pickup signals.

Click **Save** to save the settings into the gateway, click **Reset** to restore the configurations.

Note: This configuration is only supported by the CDMA module.

3.6.13 Hidden CallerID

Hidden CallerID

Port

☐Port 1 ☐Port 2 ☐Port 3 ☐Port 4
☐Port 5 ☐Port 6 ☐Port 7 ☐Port 8
☐Port 9 ☐Port 10 ☐Port 11 ☐Port 12
☐Port 13 ☐Port 14 ☐Port 15 ☐Port 16

Note: The feature of Hidden CallerID should be supported by the operator.

Figure 3-86 Hidden CallerID Setting Interface

See Figure 3-86 for the Hidden Caller Setting interface which sets whether to hide the CallerID to the called party. This feature requires the support of the operator. Select the port and click **Open** to enable the feature, and click **Close** to disable it.

Note: This configuration is only supported by the WCDMA module.

3.7 Call Management

Call Management includes eight parts: **Balance**, **Port Timer**, **Name List Timer**, **Tel→IP Auto Route**, **Blacklist**, **SMS Count**, **Auto Function** and **Port Charge**. See Figure 3-87. **Balance** is used to query the remaining time and balance of a cell phone number; **Port Timer** is used to calculate the call time length of the corresponding number; **Name List Timer** is used to set the timing rule to count and manage the call time of the target number; **Tel→IP Auto Route** is used to set the route for the remote end to call back; **Blacklist** is used to set a number table to forbid some incoming calls; **SMS Count** is used to calculate the number of short messages from a phone number corresponding to a port; **Auto Function** is used to make calls and send SMS from port to port in a special condition so as not to be blocked by the operator; **Port Charge** is used to count the call fees for a phone number corresponding to a port.




Figure 3-87 Call Management Interface

3.7.1 Balance

Balance Query							
Check	Port	Cell Phone No.	Time	Balance	Balance Alarm set message	Balance Alarm	Modify
<input type="checkbox"/>	1	13588231847	---	---	Close	Close	
<input type="checkbox"/>	2	13588277410	---	---	Close	Close	
<input type="checkbox"/>	3	13588268249	---	---	Close	Close	
<input type="checkbox"/>	4	---	---	---	Close	Close	
<input type="checkbox"/>	5	---	---	---	Close	Close	
<input type="checkbox"/>	6	---	---	---	Close	Close	---
<input type="checkbox"/>	7	---	---	---	Close	Close	---
<input type="checkbox"/>	8	---	---	---	Close	Close	---
<input type="checkbox"/>	9	---	---	---	Close	Close	---
<input type="checkbox"/>	10	---	---	---	Close	Close	---
<input type="checkbox"/>	11	---	---	---	Close	Close	---
<input type="checkbox"/>	12	---	---	---	Close	Close	---
<input type="checkbox"/>	13	---	---	---	Close	Close	---
<input type="checkbox"/>	14	---	---	---	Close	Close	---
<input type="checkbox"/>	15	---	---	---	Close	Close	---
<input type="checkbox"/>	16	---	---	---	Close	Close	---

Figure 3-88 Balance Query Interface

Via the Balance Query interface, you can query the balance of a designated cell phone number. Click Modify to modify the query mode. See the modification interface below.


Figure 3-89 Query Mode Modification Interface

The table below explains the configuration items on the Query Mode Modification interface.

Item	Description
Query Mode	Sets the mode to query. There are three options available: SMS, ATD, USSD.
Destination Number	Sets the destination number to query
Content to Send	Sets the content to send.
Keywords to Match	The balance matching the keywords will be displayed.
Query after SIM Card Registered	Sets whether to query the balance automatically once the SIM card is registered to the base station.
Query Regularly	Sets the time to query the balance regularly.
Alarm for Insufficient Balance	Once this feature is enabled, the gateway will notify the users by sending SMS or Email once the balance goes insufficient. The default value is <i>disabled</i> .
Alarm Threshold	Sets the threshold for the insufficient balance to send the alarm.
Alarm via SMS, Alarm via Email	Sets the addresses to receive the SMS/Email while the balance is insufficient.
Alarm via Web	Once this feature is enabled, the alarm information concerning the Insufficient Balance will be displayed on the web.
Apply to Other Ports	Sets whether to apply these query conditions to other ports or port groups.

Click **Modify** to save the above settings into the gateway or click **Reset** to restore the configurations. Click **Cancel** to cancel the modification. Click **Test** to set a balance query strategy, and then execute it to test the balance query feature. And this can help to set a proper balance

query strategy. See Figure 3-90.



















The interface is titled "Balance Query Strategy Test". It contains three input fields: "Keywords to Match" (a small text box), "SMS Content" (a large text area), and "Balance" (a small text box). At the bottom, there are two buttons: "Query" and "Return".

Figure 3-90 Balance Query Strategy Test Interface

Enter the **Keywords to Match** and **SMS Content**, then click **Query** to query the information about the balance.

3.7.2 Port Timer

Port Timer											
Check	Port	Cell Phone No.	Unit	Max Time(Single Call)	Max Time(Single Day)	Max Time(Total Calls)	Used Call Time Today	Used Call Time	Clear Call Time	Alarm Threshold	Modify
<input type="checkbox"/>	1	13750845957	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	
<input type="checkbox"/>	2	13588242026	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	
<input type="checkbox"/>	3	13082813431	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	
<input type="checkbox"/>	4	---	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	
<input type="checkbox"/>	5	---	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	
<input type="checkbox"/>	6	---	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	
<input type="checkbox"/>	7	---	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	
<input type="checkbox"/>	8	---	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	
<input type="checkbox"/>	9	---	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	
<input type="checkbox"/>	10	---	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	
<input type="checkbox"/>	11	---	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	
<input type="checkbox"/>	12	---	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	
<input type="checkbox"/>	13	---	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	
<input type="checkbox"/>	14	---	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	
<input type="checkbox"/>	15	---	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	
<input type="checkbox"/>	16	---	60s	Unlimited	Unlimited	Unlimited	---	---	---	---	

Check All Uncheck All Clear(A) Clear(B) Clear(C) Clear(D) Refresh

Figure 3-91 Port Timer Interface

See Figure 3-91 for the Port Timer interface, which displays such information as the call time limit on the number corresponding to the port, the timer clear cycle as well as the alarm for the call time allowance. Click Modify for each port in Figure 3-91 to modify the timer settings. See Figure 3-92.

Timing

Port ▼

Unit ▼

Time Limit on a Single Call ☐ Disable ☒ Enable

Max Call Time

Time Limit on a Single Day ☐ Disable ☒ Enable

Max Call Time

Switch to Other Card if no Time ☐

Time Limit on Total Calls ☐ Disable ☒ Enable

Max Call Time

Switch to Other Card if no Time ☐

Timing Cycle ▼

Clear 1st ▼ 00 ▼ 00 ▼

☐ Set Spent Call Time

Alarm for Call Time Allowance ☐

Allowance Alarm Threshold

☐ Alarm via SMS (Separated by ",")

☐ Alarm via Email (Separated by ",")

Apply to Other Ports ☒ Port ☐ Port Group

☒ 01 ☐ 02 ☐ 03 ☐ 04 ☐ 05 ☐ 06 ☐ 07 ☐ 08
☐ 09 ☐ 10 ☐ 11 ☐ 12 ☐ 13 ☐ 14 ☐ 15 ☐ 16

Modify

Reset

Return

Figure 3-92 Port Timing Setting Interface

The table below explains the configuration items shown in the above figure:

Item	Description
Port	The number of the port corresponding to the wireless module.
Unit	Sets the timing unit for the call, eight options available: 1s, 5s, 10s, 20s, 30s, 40s, 50s and 60s. The actual call time will be calculated as the integral multiple of the setting time. Take an example: supposed the setting time is 30s and the actual call time is 72s, thus, the gateway will consider the call time as 90s.
Time Limit on a Single Call	Sets whether to enable the time limit on a single call.
Max Call Time	Sets the maximum time length of a call.

Time Limit on a Single Day	Sets whether to enable the time limit on calls in a single day.
Switch to Other Card if no Time	Sets whether to switch to other available SIM card if the current SIM card has no available time to make calls. Note: This configuration is unavailable for SMG4004 and SMG4008 series gateway.
Time Limit on Total Calls	Sets whether to enable the time limit on all calls at the port.
Timing Cycle	Sets the time count cycle for the port.
Clear	Sets the time node to clear the time count.
Set Spent Call Time	Sets the spent call time length of the port.
Alarm for Call Time Allowance	Once this feature is enabled, when the remaining call time of the port is less than the alarm threshold value, the gateway will send the alarm information.
Allowance Alarm Threshold	Sets the threshold value for the remaining call time.
Alarm via SSM, Alarm via Email	Sets the way to send the alarm information. The gateway can send the alarm information via both SMS and Email or either of them.
Apply to Other Ports	Sets whether to apply above settings to other ports or port groups.

Click **Modify** to save the settings into the gateway, click **Reset** to restore the configurations, or click **Return** to cancel the settings.

3.7.3 Name List Timer


Port	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Index[Already Used]	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

No available name list timer rule!

Add New

Figure 3-93 Name List Timer Interface

See Figure 3-93 for the Name List Timer interface, which contains two parts: Port Timing and Name List Timer Rule. You can add the timing rule to count the call time for the port. Click **Add New** in Figure 3-93 to add a timing rule. See Figure 3-94.



The interface is titled "Add Name List Timing Rule". It contains the following fields and controls:

- Index:** A dropdown menu with the value "1" selected.
- Number:** A large text input area. To its right is the text "(Separated by ',')".
- Import Number:** A button labeled "Browse..." and a button labeled "Import".
- Number Matching Rule:** A dropdown menu with "Prefix Matching" selected.
- Max Call Time:** A text input field followed by the text "(Minute)".
- Timing Cycle:** A dropdown menu with "Year" selected.
- Clear:** A series of four dropdown menus showing "Jan", "1st", "00", and "00".


At the bottom of the interface are three buttons: "Save", "Reset", and "Return".

Figure 3-94 Add Name List Timing Rule Interface

The table below explains the configuration items shown in the above figure:

Item	Description
Number	Sets the number to be timed.
Import Number	Used to import the files on which the numbers need to be timed.
Number Matching Rule	Sets the rule to match the numbers, two options available: Prefix Matching and Whole Words only, with default value of <i>Prefix Matching</i> .
Max Call Time	Sets the maximum time length for a call.
Timing Cycle	Sets the timing cycle for the port, four options available: Day, Week, Month, Year.
Clear	Sets the time node to clear the timing.

Click **Save** to save the settings into the gateway, click **Reset** to restore the configurations, or click **Return** to cancel the settings. After adding the timing rules, click **Setting** button on the up right corner in Figure 3-93 to set the timing rule for each port. See Figure 3-95 for the setting interface.



The interface is titled "Set Port Timing Rule". It contains two columns of input fields. The left column has ports 1, 3, 5, and 7, each with a "Rule Index" dropdown menu currently set to "0". The right column has ports 2, 4, 6, and 8, each with a "Rule Index" dropdown menu also set to "0". Below these is a checkbox labeled "Set Spent Call Time". To its right is a dropdown menu labeled "Port1" and an empty text input field. A red note states: "Note: Up to 5 timing rules are supported, separated by ','; 0 means not to use..". At the bottom are three buttons: "Save", "Reset", and "Return".

Figure 3-95 Set Port Timing Rule Interface


The table below explains the configuration items shown in the above figure:

Item	Description
Rule Index	The index number of the timing rule corresponding to the port.
Set Spent Call Time	Sets the call time already used by the port.

Click **Save** to save the settings into the gateway, click **Reset** to restore the configurations, or click **Return** to cancel the settings.

3.7.4 Tel to IP Auto Route

The Tel→IP Auto Route is used to set routes for the remote phone to call back the gateway. By default, there is no available auto route for a Tel→IP call, click the **Setting** button to set it. See Figure 3-96.



The interface is titled "Tel->IP Auto Route Settings". It features a "Tel->IP Auto Route" section with radio buttons for "Disable" and "Enable" (selected). Below this are two dropdown menus: "Route Holding Time" set to "1 Hour" and "Route Calls back to IP Side" set to "YES". A red note contains two points: "1.Tel->IP Auto Route is the highest priority, and can only be used once." and "2.The 'Auto Route' feature will be valid only when the 'CallerID Detection' is enabled for the port." At the bottom are three buttons: "Modify", "Reset", and "Return".

Figure 3-96 Tel→IP Auto Route Settings Interface

The table below explains the configuration items shown in the above figure:

Item	Description
Route Holding Time	Sets the valid time of the route.

Route Calls back to IP Side	<p>Once this feature is enabled, the calls from the PSTN terminal to the soft terminal will be routed to the soft terminal of the original call. That is, when the soft terminal A called the PSTN terminal B via our gateway, if B doesn't answer the call or A cancels the call, the later call from B back to the gateway will be routed to the soft terminal A directly.</p> <p>Once this feature is disabled, the later call dialed back by the remote terminal B will be routed to the original calling party A only if B doesn't answer the first call from A to B.</p>
------------------------------------	--

Click **Modify** to save the settings into the gateway, click **Reset** to restore the configurations, or click **Return** to cancel the settings.

3.7.5 Blacklist




Figure 3-97 Incoming Call Blacklist Interface

See Figure 3-97 for the Incoming Call Blacklist interface. You can designate certain numbers to limit corresponding calls to go into the gateway (calls from the gateway out as well as the SMS are unlimited). The table below explains the configuration items shown in the above figure:

Item	Description
Blacklist	Sets the number list to forbid certain calls to go into the gateway.
Processing Mode	Sets the processing mode for the calls from the numbers in the blacklist to the gateway, two options available: Hang up directly and Hang up after ringing, with the default value of <i>Hang up directly</i> .

Click **Save** to save the settings into the gateway, click **Reset** to restore the configurations.

3.7.6 SMS Count

















SMS Count						
Check	Port	Cell Phone No.	Max Pieces of SMS in a Cycle	Used Pieces of SMS in a Cycle	Clear SMS Count	Modify
<input type="checkbox"/>	1	13750845957	Unlimited	---	---	
<input type="checkbox"/>	2	13588242026	Unlimited	---	---	
<input type="checkbox"/>	3	13082813431	Unlimited	---	---	
<input type="checkbox"/>	4	---	Unlimited	---	---	
<input type="checkbox"/>	5	---	Unlimited	---	---	
<input type="checkbox"/>	6	---	Unlimited	---	---	
<input type="checkbox"/>	7	---	Unlimited	---	---	
<input type="checkbox"/>	8	---	Unlimited	---	---	
<input type="checkbox"/>	9	---	Unlimited	---	---	
<input type="checkbox"/>	10	---	Unlimited	---	---	
<input type="checkbox"/>	11	---	Unlimited	---	---	
<input type="checkbox"/>	12	---	Unlimited	---	---	
<input type="checkbox"/>	13	---	Unlimited	---	---	
<input type="checkbox"/>	14	---	Unlimited	---	---	
<input type="checkbox"/>	15	---	Unlimited	---	---	
<input type="checkbox"/>	16	---	Unlimited	---	---	

Figure 3-98 SMS Count Interface

See Figure 3-98 for the SMS Count interface, which displays such information as the maximum pieces of SMS in a cycle, the used pieces of SMS in a cycle as well as the clear operation. Click Modify for each port in Figure 3-98 to modify the SMS count settings. See Figure 3-99.

SMS Count

Port

1

SMS Amount Limit

☐ Disable
☒ Enable

Max Pieces of SMS

0

Count Cycle

Month

Clear

1st 00 00

Apply to Other Ports

☒ Port
☐ Port Group

☒ 01
☐ 02
☐ 03
☐ 04
☐ 05
☐ 06
☐ 07
☐ 08
☐ 09
☐ 10
☐ 11
☐ 12
☐ 13
☐ 14
☐ 15
☐ 16

Modify

Reset

Return

Figure 3-99 SMS Count Configuration Interface

The table below explains the configuration items shown in the above figure:

Item	Description
------	-------------

Port	The number of the port corresponding to the wireless module.
SMS Amount Limit	Sets whether to enable the limit on the amount of SMS on a port.
Max Pieces of SMS	Sets the maximum amount of SMS.
Count Cycle	Sets the SMS counting cycle for the port
Clear	Sets the time node to clear the SMS count.
Apply to Other Ports	Sets whether to apply above settings to other ports or port groups.

Click **Modify** to save the settings into the gateway, click **Reset** to restore the configurations, or click **Return** to cancel the settings.

3.7.7 Auto Function

Auto Function Settings

Set Features

Port-to-port Call ☒ Enable

Min. Call Duration (S)

Max. Call Duration (S)

Auto Send SMS ☒ Enable

SMS-1 (random)

SMS-2 (random)

SMS-3 (random)

SMS-4 (random)

SMS-5 (random)

Set Conditions

By Device Runtime ☒ Enable

Min. Runtime (Min)

Max. Runtime (Min)

By Accumulated Call Duration ☒ Enable

Accumulated Call Duration (Min)

By Amount of Consecutive Calls Out ☒ Enable

Amount of Consecutive Calls Out

Notes:1.When both features are enabled, the call goes first before the SMS;
2.While setting conditions, do not give a small value to the duration as well as the amount.

Figure 3-100 Auto Function Settings Interface

See Figure 3-100 for the Auto Function Settings interface. You can set via this interface to implement automatic calls and SMS from port to port in some special conditions. The table below explains the configuration items shown in the above figure:

Item	Description
------	-------------

Port-to-port Call	When this feature is enabled, the gateway will make calls from port to port once the set condition is triggered.
Min. Call Duration	The minimum call time for the port-to-port call.
Max. Call Duration	The maximum call time for the port-to-port call.
Auto Send SMS	When this feature is enabled, the gateway will send SMS from port to port once the set condition is triggered.
SMS-1 (random)	Once the feature Auto Send SMS is enabled, the gateway will choose one piece at random from the set SMS to send.
By Device Runtime	When this feature is enabled, as long as the device runtime reaches the set time, the gateway will automatically enable the feature Port-to-port Call or Auto Send SMS .
Min. Runtime	The minimum runtime of the device.
Max. Runtime	The maximum runtime of the device.
By Accumulated Call Duration	When this feature is enabled, as long as the accumulated call time of a port reaches the set time, the gateway will make calls or send messages between this port and its bound port.
Accumulated Call Duration	The accumulated call time of a port. When it reaches or gets greater than the set value, the feature Port-to-port Call or Auto Send SMS will be triggered.
By Amount of Consecutive Calls Out	When this feature is enabled, as long as the amount of consecutive calls out from a port reaches the set time, the gateway will make calls or send messages between this port and its bound port.
Amount of Consecutive Calls Out	The amount of consecutive calls out from a port. When it reaches or gets greater than the set value, the feature Port-to-port Call or Auto Send SMS will be triggered.

Click **Save** to save the settings into the gateway, click **Reset** to restore the configurations.

3.7.8 Port Charge

















Port Charge											
Check	Port	Cell Phone No.	First Billing Cycle	First Billing Rate	Second Billing Cycle	Second Billing Rate	Total Expense	Spent Amount	Clear	No Balance Alarm	Modify
<input type="checkbox"/>	1	13750845957	0 s	0	0 s	0	noLimit	---	---	---	
<input type="checkbox"/>	2	13588242026	0 s	0	0 s	0	noLimit	---	---	---	
<input type="checkbox"/>	3	13082813431	0 s	0	0 s	0	noLimit	---	---	---	
<input type="checkbox"/>	4	---	0 s	0	0 s	0	noLimit	---	---	---	
<input type="checkbox"/>	5	---	0 s	0	0 s	0	noLimit	---	---	---	
<input type="checkbox"/>	6	---	0 s	0	0 s	0	noLimit	---	---	---	
<input type="checkbox"/>	7	---	0 s	0	0 s	0	noLimit	---	---	---	
<input type="checkbox"/>	8	---	0 s	0	0 s	0	noLimit	---	---	---	
<input type="checkbox"/>	9	---	0 s	0	0 s	0	noLimit	---	---	---	
<input type="checkbox"/>	10	---	0 s	0	0 s	0	noLimit	---	---	---	
<input type="checkbox"/>	11	---	0 s	0	0 s	0	noLimit	---	---	---	
<input type="checkbox"/>	12	---	0 s	0	0 s	0	noLimit	---	---	---	
<input type="checkbox"/>	13	---	0 s	0	0 s	0	noLimit	---	---	---	
<input type="checkbox"/>	14	---	0 s	0	0 s	0	noLimit	---	---	---	
<input type="checkbox"/>	15	---	0 s	0	0 s	0	noLimit	---	---	---	
<input type="checkbox"/>	16	---	0 s	0	0 s	0	noLimit	---	---	---	
<input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Clear"/> <input type="button" value="Refresh"/>											

Figure 3-101 Port Charge Interface

See Figure 3-101 for the Port Charge interface, which displays such information as the first and second billing cycles and rates, the total expense, the spent amount of the call expense, the clear operation as well as the no balance alarm. Click Modify for each port in Figure 3-101 to modify the SMS count settings. See Figure 3-102.

Figure 3-102 Call Billing Settings Interface

The table below explains the configuration items shown in the above figure:

Item	Description
Port	The number of the port corresponding to the wireless module.
Billing Limit	Sets whether to enable the cost limit on calls for a port.
First Billing Cycle	The first period of a call to charge, e.g. the first 1 minute.
First Billing Rate	The charge for the first period of a call, e.g. 5 yuan for the first 1 minute.
Second Billing Cycle	Each period after the first one of a call to charge
Second Billing Rate	The charge for each period after the first one of a call
Max Charge	Sets the maximum charge for a call.
Switch to Other Card if No Balance	Sets whether to switch the SIM card to another automatically if it has no balance.
Billing Cycle	Sets the billing cycle for the port.
Clear	Sets the time node to clear the charge.
Set Spent Amount	Sets the spent amount of call fees for the port.

No Balance Alarm	When this feature is enabled, the gateway will send an alarm once the balance in the SIM card goes insufficient.
Alarm Threshold	Sets the threshold for the insufficient balance to send the alarm.
Alarm via SMS Alarm via Email	Sets the way to send the alarm information. The gateway can send the alarm information via both SMS and Email or either of them to the corresponding number or mailbox.
Apply to Other Ports	Sets whether to apply above settings to other ports or port groups.

Click **Modify** to save the settings into the gateway, click **Reset** to restore the configurations, or click **Return** to cancel the settings.

3.8 Port Settings

Port Settings includes two parts: **Port** and **Port Group**. See Figure 3-103.





Figure 3-103 Port Settings

3.8.1 Port

Port Settings												Batch Modify
Port	SIP Account	Authentication Username	Connection Method	Bound Number	Forbid Outgoing Call	Forbid Incoming Call	Caller ID Detection	Reg Status	Echo Canceller	Color Ring	Color Ring Index	Modify
1	8001	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	
2	8002	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	
3	8003	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	
4	8004	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	
5	8005	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	
6	8006	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	
7	8007	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	
8	8008	---	Two Stage Dialing Mode	---	Disable	Disable	Enable	Unregistered	Enable	Disable	---	

Figure 3-104 Port Settings Interface

See Figure 3-104 for the Port Settings interface. The list in the above figure shows the feature and properties of each port. Click **Modify** in Figure 3-104 to modify the properties of the corresponding port. See Figure 3-105 for the Port Modification interface.



The Port-Modify interface contains the following fields and options:

- Port:** A dropdown menu currently showing '1'.
- Register Port:** A dropdown menu currently showing 'Yes'.
- SIP Account:** A text input field containing '8001'.
- Password:** An empty text input field.
- Connection Method:** A dropdown menu currently showing 'Static Binding'.
- Bound Number:** A text input field containing '9999999999'.
- Echo Cancellor:** A checkbox that is checked, labeled 'Enable'.
- Forbid Outgoing Call:** An unchecked checkbox, labeled 'Enable'.
- Forbid Ingoing Call:** An unchecked checkbox, labeled 'Enable'.
- Caller ID Detection:** A checked checkbox, labeled 'Enable'.

At the bottom of the interface are three buttons: **Modify**, **Reset**, and **Cancel**.

Figure 3-105 Port Modification

The table below explains the configuration items on the port modification interface.

Item	Description
Port	Serial number of the port on the device.
Register Port	Sets whether to register the port to the SIP server. When this item is set to <i>No</i> , the item Reg Status on the Port Settings interface (Figure 3-104) shows <i>Unregistered</i> ; when this item is set to <i>Yes</i> , the item Reg Status shows <i>Failed</i> or <i>Registered</i> .
SIP Account	When the port initiates a call to SIP, this item corresponds to the username of SIP. The default SIP account is 80XX among which XX represents the corresponding port number. For example, the default SIP account corresponding to Port 1 is 8001, and that corresponding to Port 8 is 8008.
Password	Registration password of the port. To register a port to the SIP server, both items SIP Account and Password must be filled in.

Connection Method	Port connection methods include:	
	Option	Description
	<i>Static Binding</i>	Bind the number to a wireless port. The number will be listed in the Bound Number column.
	<i>Two Stages Dialing Mode (default)</i>	Under this mode, an incoming call from a wireless port will go into the IVR system. Then IVR will play a speech prompt "Please dial the extension number". If you fail to input the correct target number before IVR finishes the third repeat of the prompt, the port will hang up the call automatically; otherwise, the call goes out successfully.
Note: Both items Connection Method and Bound Number will be hidden if the SIP Station feature is enabled on the SIP Settings interface.		
Echo Canceller	The echo cancellation feature for a call conversation over the wireless channel. By default, this feature is enabled and the effect can reach 128ms.	
Forbid Outgoing Call	If this feature is enabled, the port will be forbidden to call out. The default setting is <i>disabled</i> .	
Forbid Incoming Call	If this feature is enabled, the port will be forbidden to call in. The default setting is <i>disabled</i> .	
Caller ID Detection	If this feature is enabled, the port will detect the Caller IDs from the incoming calls. The default setting is <i>enabled</i> .	

After configuration, click **Modify** to save the settings into the gateway, click **Reset** to restore the configurations, or click **Cancel** to cancel the settings.

Or you can click **Batch Modify** in Figure 3-104 to modify several pieces of port settings at the same time. See Figure 3-106 below for the Port Batch Modification interface.

Port-Batch Modify

Starting Port

Ending Port

Register Port

Starting SIP Account

Starting Authentication Password

SIP Account Batch Rule

SIP Account Batch Step Size

Authentication Password Batch Rule

Authentication Password Batch Step Size

Connection Method

Bound Number

Bound Number Step Rule

Bound Number Step Size

Echo Cancellation
☒ Enable

Forbid Outgoing Call
☐ Enable

Forbid Incoming Call
☐ Enable

Caller ID Detection
☒ Enable

Figure 3-106 Port Batch Modification

Some configuration items on this interface are the same as those on the **Port Modification Interface**. The others are described in the table below.

Item	Description
Starting Port	The starting serial number of the port on the device in the batch setting.
Ending Port	The ending serial number of the port on the device in the batch setting.
Register Port	Sets whether to register the port to the SIP server.
Starting SIP Account	The starting SIP account in the batch setting.
Starting Authentication Password	The starting authentication password in the batch setting.
SIP Account Batch Rule	The rule for batch setting the SIP account, including Increase and Decrease two options.
SIP Account Batch Step Size	Sets the increase or decrease step size of the SIP account in the batch setting.
Authentication Password Batch Rule	The rule for batch setting the authentication password, including Increase , Decrease and All Same three options.
Authentication Password Batch Step Size	Sets the increase or decrease step size of the authentication password in the batch setting.

Bound Number Step Rule	It appears when the connection method is set to Static Binding, used to configure the step rule of the bound number in the batch setting, three options available: Increase, Decrease, Same.
Bound Number Step Size	It appears when the connection method is set to Static Binding, used to configure the increase or decrease step size of the bound number in the batch setting,

After configuration, click **Save** to save the settings into the gateway, or click **Cancel** to cancel the settings.

3.8.2 Port Group

Check	Index	Description	SIP Account	Authentication Username	Ports	Port Select Mode	Authentication Mode	Register Status	Server Index	Color Ring	Color Ring Index	Modify
<input type="checkbox"/>	1	default	---	---	1,2,3,4	Increase	Do Not Register	Unregistered	---	Disable	---	

1 Item Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-107 Port Group Settings Interface

See Figure 3-107 for the port group settings interface. A port group is a set containing single or multiple ports, used to specify such properties as **Port Selection** and **Authentication Mode** for all the ports in it. A new port group can be added by the **Add New** button on the bottom right corner of the above list. See Figure 3-108 for the port group adding interface. Note that a port which has been occupied by one port group cannot be chosen by others.

Port Group-Add

Index: 2

Description: default

Register Port Group: YES

SIP Account:

Password:

Authentication Username:

Server Index: 1:201.123.115.12

Authentication Mode: Do Not Register

Port Select Mode: Group Ringing

Color Ring: ☒ Enable

Color Ring Index: 1

Port: ☐ Port 1(WCDMA) ☐ Port 2(WCDMA) ☐ Port 3(WCDMA) ☐ Port 4(WCDMA) ☐ Port 5(WCDMA) ☐ Port 6(WCDMA) ☐ Port 7(WCDMA) ☐ Port 8(WCDMA)

Figure 3-108 Add New Port Group


The table below explains the items in the above figure.

Item	Description								
Index	The unique index of each port group, which is mainly used in the configuration of routing rules and number manipulation rules to correspond to port groups.								
Description	More information about each port group, with default value of <i>default</i> .								
Register Port Group	To register the port group to the SIP server. Only when this configuration item is set to Yes can you see the configuration items SIP Account and Password .								
SIP Account	When the port group initiates a call to SIP, this item corresponds to the username of SIP.								
Password	Registration password of the port group. To register the port group to the SIP server, both configuration items SIP Account and Password should be filled in.								
Authentication Username	Authentication username of a port, used to register the port to the SIP server when IMS network is enabled. Note: This item appears only when IMS Network is enabled.								
Server Index	The index of the sip server which will be quoted by the current port.								
Authentication Mode	Sets the way for SIP to make outgoing calls (Tel→IP) on the gateway.								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>Do Not Register (default)</i></td><td>SIP initiates a call in a point-to-point mode.</td></tr><tr><td><i>Register Port Group</i></td><td>SIP initiates a call with the registered SIP account and password of the port group.</td></tr><tr><td><i>Register Port</i></td><td>SIP initiates a call with the registered SIP account and password of the port.</td></tr></table>	Option	Description	<i>Do Not Register (default)</i>	SIP initiates a call in a point-to-point mode.	<i>Register Port Group</i>	SIP initiates a call with the registered SIP account and password of the port group.	<i>Register Port</i>	SIP initiates a call with the registered SIP account and password of the port.
	Option	Description							
	<i>Do Not Register (default)</i>	SIP initiates a call in a point-to-point mode.							
<i>Register Port Group</i>	SIP initiates a call with the registered SIP account and password of the port group.								
<i>Register Port</i>	SIP initiates a call with the registered SIP account and password of the port.								
Register Status	Registration status of the port group. See Figure 3-107. When Register Port Group is set to No, the value of this item is <i>Unregistered</i> ; when Register Port Group is set to Yes, the value of this item may be <i>Failed</i> or <i>Registered</i> .								

Port Select Mode	When the port group receives a call, it will choose a port based on the select mode set by this configuration item to ring or to connect. The optional values and their corresponding meanings are described in the table below.	
	Option	Description
	<i>Increase (default)</i>	Search for an idle port in the ascending order of the port number, starting from the minimum. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.
	<i>Decrease</i>	Search for an idle port in the descending order of the port number, starting from the maximum. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.
	<i>Cyclic Increase</i>	Provided Port N is the available port found last time. Search for an idle port in the ascending order of the port number, starting from Port N+1. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.
	<i>Cyclic Decrease</i>	Provided Port N is the available port found last time. Search for an idle port in the descending order of the port number, starting from Port N-1. If no match is found, search repeatedly until finding a port which is allowed to enter the call waiting state.
	<i>Group Ringing</i>	Ring all the idle wireless ports in this port group.
Color Ring	Sets whether to enable the color ring feature or not, with the default setting of being <i>disabled</i> . Note: Only when there are available color rings and the "Port Select Mode" is set to Grouping Ringing will this item appear.	
Color Ring Index	The index of the color ring which is quoted by the current wireless port.	
Port	The ports in the port group. If the checkbox before a port is grey, it indicates that the port is not available or has been occupied. All selected ports for a port group will be displayed in the Ports column in Figure 3-107. Note: When a port group contains multiple ports, the automatic call forward feature is invalid.	

After configuration, click **Save** to save the settings into the gateway, click **Cancel** to cancel the settings. **Check All** means to select all available ports on the current page; **Inverse** means to uncheck the selected items and check the unselected.

Click **Modify** in Figure 3-107 to modify the properties of a port group. See Figure 3-109 for the Port Group Modification interface. The configuration items on this interface are the same as those on the **Add New Port Group** interface.



The 'Port Group-Modify' interface contains the following fields and controls:


- Index:** A text input field containing the value '1'.
- Description:** A text input field containing the value 'default'.
- Register Port Group:** A dropdown menu with 'No' selected.
- Authentication Mode:** A dropdown menu with 'Do Not Register' selected.
- Port Select Mode:** A dropdown menu with 'Increase' selected.
- Port:** A section containing eight checkboxes, each labeled 'Port X(GSM)' where X is from 1 to 8. All checkboxes are checked.
- Buttons:** Below the port checkboxes are two buttons: 'Check All' and 'Inverse'.
- Footer Buttons:** At the bottom of the interface are three buttons: 'Modify', 'Reset', and 'Cancel'.

Figure 3-109 Modify Port Group

To delete a port group, check the checkbox before the corresponding index in Figure 3-107 and click the '**Delete**' button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all port groups at a time, click the **Clear All** button in Figure 3-107.

3.9 Route Settings

Route Settings is used to specify the routing rules for calls on two directions: IP→Tel/IP and Tel→IP. See Figure 3-110.




The 'Route' dialog box contains the following elements:

- Title Bar:** A tab labeled 'Route' with a close button on the right.
- Routing Parameters:** A section header.
- IP->Tel/IP:** A dropdown menu.
- Tel->IP:** A dropdown menu.

Figure 3-110 Route Settings

3.9.1 Routing Parameters



The 'Routing Parameters' configuration interface contains the following elements:

- Section Header:** 'Routing Parameters'.
- IP->TEL/IP:** A dropdown menu with 'Route before Number Manipulate' selected.
- TEL->IP:** A dropdown menu with 'Route before Number Manipulate' selected.
- Save Button:** A button labeled 'Save' at the bottom center.

Figure 3-111 Routing Parameters Configuration Interface

See Figure 3-111 for the routing parameters configuration interface. On this interface, you can set the routing rules for calls respectively on two directions IP→Tel/IP and Tel→IP to be routing before or after number manipulation. The default value is *Route before Number Manipulate*.

After configuration, click **Save** to save the above settings into the gateway.

3.9.2 IP to Tel/IP




Figure 3-112 IP→Tel/IP Routing Rule Configuration Interface (Standard)

See Figure 3-112 for the IP→Tel/IP routing rule configuration interface. By default, there is no available routing rule on the gateway. The IP→Tel/IP routing rule configuration has two modes: Standard and Character.

Under the Standard mode, click **Add New** to add them manually. See Figure 3-113. You may use the default values of all the configuration items herein.

Figure 3-113 Add New Routing Rule (IP→Tel/IP)

The table below explains the items shown in the above figure.

Item	Description
Index	The unique index of each routing rule, which denotes its priority. A routing rule with a smaller index value has a higher priority. If a call matches several routing rules, it will be processed according to the one with the highest priority.
Description	More information about each routing rule, with the default value of <i>default</i> .
Source IP	IP address from where the call is initiated. This item can be set to a specific IP address or "*" which indicates any IP address
CallerID Prefix, CalleeID Prefix	A string of characters at the beginning of the caller/called party number. It can be a specific string consisting of digits 0~9, "[*]", "#", or character ranges defined by []. '[]' represents a character within the range it defines. Values in [] only can be characters '0~9', "[*]", "#", punctuations '-' and ','; '-' is used between two characters to indicate any character between these two characters; ',' is used to separate characters or character ranges, representing alternatives.) For example, 057[1-3,6] represents the string 0571, 0572, 0573 or 0576. Also these items can be set to "*" which indicates any string. These two configuration items together with Source IP specify a routing rule for calls. Note: "[*]" represents TFM symbol *, while "*" represents any string; Multiple CallerID/CalleeID prefixes can be added simultaneously. They are separated by ":".
Route by Number	When this feature is enabled, the gateway will route a call from IP to a corresponding port based on its number. And the number of the port which this call will be routed to can be set via the item SIP Account on the Port Settings interface. In such case, the configuration item Call Destination goes invalid and shows Route by Number on the routing rule configuration interface. The default setting is <i>disabled</i> .
Call Destination	Designate a port group or an IP for the call to route.
Destination Port Group	Port group to which the call will be routed.
Destination IP, Destination Port	The IP address and port to which the call will be routed.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

See Figure 3-114 for the IP→Tel/IP routing rule configuration interface after your configuration. There is a rule displayed with Index 63 and Call Destination 'Route by Number', having no restriction on Source IP, CallerID Prefix and CalleeID Prefix, which indicates the gateway will route a call from any IP address to a corresponding port based on its number.

Press the **Add New** button on the bottom right corner of the list to add a new routing rule.

Standard Mode		Character Mode					
IP→Tel/IP Routing Rule							
Check	Index	Source IP	CallerID Prefix	CalleeID Prefix	Call Destination	Description	Modify
<input type="checkbox"/>	63	*	*	*	Route by Number	default	
Check All		Uncheck All		Inverse		Delete	
						Clear All	
1 Item Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total							
Add New							

Figure 3-114 IP→Tel/IP Routing Rule Configuration Interface

Click **Modify** in Figure 3-114 to modify a routing rule. The configuration items on the IP→Tel/IP routing rule modification interface are the same as those on the **Add New Routing Rule (IP→Tel/IP)** interface. Note that the item **Index** cannot be modified.

To delete a routing rule, check the checkbox before the corresponding index in Figure 3-114 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all routing rules at a time, click the **Clear All** button in Figure 3-114.

See Figure 3-115 for the IP→Tel/IP Routing Rule Configuration Interface under the Character mode. You can edit the routing rule list to add a new one or modify an old one. The exact meaning of each element of the rule is described on the page.




Figure 3-115 IP→Tel/IP Routing Rule Configuration Interface (Character)

3.9.3 Tel to IP




Figure 3-116 Tel→IP Routing Rule Configuration Interface (Standard)

See Figure 3-116 for the Tel→IP routing rule configuration interface. By default, there is no available routing rule on the gateway. The Tel→IP routing rule configuration has two modes: Standard and Character.

Under the Standard mode, click **Add New** to add them manually. See Figure 3-117. You may use

the default values of all the configuration items herein except for **Destination IP** and **Destination Port**.

Figure 3-117 Add New Routing Rule (Tel→IP)

The table below explains the items shown in the above figure.

Item	Description
Index	The unique index of each routing rule, which denotes its priority. A routing rule with a smaller index value has a higher priority. If a call matches several routing rules, it will be processed according to the one with the highest priority.
Description	More information about each routing rule, with the default value of <i>default</i> .
Source Port Group (Call Initiator)	Port group from which the call is initiated. This item can be set to a specific port group or '*' which indicates any port group.
CallerID Prefix, CalleelD Prefix	A string of characters at the beginning of the caller/called party number. It can be a specific string consisting of digits 0~9, "[*]", "#", or characters ranges defined by []. '[]' represents a character within the range it defines. Values in [] only can be digits '0~9', "[*]", "#", punctuations '-' and ';'. '-' is used between two characters to indicates any characters between these two characters. ';' is used to separate characters or characters ranges, representing alternatives.) For example, 057[1-3,6] represents the string 0571, 0572, 0573 or 0576. Also these items can be set to "*" which indicates any string. These two configuration items together with Source Port Group (Call Initiator) specify a routing rule for calls. Note: "[*]" represents DTFM symbol *, while "*" represents any string; Multiple CallerID/CalleelD prefixes can be added simultaneously. They are separated by ":".
Destination IP, Destination Port	IP address and port number of the remote end to which the call will be routed.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

See Figure 3-118 for the Tel→IP routing rule configuration interface after your configuration. There is a rule displayed with Index 63, Destination IP '192.168.1.101' and Destination Port '5060' (i.e. default IP address and port of the gateway), having no restriction on Call Initiator, CallerID Prefix and CalleeID Prefix, which indicates all the outgoing calls from Tel which conform to the dialing rule will be routed to the gateway.

Standard Mode		Character Mode						
Tel->IP Routing Rule								
Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	Destination IP	Destination Port	Description	Modify
<input type="checkbox"/>	63	*	*	*	192.168.1.101	5060	default	
<div>Check All Uncheck All Inverse Delete Clear All Add New</div> <div>1 Item Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total</div>								

Figure 3-118 Tel→IP Routing Rule Configuration Interface

Click **Modify** in Figure 3-118 to modify a routing rule. The configuration items on the Tel→IP routing rule modification interface are the same as those on the **Add New Routing Rule (Tel→IP)** interface. Note that the item **Index** cannot be modified.

To delete a routing rule, check the checkbox before the corresponding index in Figure 3-118 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all routing rules at a time, click the **Clear All** button in Figure 3-118.

See Figure 3-119 for the Tel→IP Routing Rule Configuration Interface under the Character mode. You can edit the routing rule list to add a new one or modify an old one. The exact meaning of each element of the rule is described on the page.

Standard Mode	Character Mode
Tel->IP Routing Rule	
Note: The routing information contains such fields as Source Port Group, CallerID Prefix, CalleeID Prefix, Destination IP, Destination Port and Description The priority decreases from top to bottom; adjacent fields are separated by a space CallerID Prefix, CalleeID Prefix, Destination IP Symbol * indicates any character; Source Port Group set to 0 denotes any port group. Don't forget to save the configuration after your modification!	
0 * * 192.168.1.101 5060 default	
1 Item Total	
Save	

Figure 3-119 Tel→IP Routing Rule Configuration Interface (Character)

3.10 Number Manipulation

Number Manipulation includes four parts: **IP→Tel/IP CallerID**, **IP→Tel/IP CalleeID**, **Tel→IP CallerID** and **Tel→IP CalleeID**. See Figure 3-120.




Figure 3-120 Number Manipulation

3.10.1 IP to Tel/IP CallerID




Figure 3-121 IP→Tel/IP CallerID Manipulation Interface (Standard)

See Figure 3-121 for the IP→Tel/IP CallerID manipulation interface under the Standard mode. A new number manipulation rule can be added by the **Add New** button on the bottom right corner of the list in the above figure. See Figure 3-122 for the IP→Tel/IP CallerID manipulation rule adding interface. You may use the default values of all the configuration items herein.

IP->Tel/IP CallerID

Index:

63 ▼

Description:

default

Call Initiator:

*

CallerID Prefix:

*

CalleeID Prefix:

*

Stripped Digits from Left:

0

Stripped Digits from Right:

0

Reserved Digits from Right:

0

Prefix to Add:

Suffix to Add:

Save

Close

Figure 3-122 Add IP→Tel/IP CallerID Manipulation Rule

The table below explains the items shown in the above figure.

Item	Description
<i>Index</i>	The unique index of each number manipulation rule, which denotes its priority. A number manipulation rule with a smaller index value has a higher priority. If a call matches several number manipulation rules, it will be processed according to the one with the highest priority.
<i>Description</i>	More information about each number manipulation rule, with the default value of <i>default</i> .
<i>Call Initiator</i>	IP address from where the call is initiated. This item can be set to a specific IP address or "*" which indicates any IP address.

CallerID Prefix, CalleelD Prefix	<p>A string of characters at the beginning of the caller/called party number. It can be a specific string consisting of digits 0~9, "[*]", "#", or character ranges defined by []. '[' represents a character within the range it defines. Values in [] only can be digits '0~9', "[*]", "#", punctuations '-' and ';'. ('-' is used between two characters to indicates any character between these two characters. ';' is used to separate characters or character ranges, representing alternatives.) For example, 057[1-3,6] represents the string 0571, 0572, 0573 or 0576. Also these items can be set to "*" which indicates any string. These two configuration items together with Call Initiator specify a number manipulation rule for calls.</p> <p>Note: "[*]" represents DTFM symbol *, while "*" represents any string; Multiple CallerID/CalleelD prefixes can be added simultaneously. They are separated by ":".</p>
Stripped Digits from Left	The amount of digits to be deleted from the left end of the number. If the value of this item exceeds the length of the current number, the whole number will be deleted.
Stripped Digits from Right	The amount of digits to be deleted from the right end of the number. If the value of this item exceeds the length of the current number, the whole number will be deleted.
Reserved Digits from Right	The amount of digits to be reserved from the right end of the number. Only when the value of this item is less than the length of the current number will some digits be deleted from left; otherwise, the number will not be manipulated.
Prefix to Add	Designated information to be added to the left end of the current number.
Suffix to Add	Designated information to be added to the right end of the current number.

Note: The number manipulation is performed in 5 steps by the order of the following configuration items: **Stripped Digits from Left**, **Stripped Digits from Right**, **Reserved Digits from Right**, **Prefix to Add** and **Suffix to Add**.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings. See the figure below.

Figure 3-123 IP→Tel/IP CallerID Manipulation Interface (Standard)

Click **Modify** in Figure 3-123 to modify a number manipulation rule. See Figure 3-124 for the IP→Tel/IP CallerID manipulation rule modification interface. The configuration items on this interface are the same as those on the **Add IP→Tel/IP CallerID Manipulation Rule** interface. Note that the item **Index** cannot be modified.

IP→Tel/IP CallerID

Index:

63 ▼

Description:

default

Call Initiator:

*

CallerID Prefix:

*

CalleedID Prefix:

*

Stripped Digits from Left:

0

Stripped Digits from Right:

0

Reserved Digits from Right:

0

Prefix to Add:

Suffix to Add:

Save

Close

Figure 3-124 Modify IP→Tel/IP CallerID Manipulation Rule

To delete a number manipulation rule, check the checkbox before the corresponding index in Figure 3-123 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all number manipulation rules at a time, click the **Clear All** button in Figure 3-123.

See Figure 3-125 for the IP→Tel/IP CallerID Manipulation Interface under the Character mode. You can edit the number manipulation rule list to add a new one or modify an old one. The exact meaning of each element of the rule is described on the page.

Standard Mode | Character Mode

IP->Tel/IP CallerID Number Manipulation Rule

Note: The Number Manipulation Rule contains such fields as Call Initiator, CallerID Prefix, CalleeID Prefix, Delete Digits from Left, Delete Digits from Right, Reserve Digits from Right, Add Prefix, Add Suffix and Description
 The priority decreases from top to bottom; by default, the rule will be inserted to the end after you click 'Add'. If you want to increase its priority, please copy it to the corresponding position.
 Adjacent fields are separated by a space; Symbol * in Call Initiator, CallerID Prefix and CalleeID Prefix indicates any string; Symbol <@#> in Add Prefix and Add Suffix denotes not to add.
 Don't forget to save the configuration after your modification!

***000 <@#> <@#> default

1 Item Total

Save

Figure 3-125 IP→Tel/IP CallerID Manipulation Interface (Character)

3.10.2 IP to Tel/IP CalleeID

The number manipulation process for IP→Tel/IP CalleeID is almost the same as that for IP→Tel/IP CallerID; only the number to be manipulated changes from CallerID to CalleeID. See Figure 3-126, Figure 3-127 for IP→Tel/IP CalleeID Manipulation interface. The configuration items on this interface are the same as those on **IP→Tel/IP CallerID Manipulation Interface** (Figure 3-123).

Standard Mode | Character Mode

IP->Tel/IP CalleeID Number Manipulation Rule

Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	Stripped Digits from Left	Stripped Digits from Right	Reserved Digits from Right	Prefix to Add	Suffix to Add	Description
<input type="checkbox"/>	63	*	*	*	0	0	0			

Check All | Uncheck All | Inverse | Delete | Clear All | Add New

1 Item Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-126 IP→Tel/IP CalleeID Manipulation Interface(Standard)

Standard Mode

Character Mode

IP->Tel/IP CalleeID Number Manipulation Rule

Note: The Number Manipulation Rule contains such fields as Call Initiator, CallerID Prefix, CalleeID Prefix, Delete Digits from Left, Delete Digits from Right, Reserve Digits from Right, Add Prefix, Add Suffix and Description

The priority decreases from top to bottom; by default, the rule will be inserted to the end after you click 'Add'. If you want to increase its priority, please copy it to the corresponding position.

Adjacent fields are separated by a space; Symbol * in Call Initiator, CallerID Prefix and CalleeID Prefix indicates any string; Symbol <@#> in Add Prefix and Add Suffix denotes not to add.

Don't forget to save the configuration after your modification!

***000 <@#> <@#> default

1 Item Total

Save

Figure 3-127 IP→Tel/IP CalleeID Manipulation Interface (Character)

3.10.3 Tel to IP CallerID

Standard Mode

Character Mode

Tel->IP CallerID Number Manipulation Rule

Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	Stripped Digits from Left	Stripped Digits from Right	Reserved Digits from Right	Prefix to Add	Suffix to Add	Description
<input type="checkbox"/>	63	*	*	*	0	0	0			

Check All

Uncheck All

Inverse

Delete

Clear All

Add New

1 Item Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-128 Tel→IP CallerID Manipulation Interface (Standard)

See Figure 3-128 for the Tel→IP CallerID manipulation interface under the Standard mode. A new number manipulation rule can be added by the **Add New** button on the bottom right corner of the list in the above figure. See Figure 3-129 for the Tel→IP CallerID manipulation rule adding interface. You may use the default values of all the other configuration items herein.




Figure 3-129 Add Tel→IP CallerID Manipulation Rule

The table below explains the items shown in the above figure.

Item	Description
Index	The unique index of each number manipulation rule, which denotes its priority. A number manipulation rule with a smaller index value has a higher priority. If a call matches several number manipulation rules, it will be processed according to the one with the highest priority.
Description	More information about each number manipulation rule, with the default value of <i>default</i> .
Source Port Group (Call Initiator)	Port group from which the call is initiated. This item can be set to a specific port group or '*' which indicates any port group.
CallerID Prefix, CalleeID Prefix	A string of characters at the beginning of the caller/called party number. It can be a specific string consisting of digits 0~9, "[*]", "#", or character ranges defined by []. '[' represents a character within the range it defines. Values in [] only can be digits '0~9', "[*]", "#", punctuations '-' and ','. '-' is used between two characters to indicate any character between these two characters. ',' is used to separate characters or character ranges, representing alternatives.) For example, 057[1-3,6] represents the string 0571, 0572, 0573 or 0576. Also these items can be set to "*" which

	<p>indicates any string. These two configuration items together with Call Initiator specify a number manipulation rule for calls.</p> <p>Note: “[*]” represents DTFM symbol *, while “*” represents any string; Multiple CallerID/CalleeID prefixes can be added simultaneously. They are separated by “.”.</p>
Stripped Digits from Left	The amount of digits to be deleted from the left end of the number. If the value of this item exceeds the length of the current number, the whole number will be deleted.
Stripped Digits from Right	The amount of digits to be deleted from the right end of the number. If the value of this item exceeds the length of the current number, the whole number will be deleted.
Reserved Digits from Right	The amount of digits to be reserved from the right end of the number. Only when the value of this item is less than the length of the current number will some digits be deleted from left; otherwise, the number will not be manipulated.
Prefix to Add	Designated information to be added to the left end of the current number.
Suffix to Add	Designated information to be added to the right end of the current number.

Note: The number manipulation is performed in 5 steps by the order of the following configuration items: **Stripped Digits from Left**, **Stripped Digits from Right**, **Reserved Digits from Right**, **Prefix to Add** and **Suffix to Add**.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-128 to modify a number manipulation rule. See Figure 3-130 for the Tel→IP CallerID manipulation rule modification interface. The configuration items on this interface are the same as those on the **Add Tel→IP CallerID Manipulation Rule** interface. Note that the item **Index** cannot be modified.




Figure 3-130 Modify Tel→IP CallerID Manipulation Rule

To delete a number manipulation rule, check the checkbox before the corresponding index in Figure 3-128 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all number manipulation rules at a time, click the **Clear All** button in Figure 3-128.

See Figure 3-131 for the Tel→IP CallerID Manipulation Interface under the Character mode. You can edit the number manipulation rule list to add a new one or modify an old one. The exact meaning of each element of the rule is described on the page.

Standard Mode Character Mode

Tel->IP CallerID Number Manipulation Rule

Note: The Number Manipulation Rule contains such fields as Source Port Group, CallerID Prefix, CalleeID Prefix, Delete Digits from Left, Delete Digits from Right, Reserve Digits from Right, Add Prefix, Add Suffix and Description
The priority decreases from top to bottom; Adjacent fields are separated by a space.
Symbol * in Call Initiator, CallerID Prefix and CalleeID Prefix indicates any string; Symbol <@#> in Add Prefix and Add Suffix denotes not to add.
Don't forget to save the configuration after your modification!

0 * * 0 0 0 <@#> <@#> default

1 Item Total

Save

Figure 3-131 Tel->IP CallerID Manipulation Interface (Character)

3.10.4 Tel to IP CalleeID

The number manipulation process for Tel->IP CalleeID is almost the same as that for Tel->IP CallerID; only the number to be manipulated changes from CallerID to CalleeID. See Figure 3-132, Figure 3-133 for the Tel->IP CalleeID manipulation interface. The configuration items on this interface are the same as those on **Tel->IP CallerID Manipulation Interface** (Figure 3-128).

Standard Mode Character Mode

Tel->IP CalleeID Number Manipulation Rule

Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	Stripped Digits from Left	Stripped Digits from Right	Reserved Digits from Right	Prefix to Add	Suffix to Add	Description
<input type="checkbox"/>	63	*	*	*	0	0	0			

Check All Uncheck All Inverse Delete Clear All Add New

1 Item Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-132 Tel->IP CalleeID Manipulation Interface (Standard)

Standard Mode Character Mode

Tel->IP CalleeID Number Manipulation Rule

Note: The Number Manipulation Rule contains such fields as Source Port Group, CallerID Prefix, CalleeID Prefix, Delete Digits from Left, Delete Digits from Right, Reserve Digits from Right, Add Prefix, Add Suffix and Description
The priority decreases from top to bottom; Adjacent fields are separated by a space.
Symbol * in Call Initiator, CallerID Prefix and CalleeID Prefix indicates any string; Symbol <@#> in Add Prefix and Add Suffix denotes not to add.
Don't forget to save the configuration after your modification!

0 * * 0 0 0 <@#> <@#> default

1 Item Total

Save

Figure 3-133 Tel→IP CalleeID Manipulation Interface (Character)

3.11 System Tools

System Tools is mainly for gateway maintenance. It provides such features as change password, data backup and connectivity check. See Figure 3-134 for details.




Figure 3-134 System Tools

3.11.1 Upgrade

Current Version	
Serial Num	16873
WEB	Version 1.8.0_2017101109
Service	Version 1.8.0_2017101109
FPGA	Version 2.05
U-boot	Version Aug 18 2016-06:40:25
Kernel	Version #233 Tue Jan 10 14:45:17 CST 2017
Device Type	SMG4016-16G

Select an Update File

Note: Please make sure to update the WEB package before the FPGA package.

Figure 3-135 Upgrade Interface

See Figure 3-135 for the upgrade interface where you can upgrade the WEB, gateway service, kernel and firmware to new versions. Select the upgrade package “*.tar.gz” (The gateway will do MD5 verification before upgrading and will not start to upgrade until it passes the verification.) via **Browse...** and click **Update**. Then the file uploading interface will appear. See Figure 3-136.

Current Version	
Serial Num	16873
WEB	Version 1.8.0_2017101109
Service	Version 1.8.0_2017101109
FPGA	Version -1
U-boot	Version Aug 18 2016-06:40:25
Kernel	Version #233 Tue Jan 10 14:45:17 CST 2017
Device Type	SMG

Note: Please make sure to update the WEB package before the FPGA package.

46%

2015kb/s

The file is uploading. Please do not leave this page!.....

Upgrade Information

start upload upgrade file...

Figure 3-136 File Uploading Interface

After a successful uploading of the file, the gateway will start to upgrade the system. See Figure 3-137 and you can learn the detailed upgrading information from the upgrade information box at the bottom.

Current Version	
Serial Num	16873
WEB	Version 1.8.0_2017101109
Service	Version 1.8.0_2017101109
FPGA	Version 2.05
U-boot	Version Aug 18 2016-06:40:25
Kernel	Version #233 Tue Jan 10 14:45:17 CST 2017
Device Type	SMG4016-16G

Note: Please make sure to update the WEB package before the FPGA package.

Upload completion!

18%

System updating, please do not leave this page!.....

Upgrade Information

```
[setp 3]: kill common task
SmgMonitor pid=
SMGSvr pid=
DbgSvr pid=966
967
969
970
do killall DbgSvr
[setp 4]: copy package file to storage...
```

Figure 3-137 System Upgrading Interface

Note that clicking **Reset** can only delete the selected update file but not cancel the operation of **Update**.

Note: Please contact our technicians if you need to downgrade the gateway to an old version. An improper operation may cause unexpected problems.

3.11.2 Signaling Capture

Packet Capture	
Signaling Packet Capture	SIP&Syslog&Cent
RTP Packet Capture	RTP Port Range 50000,50767
<div>Start</div> <div>Download</div>	

Note: Only latest 50M capture data will be saved.

Figure 3-138 Signaling Capture Interface

See Figure 3-138 for the Signaling Capture interface. Packet capture contains Signaling Packet

Capture, RTP Packet Capture. You can select either of them to start the capture according to your requirement. Click **Start** to start capturing packets. Click **Stop** to stop the capture. Click **Download** to download the captured packets.

3.11.3 Data Recording




Figure 3-139 Data Recording Interface

See Figure 3-139 for the Data Recording interface. Click **Start** to start the recording. Click **Stop** to stop the recording. Click **Download** to download the recorded data.

3.11.4 Call Log




Figure 3-140 Call Log Interface




Figure 3-141 SIP Log Interface

See Figure 3-140, Figure 3-141 for the Call Log interface. Click the checkbox before **Enable Call Log** to enable the call log feature, including **Call Log** and **SIP Log**. **Call from IP Channel** displays the call log information generated on all IP channels, and **Call from Port** displays the call log information generated on the port you select. All the SIP related information will be displayed in **SIP Log**.

3.11.5 Operation Log





Figure 3-142 Operation Log Interface

See Figure 3-142 for the Operation Log interface, which is used to check the operation records on WEB. Click **Refresh** to refresh the log; click **Clear All** to clear all the operation logs and click **Download** to download the logs. The operation log will be automatically cleared once the system restarts.

Note: The sign <@#> here means the configuration item is null.

3.11.6 Change Password




The 'Change Password' interface features a light blue header bar with the title 'Change Password'. Below the header, there are five input fields arranged vertically. The first field is labeled 'Current Username' and contains the text 'admin'. The second field is labeled 'Current Password'. The third field is labeled 'New Username'. The fourth field is labeled 'New Password'. The fifth field is labeled 'Confirm New password'. At the bottom of the form, there are two blue buttons: 'Save' and 'Reset'.

Figure 3-143 Password Changing Interface

See Figure 3-143 for the password changing interface where you can change username and password of the gateway. Enter the current password, the new username and password, and then confirm the new password. After configuration, click **Save** to apply the new username and password or click **Reset** to restore the configurations. After changing the username and password, you are required to log in again.

3.11.7 Backup & Upload



The 'Backup & Upload' interface is divided into two main sections. The top section, titled 'Data Backup', has a light blue header and contains the instruction 'To backup the configuration file, click the 'Backup' button to start.' followed by a blue 'Backup' button. The bottom section, titled 'Data Upload', also has a light blue header and contains the instruction 'To upload a configuration file, select it and click the button 'Upload' to start.' Below this instruction, there is a 'Configuration File' label, an empty text input field, a 'Browse...' button, and a blue 'Upload' button. At the very bottom of the interface, a red note states: 'Note: After you successfully upload the configuration file, the gateway will restart automatically.'

Figure 3-144 Backup & Upload Interface

See Figure 3-144 for the backup and upload interface. To back up the configuration file to your PC, just click **Backup**. To upload a configuration file, select it via **Browse...** and click **Upload**.




Figure 3-145 Backup & Upload & Prompt Interface

Click **OK** on the prompt box (Figure 3-145) to upload the configuration file to the gateway. Now the prompt information 'System is rebooting, please do not leave this page' appears. See Figure 3-146. The gateway will overwrite the current configurations with the uploaded data after restart. Click **Cancel** to cancel this upload directly.




Figure 3-146 Configuration File Uploading Interface


3.11.8 Factory Reset



Figure 3-147 Factory Reset Interface

See Figure 3-147 for the factory reset interface. Click **Reset** to restore all configurations on the gateway to factory settings.

3.11.9 Restart




The interface is titled "System Restart" in a blue header bar. Below the header, there is a light gray box containing the text "Click the button 'Restart' to restart the system." on the left, a blue "Restart" button in the center, and a checkbox labeled "Generate a Dump File" on the right. Below this box is another light gray box titled "Dump File Download" in a blue header bar. This box contains the text "Click the button 'Download' to download the dump file." on the left and a blue "Download" button on the right.

Figure 3-148 System Restart Interface

See Figure 3-148 for the restart interface. Click **Restart** under the service restart interface to restart the gateway service or click **Restart** under the system restart interface to restart the whole gateway system. A dump file will be generated each time you restart the service or the system. Click **Download** and you can download it to help troubleshoot issues.

3.11.10 System Monitor



The interface is titled "System Monitor" in a blue header bar. Below the header, there is a light gray box containing three configuration items: "Watchdog:" with a checked checkbox and the word "Enable"; "Dog Feeding Interval (s)" with a text input field containing the value "5"; and "Automatically restart the service if undetected:" with a checked checkbox and the word "Enable". Below this box, there are two blue buttons: "Save" and "Reset".

Figure 3-149 System Monitor Configuration Interface

See Figure 3-149 for the System Monitor Configuration interface. Watchdog is a timing reset system used to avoid application crash. You can set the dog feeding interval when this feature is enabled. The feeding interval is calculated by s, with the value range of 1~15s. By default, this feature is enabled with the default value of 5s. As the feature 'Automatically restart the service if undetected' is enabled, the service application will restart automatically if it is not detected by the gateway guard application. By default, this feature is enabled.

3.11.11 Centralized Manage

Centralized Manage

Centralized Manage ☒ Enable

DCMS Server Address *

Company Name *

Authorization Code *

Gateway Description

Working Status Disabled

Save Reset

Figure 3-150 Centralized Manage Setting Interface

See Figure 3-150 for the Centralized Manage Setting interface. The gateway can register to a centralized management platform and accept the management of the platform. The table below explains the items shown in above figures.

Item	Description
DCMS Server Address	The address of the server in which the DCMS locates, It can be IP or a domain name. Note: To configure the domain name, make sure the DNS is already configured and the corresponding domain name is analyzable.
Company Name	The company name used to register the gateway to DCMS, only valid when DCMS is selected.
Authorization Code	The authorization code is used for the connection verification. A device can connect to the DCMS successfully only after it passes the verification.
Gateway Description	The description displayed on Synway DCMS after the gateway is registered to Synway DCMS, giving an easy identification of the gateway in device grouping. It is valid only when Synway DCMS is selected
Working Status	The status of the connection between the gateway and the centralized management server.

3.11.12 PING Test




Figure 3-151 Ping Test Interface

See Figure 3-151 for the Ping test interface. A Ping test can be initiated from the gateway on a designated IP address to check the connection status between them. The table below explains the configuration items shown in the above figure.

Item	Description
Destination Address	Destination IP address or domain name on which the Ping test is executed.
Ping Count	The number of times that the Ping test should be executed. Range of value: 1~100.
Package Length	Length of the data package used in the Ping test. Range of value: 56~1024 bytes.
Info	The information returned during the Ping test, helping you to learn the network connection status between the gateway and the destination address.

After configuration, click **Start** to execute the Ping test; click **End** to terminate it immediately.

3.11.13 TRACERT Test


The image shows a web-based interface for a Tracert test. At the top, there is a blue header bar with the text "Tracert Test". Below this, the interface is divided into several sections. The first section contains two input fields: "Destination Address" with the value "127.0.0.1" and "Maximum Jumps (1-255)" with the value "30". Below these fields are two blue buttons labeled "Start" and "End". The second section is labeled "Info" and contains a large, empty text area with a vertical scrollbar on the right side.


Figure 3-152 Tracert Test Interface

See Figure 3-152 for the Tracert test interface. A Tracert test can be initiated from the gateway on a designated IP address to check the routing status between them. The table below explains the configuration items shown in the above figure.

Item	Description
Source IP Address	Source IP address where the Tracert test is initiated.
Destination Address	Destination IP address on which the Tracert test is executed.
Maximum Jumps	Maximum number of jumps between the gateway and the destination address which are returned by the Tracert test. Range of value: 1~255.
Info	The information returned during the Tracert test, helping you to learn the detailed information about the jumps between the gateway and the destination address.

After configuration, click **Start** to execute the Tracert test; click **End** to terminate it immediately.

3.11.14 Wireless Network Test



The figure shows a software interface titled "Wireless Network Test". It contains four configuration fields: "Port" with a dropdown menu showing "1", "Called Number" with an empty text box, "Conversation Time Length (s)" with a dropdown menu showing "5", and "Call Times" with a dropdown menu showing "1". Below these fields are two buttons: "Start" and "Stop". At the bottom, there is an "Info" label next to a large, empty rectangular box.

Figure 3-153 Wireless Network Test Interface

See Figure 3-153 for the Wireless Network Test interface. This test is to check whether the SIM card inserted in the gateway port can make normal calls. The table below gives the explanation to the configuration items shown in the above figure.

Item	Description
Port	The port used for the test
Called Number	The called party number which will be dialed for the test
Conversion Time Length	The time length of the conversion
Call Times	The times of the testing call

After configuration, click **Start** to execute the test; click **Stop** to terminate it immediately.

3.11.15 Access Control

Access Control List			
Check	Index	Command	Modify
<input type="checkbox"/>	0	iptables -I INPUT -s 123.45.6.7 -j DROP	
<div> <input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Inverse"/> <input type="button" value="Delete"/> <input type="button" value="Clear All"/> <input type="button" value="Apply"/> <input type="button" value="Add New"/> </div>			
1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total Note: Please don't enable "SIP"=>"Calls from SIP Trunk Address only".			

Figure 3-154 Access Control List Interface

See Figure 3-154 for the Access Control List interface. You can add a piece of command to ACL to restrict the network flow. Thus only the particular devices are allowed to visit the gateway and only the data packages on the designated ports can be forwarded. Click **Add New** to add a new piece of command. See Figure 3-155.

Access Control Command	
Index:	<input type="text" value="1"/>
Command:	<input type="text"/>
<input type="button" value="Save"/> <input type="button" value="Close"/>	

Figure 3-155 Add Access Control Command Interface

Fill in a piece of command to the item Command and click **Save** to save the settings to the gateway. Click **Close** to cancel your settings. Click **Apply** to make the new command valid.

Click **Modify** in Figure 3-154 to modify a command. See Figure 3-156 for the Access Control Command Modification interface. The configuration items on this interface are the same as those on the **Add Access Control Command** interface. Note that the item **Index** cannot be modified.

Access Control Command	
Index:	<input type="text" value="0"/>
Command:	<input type="text" value="iptables -I INPUT -s 123.45.6.7 -j DROP"/>
<input type="button" value="Save"/> <input type="button" value="Close"/>	


Figure 3-156 Access Control Command Modification Interface

To delete an Access Control Command, check the checkbox before the corresponding index in Figure 3-154 and click the **Delete** button, and then click the **Apply** button to make the deleted command invalid. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all access control commands at a time, click the **Clear All** button in Figure 3-154.

Note:

- 1, Currently, only the command iptables is supported by the gateway.
- 2, If you add or modify or delete commands manually, don't forget to click the **Apply** button to make your settings valid. However, if the gateway restarts or the configuration is leading-in, you need not click the **Apply** button and the commands will get valid automatically.

3.11.16 Device Lock



The image shows a web-based configuration interface titled "Device Lock". At the top right, there is a checkbox labeled "Enable" which is checked. Below this, under the heading "Lock Parameter", there are two checkboxes: "IP Address" and "Registrar Server", both of which are checked. The interface then presents two password fields. The first section is labeled "Primary Password (for disabling the lock feature or unlocking the device):" and contains "Password" and "Confirm Password" input boxes. The second section is labeled "Secondary Password (for modifying the parameters in case the the lock feature is enabled):" and also contains "Password" and "Confirm Password" input boxes. At the bottom of the interface, there are two buttons: "Enable" and "Reset".

Figure 3-157 Device Lock Configuration Interface

See Figure 3-157 for the Device Lock Configuration interface. This feature is unopened. If you need use it, please contact our technicians to apply for a special link to access the gateway again.

Appendix A Technical Specifications

Dimensions

4004/4008 series: 260×30×153mm³

4016/4032 series: 440×44×200mm³

Weight

4004/4008 series Net: 1.2 kg

4016 series Net: 2.4 kg

4032 series Net: 3.1 kg

Environment

Operating temperature: 0℃—45℃

Storage temperature: -20℃—85℃

Humidity: 8%— 90% non-condensing

Storage humidity: 8%— 90% non-condensing

LAN

Amount: 2 (10/100 BASE-TX (RJ-45))

Self-adaptive bandwidth supported

Auto MDI/MDIX supported

Console Port

Amount: 1 (RS-232)

Baud rate: 115200bps

Connector: RJ45 to DB-9 Connector (4004/4008 series), Mini-USB connecting line (4016/4032 series)

Data bits: 8 bits

Stop bit: 1 bit

Parity unsupported

Flow control unsupported

Note: Follow the above settings to configure the serial port; or it may work abnormally.

Power Requirements

Input power: 12V DC ±10%

Input Current: ≥3A DC

Signaling & Protocol

SIP signaling

Supported protocol: SIP V1.0/2.0, RFC3261

Network Protocol

IP v4, UDP/TCP, PPPoE, DHCP,

FTP/TFTP ARP, RARP, NTP,

HTTP, Telnet

Audio Encoding & Decoding

G.711A 64 kbps

G.711U 64 kbps

G.729A/B 8 kbps

G.723 5.3/6.3 kbps

G.722 64 kbps

AMR 4.75 kbps

iLBC 13.3/15.2 kbps

Sampling Rate

8kHz

Wireless Feature

SMS CODEC: ASCII/UCS2

Others

The LTE series gateways support the VoLTE network so that they provide quick call establishment and stay unaffected by the Base Station capacity.

Appendix B Troubleshooting

Q1. What to do if I forget the IP address of the wireless gateway?

There are two ways to get the IP address:

- 1) Long press the Reset button on the gateway to restore to factory settings. The default IP address is 192.168.1.101
- 2) Make a call to any wireless port and press the function key to query the IP address. See [3.5.5 Function Key](#) for more details.

Q2. In what cases can I conclude that the wireless gateway is abnormal and turn to Synway's technicians for help?

- a) During runtime, the run indicator does not flash or the alarm indicator lights up or flashes, and such error still exists even after you restart the device or restore it to factory settings.
- b) Voice problems occur during call conversation, such as that one party or both parties cannot hear the voice or the voice quality is unacceptable.
- c) The port of the gateway is well connected with the antenna and has a SIM card properly inserted, but the port indicator never lights up after the gateway startup or the color it lights up does not comply with the actual port state or port type.

Other problems such as inaccessible calls, failed registrations, incorrect numbers are probably caused by configuration errors. We suggest you refer to [Chapter 3 WEB Configuration](#) for further examination. If you still cannot figure out or solve your problems, please feel free to contact our technicians.

Q3. What to do if I cannot enter the WEB interface of the gateway after login?

This problem may happen on some browsers. To settle it, follow the instructions here to configure your browser. Enter 'Tools > Internet Options > Security Tab', and add the current IP address of the gateway into 'Trusted Sites'. If you changes the IP address of the gateway, add your new IP address into the above settings too.

Q4. Is there any cell-phone APP can make calls to the gateway?

Yes. Linphone is a soft SIP phone that is supported by multiple platforms, such as Linux, Windows, iOS, Android, etc. It must be registered to the SIP registrar server before dialing to other SIP devices or PSTN telephones,


Q5. Which RTP codecs are supported by the gateway?

At present, the supported RTP codecs are: G.711A, G.711u, G.729, G.723, G.722, AMR and iLBC.


Appendix C About VPN

Part 1: Steps to Enable VPN Feature


Find the VPN Settings interface under Advanced Settings on the web. This featured is disabled by default.



Step 1: Select Yes to enable this feature, click the 'Save' button and the following interface will appear.



Step 2: Select a certificate from the client, that is, a configuration file with the suffix of .conf, and then click the 'Upload' button. The following dialog will appear.



Step 3: Now you will get a virtual IP address which is allocated automatically by the VPN server.
Note that each upload will lead to a new allocation of the IP address; however, restarting the gateway will not change the virtual IP address.

Then you may use the PING test under System Tool on the web to test if the client connects successfully with the server via IP, by which to check whether the VPN feature is successfully enabled or not.

Part 2: Steps to Make VPN Certificate

Step 1: Get the file of client.ovpn from the VPN server (under the 'sample-config' directory of the installation package) and rename it to "client.conf".

Step 2: Examine or add the following content into the file.

The file should contain the following content, in which the black part is fixed while the red part shall change according to the note.

client

dev tap (Note: Fill in tap or tun according to the VPN server's requirement. Currently, only tap is supported.)

proto tcp (Note: Connect via TCP which should be consistent with that of the server.)

;cipher AES-128-CBC (Note: Select an encryption algorithm which should be consistent with that of the client. It is not necessary to add if there is no algorithm at the client.)

remote 192.168.143.235 1194 udp (Note: Fill in the IP address and the port number of the VPN server, and the protocol can be left empty.)

;remote-random (Note: If there are multiple servers configured, let the client connect at random.)

resolv-retry infinite (Note: Analyze the server's domain name)

nobind (Note: Not to bind any port to the client)

persist-tun

persist-key

mute-replay-warnings (Note: Set as a flag to warn about replayed data packages.)

ns-cert-type server

comp-lzo (Note: Use the lzo compression which is consistent with the server.)

verb 3

;tls-client

;tls-auth ta.key 1 (Note: It is used to enable the feature of TLS encryption, and should be consistent with that of the server.)

<ca>

-----BEGIN CERTIFICATE-----

Note: Fill in the key copied from the file of ca.crt.

-----END CERTIFICATE-----

</ca>

<cert>

-----BEGIN CERTIFICATE-----

Note: Fill in the key copied from the file of client.crt, that is, the content inbetween "-----BEGIN CERTIFICATE-----" and "-----ENDCERTIFICATE-----"

-----END CERTIFICATE-----

</cert>

<key>

-----BEGIN RSA PRIVATE KEY-----

Note: Fill in the key copied from the file of client.key

-----END RSA PRIVATE KEY-----

</key>

Note: The following key is not necessary to add if it is never encrypted at the server.

<tls-auth>

Note: Fill in the key copied from the file of ta.key

</tls-auth>

Make sure the three key files ca.crt, client.crt and client.key are of the newest versions.

Step 3: Save the file after your examination or supplement and upload it to the device. Note that the suffix of the file must be .conf.

Part 3: Attentions

- a) After the VPN featured is opened at the server, use your PCs to connect as a test. If two PCs can PING through each other, it means the server works normally.

- b)** Make sure the server is OK and the configuration file is ready before opening the VPN feature.
The system time of the wireless gateway must be consistent with that of the server, or the connection may sometimes fails.
- c)** After enabling the VPN feature successfully, you can use the virtual IP of the gateway to make calls in both directions IP-->tel and tel-->IP.

Appendix D Technical/sales Support

Thank you for choosing Synway. Please contact us should you have any inquiry regarding our products. We shall do our best to help you.

Headquarters

Synway Information Engineering Co., Ltd

<http://www.synway.net/>

9F, Synway D&R Center, No.3756, Nanhuan Road, Binjiang District,
Hangzhou, P.R.China, 310053

Tel: +86-571-88860561

Fax: +86-571-88850923

Wechat QR Code: Scan the QR code to give attention to us



Technical Support

Tel: +86-571-88864579

Mobile: +86-18905817070

Email: techsupport@sanhuid.com

Email: techsupport@synway.net

MSN: synway.support@hotmail.com

Sales Department

Tel: +86-571-88860561

Tel: +86-571-88864579

Fax: +86-571-88850923

Email: sales@synway.net