



Synway AST Series

SynAST Application Platform-FreeSwitch Installation Manual

Version 1.0.0.0

Synway Information Engineering Co., Ltd

www.synway.net

Contents

Contents	i
Copyright Declaration	ii
Software License Agreement.....	iii
Revision History	iv
Preface	v
Chapter 1 Installation & Automatic Configuration	1
1.1 FreeSwitch	1
1.1.1 Preparation.....	1
1.1.2 Driver Installation	1
1.1.3 FreeSwitch Installation	1
1.1.4 Configuration.....	2
1.1.5 FreeSwitch Startup.....	2
Chapter 2 Manual Configuration	3
2.1 Zaptel/Dahdi Configuration.....	3
2.2 FreeSwitch Configuration	3
Chapter 3 Test.....	8
3.1 Preparation.....	8
3.2 Test Example.....	8
3.2.1 FreeSwitch Environment	8
Appendix A FAQs	9
Appendix B Technical/Sales Support	10

Copyright Declaration

This manual is provided by Synway Information Engineering Co., Ltd (hereinafter referred to as 'Synway') as the support file for 'Synway AST Series board driver software'. Both the software and this manual are copyrighted and protected by the laws of the People's Republic of China.

All rights reserved; no part of this manual may be extracted, modified, copied, reproduced or transmitted in any form or by any means, electronic or mechanical, without prior written permission from Synway. By using this manual, you agree to the following *Software License Agreement*.

Synway reserves the right to revise this manual without prior note. Please contact Synway for the latest version of this manual before placing an order.

Synway has made every effort to ensure the accuracy of this manual but does not guarantee the absence of errors. Moreover, Synway assumes no responsibility in obtaining permission and authorization of any third party patent, copyright or product involved in relation to the use of this manual.

Note: FreeSwitch mentioned in this book is the registered trademark of FreeSwitch.org.

Software License Agreement

Synway Information Engineering Co., Ltd (hereinafter referred to as 'Synway') owns the copyright of 'this software and its accessories, relative files and archives' (hereinafter referred to as 'this product'). Any company or person can download the corresponding driver software and other useful documents for free directly from our website after purchasing a board of Synway.

Revision History

Version	Date	Comments
Version 1.0.0.0	2009-7	Initial publication.

Note: Only major revisions to this manual itself recorded herein.

Preface

When you use the Synway AST series boards to set up a FreeSwitch application system, this file provides the help for software installation, configuration and test. It aims at those people who use the Synway AST series boards in FreeSwitch for the first time, and takes the use of TEJ-4A/PCI and FXM-16A/PCIe in FreeSwitch-1.0.4pre7 for example.

Chapter 1 introduces how to install and automatically configure the driver of Synway AST series boards in FreeSwitch.

Chapter 2 tells how to manually configure the system.

Chapter 3 shows how to test the Synway AST series boards in FreeSwitch.

Appendix A provides answers to some problems that may occur when using the Synway AST series boards.

Appendix B gives the contact way of technical support and sales department in Synway.

Although Synway has scrupulously checked through this manual, but cannot guarantee the absence of errors and omissions. We sincerely apologize for any consequent inconvenience brought to you and will be very grateful if you kindly give your advice regarding amendments to this book.

Chapter 1 Installation & Automatic Configuration

1.1 FreeSwitch

For detailed information about FreeSwitch, visit the official website of FreeSwitch:
<http://www.freeswitch.org>.

1.1.1 Preparation

Obtain the resource package you need for FreeSwitch installation. See Table 1-1 below for details.

Resource Package	Version Recommendation	Address	Description
zaptel-1.4.x.tar.gz	1.4.x	http://downloads.digium.com/pub/zaptel/releases/	Command: #rpm -q zaptel, to check the version
freeswitch	latest version downloaded from svn	http://svn.freeswitch.org/svn/freeswitch/trunk	Command: #svn co [address] freeswitch, to download freeswitch
Synast-x.x.x.x.tar.gz	1.1.0.0 or above	http://www.sanhuid.com	None

Table 1-1 Resource Packages for FreeSwitch Installation

1.1.2 Driver Installation

Step 1: Install the zaptel driver and the SynAST driver.

Refer to Chapter 3 Driver Installation & Configuration in the file *SynAST_UserManual.pdf*.

1.1.3 FreeSwitch Installation

Step 1: Install FreeSwitch.

```
#cd /usr/src/freeswitch
```

```
# ../bootstrap.sh
```

```
# vim /usr/src/freeswitch/modules.conf
```

Find the line ‘../libs/opensap/mod_opensap’ and remove # in front.

```
# ./configure
```

```
#make
```

```
#make install
```

```
#make samples
```

1.1.4 Configuration

Note: You may choose either the method listed here or the manual configuration (See [Chapter 2 Manual Installation](#)) by individual requirement.

```
#astcfg_zaptel    freeswitch
```

1.1.5 FreeSwitch Startup

Step 1: Modify the module configuration file.

Modify the file modules.conf.xml so as to load the module openzap at the start of FreeSwitch.

```
#cd /usr/local/freeswitch/conf/autoload_configs
```

```
#vim modules.conf.xml
```

Find the line 'mod_openzap' and change it to be <load module="mod_openzap"/>.

Step 2: Start FreeSwitch.

```
#cd /usr/local/freeswitch/bin
```

```
#./freeswitch
```

Chapter 2 Manual Configuration

This chapter takes the FXM-16A/PCIe board and the TEJ-4A/PCI board for example to show you how to configure a system.

2.1 Zaptel/Dahdi Configuration

Refer to Section 3.2.2 Manual Configuration in the document *SynAST_UserManual.pdf*.

2.2 FreeSwitch Configuration

Modify the configuration file according to Table 2-1 below.

Board Config Model File	TEJ-4A/PCI		FXM-16A/PCIe (top 4 slots: trunk; bottom 4 slots: station)
	E1 Mode	T1/J1 Mode	
/usr/ local/ freeswitch/ conf/ openzap.conf	ISDN	ISDN	
	[span zt] name =>OpenZAP1 number=>1 trunk_type=>e1 b-channel=>1->15 d-channel=>16 b-channel=>17->31 [span zt] name =>OpenZAP2 number=>2 trunk_type=>e1 b-channel=>32->46 d-channel=>47 b-channel=>48->62 [span zt] name =>OpenZAP3 number=>3 trunk_type=>e1 b-channel=>63->77 d-channel=>78 b-channel=>79->93 [span zt] name =>OpenZAP4 number=>4 trunk_type=>e1 b-channel=>94->108	[span zt] name =>OpenZAP1 number=>1 trunk_type=>t1 b-channel=>1->23 d-channel=>24 [span zt] name =>OpenZAP2 number=>2 trunk_type=>t1 b-channel=>25->47 d-channel=>48 [span zt] name =>OpenZAP3 number=>3 trunk_type=>t1 b-channel=>49->71 d-channel=>72 [span zt] name =>OpenZAP4 number=>4 trunk_type=>t1 b-channel=>73->95 d-channel=>96	#fxo Interface [span zt] name => OpenZAP-FX01 number => 1 fxo-channel => 1 [span zt] name => OpenZAP-FX02 number => 2 fxo-channel => 2 [span zt] name => OpenZAP-FX03 number => 3 fxo-channel => 3 [span zt] name => OpenZAP-FX04 number => 5 fxo-channel => 4 [span zt] name => OpenZAP-FX05 number => 5 fxo-channel => 5 [span zt] name => OpenZAP-FX06 number => 6 fxo-channel => 6 [span zt] name => OpenZAP-FX07 number => 7 fxo-channel => 7

	d-channel=>109 b-channel=>110->124	[span zt] name => OpenZAP-FX08 number => 8 fxo-channel => 8 #fxs Interface [span zt] name => OpenZAP-FXS9 number => 9 fxs-channel => 9 [span zt] name => OpenZAP-FXS10 number => 10 fxs-channel => 10 [span zt] name => OpenZAP-FXS11 number => 11 fxs-channel =>11 [span zt] name => OpenZAP-FXS12 number => 12 fxs-channel =>12 [span zt] name => OpenZAP-FXS13 number => 13 fxs-channel =>13 [span zt] name => OpenZAP-FXS14 number => 14 fxs-channel =>14 [span zt] name => OpenZAP-FXS15 number => 15 fxs-channel =>15 [span zt] name => OpenZAP-FXS16 number => 16 fxs-channel =>16
/usr/ local/ freeswitch/ conf/ autoload_configs/ openzap.conf.xml	<p>Add the following content behind </settings> in the file.</p> <pre> <pri_spans> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> </pre>	<p>Add the following content behind </settings> in the file.</p> <pre> <analog_spans> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> </pre>

	<pre> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> </pri_spans> </pre>	<pre> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> </pre>
--	--	---

	<pre> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" </pre>
--	---

	<pre> value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> <param name="tonegroup" value="us"/> <param name="digit-timeout" value="2000"/> <param name="max-digits" value="11"/> <param name="dialplan" value="XML"/> <param name="context" value="default"/> <param name="enable-callerid" value="true"/> </analog_spans> </pre>
--	--

Table 2-1 FreeSwitch Configuration

Chapter 3 Test

3.1 Preparation

Use an FXM-16A/PCIe board and a TEJ-4A/PCI board for example. The former 4 modules on the FXM-16A/PCIe board are FXO and the latter 4 are FXS. Meanwhile, configure the TEJ-4A/PCI board with E1+ISDN mode.

Examine the configuration of zaptel:

```
#ztcfg -vv
```

3.2 Test Example

3.2.1 FreeSwitch Environment

Step 1: Examine the configuration of FreeSwitch.

```
#cd /usr/local/freeswitch/bin
#./freeswitch
freeswitch@> oz list
```

Step 2: Test Example 1 (FXM-16A/PCIe).

- 1) # vim /usr/local/freeswitch/conf/dialplan/default.xml
- 2) Modify the head of the file to be:

```
<?xml version="1.0" encoding="utf-8"?>
<!-- http://wiki.freeswitch.org/wiki/Dialplan_XML -->
<include>
  <context name="default">
    <extension name="fxstfxo">
      <condition field="destination_number" expression="^(.*)$">
        <action application="set" data="dialed_number=$1"/>
        <action application="bridge" data="openzap/1/1/${dialed_number}"/>
      </condition>
    </extension>
```

- 3) Restart FreeSwitch or enter the command 'reloadxml' under the command of FreeSwitch to reload the dialing rule.
- 4) Test outbound calls from station.

Appendix A FAQs

Q1: How to deal with errors in the module switch_odbc that sometimes occur while compiling FreeSwitch?

It may be due to the lack of the development package unixodbc. Please download unixodbc and then reinstall FreeSwitch.

Appendix B Technical/Sales Support

Thank you for choosing Synway. Please contact us should you have any inquiry regarding our products. We shall do our best to help you. However, our technicians and salesmen are mainly responsible for maintaining our boards and providing relative technical support. If there are problems about Asterisk, please keep touch with Digium Inc. for help.

Headquarters

Synway Information Engineering Co., Ltd

<http://www.synway.net/>

9F, Synway D&R Center, No.3756, Nanhuan Road, Binjiang District,
Hangzhou, P.R.China, 310053

Tel: +86-571-88860561

Fax: +86-571-88850923

Technical Support

Tel: +86-571-88864579

Mobile: +86-13735549651

Email: techsupport@sanhuid.com

Email: techsupport@synway.net

MSN: scycindy_sh@hotmail.com

Sales Department

Tel: +86-571-88860561

Tel: +86-571-88864579

Fax: +86-571-88850923

Email: sales@synway.net