



Synway AST Series

SynAST Application Platform-Yate Installation Manual

Synway Information Engineering Co., Ltd

www.synway.net

Contents

Contents	i
Copyright Declaration	ii
Software License Agreement.....	iii
Preface	iv
Chapter 1 Installation & Automatic Configuration	1
1.1 Yate	1
1.1.1 Preparation.....	1
1.1.2 Driver Installation	1
1.1.3 Yate Installation	1
1.1.4 Configuration.....	2
1.1.5 Yate Startup.....	2
Chapter 2 Manual Configuration	3
2.1 Zaptel/Dahdi Configuration.....	3
2.2 Yate Configuration.....	3
Chapter 3 Test	5
3.1 Preparation.....	5
3.2 Test Example.....	5
3.2.1 Yate Environment.....	5
Appendix A Technical/Sales Support.....	6

Copyright Declaration

This manual is provided by Synway Information Engineering Co., Ltd (hereinafter referred to as 'Synway') as the support file for 'Synway AST Series board driver software'. Both the software and this manual are copyrighted and protected by the laws of the People's Republic of China.

All rights reserved; no part of this manual may be extracted, modified, copied, reproduced or transmitted in any form or by any means, electronic or mechanical, without prior written permission from Synway. By using this manual, you agree to the following *Software License Agreement*.

Synway reserves the right to revise this manual without prior note. Please contact Synway for the latest version of this manual before placing an order.

Synway has made every effort to ensure the accuracy of this manual but does not guarantee the absence of errors. Moreover, Synway assumes no responsibility in obtaining permission and authorization of any third party patent, copyright or product involved in relation to the use of this manual.

Note: Yate mentioned in this book is the registered trademark of yate.null.ro.

Software License Agreement

Synway Information Engineering Co., Ltd (hereinafter referred to as 'Synway') owns the copyright of 'this software and its accessories, relative files and archives' (hereinafter referred to as 'this product'). Any company or person can download the corresponding driver software and other useful documents for free directly from our website after purchasing a board of Synway.

Preface

When you use the Synway AST series boards to set up a Yate application system, this file provides the help for software installation, configuration and test. It aims at those people who use the Synway AST series boards in Yate for the first time, and takes the use of TEJ-4A/PCI and FXM-16A/PCIe in Yate-1.3.0 for example.

Chapter 1 introduces how to install and automatically configure the driver of Synway AST series boards in Yate.

Chapter 2 tells how to manually configure the system.

Chapter 3 shows how to test the Synway AST series boards in Yate.

Appendix A gives the contact way of technical support and sales department in Synway.

Although Synway has scrupulously checked through this manual, but cannot guarantee the absence of errors and omissions. We sincerely apologize for any consequent inconvenience brought to you and will be very grateful if you kindly give your advice regarding amendments to this book.

Chapter 1 Installation & Automatic Configuration

1.1 Yate

For detailed information about Yate, visit the official website of Yate: <http://yate.null.ro>.

1.1.1 Preparation

Obtain the resource package you need for Yate installation. See Table 1-1 below for details.

Resource Package	Version Recommendation	Address	Description
zaptel-1.4.x.tar.gz	1.4.x	http://downloads.digium.com/pub/zaptel/releases/	Command: <code>#rpm -q zaptel</code> , to check the version
yate	latest version downloaded from CVS	<code>pserver:anonymous@voip.null.ro:/home/cvsroot/private</code>	Respectively execute the following commands: <code>#cvs</code> <code>-d :pserver:anonymous@voip.null.ro:/home/cvsroot/private login</code> <code>#cvs</code> <code>-d :pserver:anonymous@voip.null.ro:/home/cvsroot/private checkout yate</code>
SynAST-x.x.x.x.tar.gz	1.1.0.0 or above	http://www.synway.net	None

Table 1-1 Resource Packages for Yate Installation

1.1.2 Driver Installation

Step 1: Install the zaptel driver and the SynAST driver.

Refer to Chapter 3 Driver Installation & Configuration in the file *SynAST_UserManual.pdf*.

1.1.3 Yate Installation

```
# ./configure
```

```
#make
```

```
#make install
```

1.1.4 Configuration

Note: Follow [Chapter 2 Manual Installation](#) in this file to configure.

1.1.5 Yate Startup

#yate&

Chapter 2 Manual Configuration

This chapter takes the FXM-16A/PCle board and the TEJ-4A/PCI board for example to show you how to configure a system.

2.1 Zaptel/Dahdi Configuration

Refer to Section 3.2.2 Manual Configuration in the document *SynAST_UserManual.pdf*.

2.2 Yate Configuration

Modify the configuration file according to Table 2-1 below.

Board Config Model File	TEJ-4A/PCI		FXM-16A/PCle (top 4 slots: trunk; bottom 4 slots: station)
	E1 Mode	T1/J1 Mode	
/usr/ local/ etc/ yate/ zapcard.conf	ISDN	ISDN	
	[span1-1] type=E1 offset=0 sigchan=16 voicechans=1-15	[span1] type=T1 offset=0 sigchan=24 voicechans=1-23	;fxo Module [span1] type=FXO offset=0 voicechans=1-8 echotaps=4
	[span1-2] type=E1 offset=16 voicechans=1-15	[span2] type=T1 offset=24 sigchan=48 voicechans=1-23	;fxs Module [span2] type=FXS offset=8 voicechans=1-8 echotaps=4 channel=>1-8
	[span2-1] type=E1 offset=31 sigchan=47 voicechans=1-15	[span1] type=T1 offset=48 sigchan=72 voicechans=1-23	
	[span2-2] type=E1 offset=47 voicechans=1-15	[span1] type=T1 offset=72 sigchan=96 voicechans=1-23	
	[span3-1] type=E1 offset=62 sigchan=78 voicechans=1-15		
	[span3-1] type=E1		

	offset=78 voicechans=1-15 [span4-1] type=E1 offset=93 sigchan=109 voicechans=1-15 [span4-2] type=E1 offset=109 voicechans=1-15		
/usr/ local/ etc/ yate/ ysigchan.conf	[link1] type=isdn-pri-net sig=span1-1 voice=span1-1,span1-2 [link2] type=isdn-pri-net sig=span2-1 voice=span2-1,span2-2 [link3] type=isdn-pri-net sig=span3-1 voice=span3-1,span3-2 [link4] type=isdn-pri-net sig=span4-1 voice=span4-1,span4-2	link1] type=isdn-pri-net sig=span1 voice=span1 [link2] type=isdn-pri-net sig=span2 voice=span2 [link3] type=isdn-pri-net sig=span3 voice=span3 [link4] type=isdn-pri-net sig=span4 voice=span4	
/usr/ Local/ etc/ yate/ analog.conf			[link1] echocancel=enable type=FX0 spans=span1 [link2] Echocancel=enable type=FXS spans=span2

Table 2-1 Yate Configuration

Chapter 3 Test

3.1 Preparation

Use an FXM-16A/PCle board and a TEJ-4A/PCI board for example. The former 4 modules on the FXM-16A/PCle board are FXO and the latter 4 are FXS. Meanwhile, configure the TEJ-4A/PCI board with E1+ISDN mode.

Examine the configuration of zaptel:

```
#ztcfg -vv
```

3.2 Test Example

3.2.1 Yate Environment

Step 1: Examine the configuration of Yate.

```
#yate&                # start Yate

#telnet 127.0.0.1 5038 # connect toYate

status zaptel         # enter this command at the terminal telnet to check the configuration
```

Step 2: Test Example 1 (FXM-16A/PCle).

- 1) Add dialing rules to '/usr/local/etc/yate/regexroute.conf':

```
[default]
^3020$=analog/span1/1
```

- 2) Use the client program in Yate to dial 3020 and call out through the first channel on FXM-16A/PCle.

Appendix A Technical/Sales Support

Thank you for choosing Synway. Please contact us should you have any inquiry regarding our products. We shall do our best to help you. However, our technicians and salesmen are mainly responsible for maintaining our boards and providing relative technical support. If there are problems about Asterisk, please keep touch with Digium Inc. for help.

Headquarters

Synway Information Engineering Co., Ltd

<http://www.synway.net/>

9F, Synway D&R Center, No.3756, Nanhuan Road, Binjiang District,
Hangzhou, P.R.China, 310053

Tel: +86-571-88860561

Fax: +86-571-88850923

Technical Support

Tel: +86-571-88864579

Mobile: +86-18905817070

Email: techsupport@sanhuid.com

Email: techsupport@synway.net

MSN: synway.support@hotmail.com

Sales Department

Tel: +86-571-88860561

Tel: +86-571-88864579

Fax: +86-571-88850923

Email: sales@synway.net